

# Atlas Copco Stationary Air Compressors

ZR/ZT 160-275 HV

## Parts list

- Copyright 2013, Atlas Copco (I) Ltd.  
Any unauthorized use or copying of the contents or any part thereof is prohibited.  
This applies in particular to trademarks, model denominations, part numbers and drawings.
- **Use only authorized parts.** Any damage or malfunction caused by the use of unauthorized parts is not covered by Warranty or Product Liability.
- BOM downloaded date - 19 June 2013.  
This ASL is made as per BOM down load dated - 19 June 2013  
After this date if there is any change in BOM it will not reflect in this ASL.

No. 9096 5159 30

2013-08

[www.atlascopco.com](http://www.atlascopco.com)

**Atlas Copco**


Contents

Gear casing .....	<b>1</b>	- HP Outlet - ZR .....	<b>10</b>
Compressor element .....	<b>2</b>	- HP Outlet - ZT .....	<b>11</b>
Gears .....	<b>3</b>	- LP Outlet - ZR .....	<b>12</b>
<b>Mounts on gear casing</b>		- LP Outlet - ZT .....	<b>13</b>
- ZR .....	<b>4</b>	<b>Air outlet</b>	
- ZT .....	<b>5</b>	- ZT pack with aftercooler .....	<b>14</b>
Compressor drive .....	<b>6</b>	- ZT connection air .....	<b>15</b>
Air inlet .....	<b>7</b>	Water system - ZR .....	<b>16</b>
<b>Air flow</b>		<b>Drain system</b>	
- HP Inlet - ZR .....	<b>8</b>	- ZR .....	<b>17</b>
- HP Inlet - ZT .....	<b>9</b>		

Contents

- ZT .....	18	<b>Regulation system</b>	
<b>Coolers</b>		- ZR .....	25
- ZR .....	19	- ZT .....	26
- ZT .....	20	<b>Bodywork</b>	27
- cooling system - ZT .....	21	- Cubicle box .....	28
<b>Oil system</b>		- ZR Inlet silencer .....	29
- ZR .....	22	- ZR Baffles .....	30
- ZT .....	23	- ZT Baffles .....	31
Drive arrangement .....	24	- ZR Doors & stays .....	32
		- ZT Doors & stays .....	33
		Electrical kit starter .....	34
		Vci packing kit .....	34

1




**Gear casing**

1

Ref.	Part number	Qty	Name	Remarks	Ref.	Part number	Qty	Name	Remarks
			ZR160 7.5 bar(e) 190KW/ 3.3KVO					ZR275 7.5 bar(e) 345KW/ 3.3KVO	
			ZR160 7.5 bar(e) 190KW/ 6.6KVO					ZR275 7.5 bar(e) 345KW/ 6.6KVO	
			ZR160 7.5 bar(e) 200KW/ 3.3KVO		1005	1616 6425 04	1	<b>Gear Casing</b>	
			ZR160 7.5 bar(e) 200KW/ 6.6KVO		1007	0663 2107 81	1	Gear casing	
			<b>Gear Casing</b>		1008	1621 3505 00	2	O-Ring	
1005	1616 6425 03	1	Gear casing		1009	0147 1323 00	2	Flange	
			ZR160 8.6 bar(e) 175KW/ 3.3KVO		1010	0101 1953 00	2	Hex.bolt	
			ZR160 8.6 bar(e) 175KW/ 6.6KVO		1015	0686 3716 09	2	Pin	
			ZR160 8.6 bar(e) 190KW/ 3.3KVO		1016	0686 3716 09	2	Plug	
			ZR160 8.6 bar(e) 190KW/ 6.6KVO		1017	0686 3716 09	2	Plug	
			<b>Gear Casing</b>		1018	0686 3716 09	1	Plug	
1005	1616 6425 03	1	Gear casing		1020	0661 1000 31	2	Plug	
			ZR160 10 bar(e) 165KW/ 3.3KVO		1021	0661 1000 31	2	Washer	
			ZR160 10 bar(e) 165KW/ 6.6KVO		1022	0661 1000 31	2	Washer	
			ZR160 10 bar(e) 175KW/ 3.3KVO		1023	0661 1000 31	1	Washer	
			ZR160 10 bar(e) 175KW/ 6.6KVO		1025	0686 4230 07	1	Washer	
			<b>Gear Casing</b>		1030	9125 6303 00	1	Plug	
1005	1616 6425 03	1	Gear casing					Washer	
			ZR250 7.5 bar(e) 300KW/ 3.3KVO					ZT160 7.5 bar(e) 160KW,3.3KV S	
			ZR250 7.5 bar(e) 300KW/ 6.6KVO					ZT160 7.5 bar(e) 160KW,6.6KV S	
			ZR250 7.5 bar(e) 320KW/ 3.3KVO					ZT160 8.6 bar(e) 160KW,3.3KV S	
			ZR250 7.5 bar(e) 320KW/ 6.6KVO					ZT160 8.6 bar(e) 160KW,6.6KV S	
			<b>Gear Casing</b>					ZT200 8.6 bar(e) 200KW,3.3KV S	
1005	1616 6425 02	1	Gear casing		1005	1616 6425 03	1	<b>Gear Casing</b>	
			ZR250 8.6 bar(e) 280KW/ 3.3KVO					Gear casing	
			ZR250 8.6 bar(e) 280KW/ 6.6KVO					ZT160 10 bar(e) 160KW,3.3KV S	
			ZR250 8.6 bar(e) 300KW/ 3.3KVO					ZT160 10 bar(e) 160KW,6.6KV S	
			ZR250 8.6 bar(e) 300KW/ 6.6KVO		1005	1616 6425 03	1	<b>Gear Casing</b>	
			<b>Gear Casing</b>					Gear casing	
1005	1616 6425 02	1	Gear casing					ZT250 7.5 bar(e) 250KW,3.3KV S	
			ZR250 10 bar(e) 255KW/ 3.3KVO					ZT250 7.5 bar(e) 250KW,6.6KV S	
			ZR250 10 bar(e) 255KW/ 6.6KVO					ZT250 8.6 bar(e) 250KW,3.3KV S	
			ZR250 10 bar(e) 280KW/ 3.3KVO					ZT250 8.6 bar(e) 250KW,6.6KV S	
			ZR250 10 bar(e) 280KW/ 6.6KVO		1005	1616 6425 02	1	<b>Gear Casing</b>	
			<b>Gear Casing</b>					Gear casing	
1005	1616 6425 02	1	Gear casing					ZT250 10 bar(e) 250KW,3.3KV S	
			ZR275 7.5 bar(e) 320KW/ 3.3KVO					ZT250 10 bar(e) 250KW,6.6KV S	
			ZR275 7.5 bar(e) 320KW/ 6.6KVO		1005	1616 6425 02	1	<b>Gear Casing</b>	
								Gear casing	
1005	1616 6425 02	1	Gear casing					ZT275 8.6 bar(e) 275KW,3.3KV S	
								ZT275 8.6 bar(e) 275KW,6.6KV S	
								<b>Gear Casing</b>	
								Gear casing	
								ZT275 10 bar(e) 275KW,3.3KV S	
								ZT275 10 bar(e) 275KW,6.6KV S	

1



## Gear casing

1

Ref.	Partnumber	Qty	Name	Remarks	Ref.	Partnumber	Qty	Name	Remarks
1005	1616 6425 02	1	<b>Gear Casing</b> Gear casing ZR200 7.5 bar(e) 240KW/ 3.3KVO ZR200 7.5 bar(e) 240KW/ 6.6KVO ZR200 7.5 bar(e) 255KW/ 3.3KVO ZR200 7.5 bar(e) 255KW/ 6.6KVO					ZT200 7.5 bar(e) 200KW,3.3KVS ZT200 7.5 bar(e) 200KW,6.6KVS ZT200 8.6 bar(e) 200KW,6.6KVS	
1005	1616 6425 01	1	<b>Gear Casing</b> Gear casing ZR200 10 bar(e) 200KW/ 3.3KVO ZR200 10 bar(e) 200KW/ 6.6KVO ZR200 10 bar(e) 220KW/ 3.3KVO ZR200 10 bar(e) 220KW/ 6.6KVO		1005	1616 6425 01	1	<b>Gear Casing</b> Gear casing ZT 200 10 bar(e) 200KW,3.3KVS ZT200 10 bar(e) 200KW,6.6KVS	
1005	1616 6425 01	1	<b>Gear Casing</b> Gear casing ZR200 8.6 bar(e) 220KW/ 3.3KVO ZR200 8.6 bar(e) 220KW/ 6.6KVO ZR200 8.6 bar(e) 240KW/ 3.3KVO ZR200 8.6 bar(e) 240KW/ 6.6KVO		1005	1616 6425 01	1	<b>Gear Casing</b> Gear casing ZT275 7.5 bar(e) 275KW,3.3KVS ZT 275 7.5 bar(e) 275KW,6.6KVS	
1005	1616 6425 01	1	<b>Gear Casing</b> Gear casing		1005	1616 6425 04	1	<b>Gear Casing</b> Gear casing	
					1010	0101 1951 50	2	Pin	
					1015	0686 3716 09	2	Plug	
					1016	0686 3716 09	2	Plug	
					1017	0686 3716 09	1	Plug	
					1018	0686 3716 09	1	Plug	
					1020	0661 1000 31	2	Washer	
					1021	0661 1000 31	2	Washer	
					1022	0661 1000 31	1	Washer	
					1023	0661 1000 31	1	Washer	
					1025	0686 4230 07	1	Plug	
					1030	9125 6303 00	1	Washer	




## Compressor element

2

Ref.	Partnumber	Qty	Name	Remarks	Ref.	Partnumber	Qty	Name	Remarks
1010	1616 5904 81	1	O.f.s.					ZT200 7.5 bar(e)	
1015	0663 2103 24	1	O-Ring					200KW,3.3KV S	
1017	0663 2107 89	1	O-Ring					ZT200 7.5 bar(e)	
1020	0147 1402 03	3	Hex. head screw					200KW,6.6KV S	
1025	0147 1962 34	4	Hex.bolt					ZT200 8.6 bar(e)	
1030	1616 7472 81	1	O.f.s.					200KW,3.3KV S	
1057	1621 0387 00	1	Pipe					ZT200 8.6 bar(e)	
1058	1621 0386 00	2	Seal disc					200KW,6.6KV S	
1060	0663 2103 20	1	O-Ring					ZT 200 10 bar(e)	
1062	0147 1408 00	2	Hex.bolt					200KW,3.3KV S	
1065	0147 1402 03	2	Hex. head screw					ZT200 10 bar(e)	
1070	0663 2107 89	1	O-Ring					200KW,6.6KV S	
1140	0580 0400 03	2	Straight coupling					ZT250 7.5 bar(e)	
1150	0661 1000 25	2	Seal washer					250KW,3.3KV S	
1160	1621 6561 00	1	Hose assembly					ZT250 7.5 bar(e)	
1180	0663 2107 81	2	O-Ring					250KW,6.6KV S	
1185	0147 1323 00	4	Hex.bolt					ZT250 8.6 bar(e)	
1190	1621 2012 00	1	Hose assembly					250KW,3.3KV S	
1215	0147 1323 00	4	Hex.bolt					ZT250 8.6 bar(e)	
1220	0663 2107 81	2	O-Ring					250KW,6.6KV S	
1250	0686 3716 07	1	Plug					ZT250 10 bar(e)	
1255	0661 1000 30	1	Seal washer					250KW,3.3KV S	
1260	0686 3716 04	2	Plug					ZT250 10 bar(e)	
1265	0661 1000 25	2	Seal washer					250KW,6.6KV S	
1290	0686 3716 07	1	Plug					ZT275 7.5 bar(e)	
1295	0661 1000 30	1	Seal washer					275KW,3.3KV S	
1300	0686 3716 04	2	Plug					ZT 275 7.5 bar(e)	
1305	0661 1000 25	2	Seal washer					275KW,6.6KV S	
			ZT160 7.5 bar(e)					ZT275 8.6 bar(e)	
			160KW,3.3KV S					275KW,3.3KV S	
			ZT160 7.5 bar(e)					ZT275 8.6 bar(e)	
			160KW,6.6KV S					275KW,6.6KV S	
			ZT160 8.6 bar(e)					ZT275 10 bar(e)	
			160KW,3.3KV S					275KW,3.3KV S	
			ZT160 8.6 bar(e)					ZT275 10 bar(e)	
			160KW,6.6KV S					275KW,6.6KV S	
			ZT160 10 bar(e)		2010	0244 4184 00	4	Round head drive screw	
			160KW,3.3KV S						
			ZT160 10 bar(e)						
			160KW,6.6KV S						

# 3




## Gears

## 3

Ref.	Partnumber	Qty	Name	Remarks	Ref.	Partnumber	Qty	Name	Remarks
			ZR160 7.5 bar(e) 190KW/ 3.3KVO					ZR200 8.6 bar(e) 240KW/ 6.6KVO	
			ZR160 7.5 bar(e) 190KW/ 6.6KVO		1010	1616 6206 16	1	Gear wheel	
			ZR160 7.5 bar(e) 200KW/ 3.3KVO		1020	0211 1402 00	12	Cap screw	
			ZR160 7.5 bar(e) 200KW/ 6.6KVO		1030	1616 6207 15	1	Gear wheel	
					1040	1616 6208 10	1	Gear wheel	
					1050	0686 3115 46	2	Plug	
1010	1616 6206 13	1	Gear wheel					ZR200 10 bar(e) 200KW/ 3.3KVO	
1020	0211 1402 00	12	Cap screw					ZR200 10 bar(e) 200KW/ 6.6KVO	
1030	1616 6207 12	1	Gear wheel					ZR200 10 bar(e) 220KW/ 3.3KVO	
1035	1616 6275 00	1	Washer					ZR200 10 bar(e) 220KW/ 6.6KVO	
1040	1616 6208 02	1	Gear wheel					ZR200 10 bar(e) 220KW/ 3.3KVO	
1050	1621 3608 00	2	Hex.nipple					ZR200 10 bar(e) 220KW/ 6.6KVO	
			ZR160 8.6 bar(e) 175KW/ 3.3KVO		1010	1616 6206 08	1	Gear wheel	
			ZR160 8.6 bar(e) 175KW/ 6.6KVO		1020	0211 1402 00	12	Cap screw	
			ZR160 8.6 bar(e) 190KW/ 3.3KVO		1030	1616 6207 04	1	Gear wheel	
			ZR160 8.6 bar(e) 190KW/ 6.6KVO		1040	1616 6208 02	1	Gear wheel	
					1050	0686 3115 46	2	Plug	
1010	1616 6206 06	1	Gear wheel					ZR250 7.5 bar(e) 300KW/ 3.3KVO	
1020	0211 1402 00	12	Cap screw					ZR250 7.5 bar(e) 300KW/ 6.6KVO	
1030	1616 6207 16	1	Gear wheel					ZR250 7.5 bar(e) 320KW/ 3.3KVO	
1035	1616 6275 00	1	Washer					ZR250 7.5 bar(e) 320KW/ 6.6KVO	
1040	1616 6208 15	1	Gear wheel					ZR250 7.5 bar(e) 320KW/ 3.3KVO	
1050	1621 3608 00	2	Hex.nipple					ZR250 7.5 bar(e) 320KW/ 6.6KVO	
			ZR160 10 bar(e) 165KW/ 3.3KVO		1010	1616 6206 12	1	Gear wheel	
			ZR160 10 bar(e) 165KW/ 6.6KVO		1020	0211 1402 00	12	Cap screw	
			ZR160 10 bar(e) 175KW/ 3.3KVO		1030	1616 6221 01	1	Gear wheel	
			ZR160 10 bar(e) 175KW/ 6.6KVO		1035	1616 6275 00	1	Washer	
					1040	1616 6220 01	1	Gear wheel	
					1045	1616 6274 00	1	Washer	
					1050	1621 3608 00	2	Hex.nipple	
1010	1616 6206 04	1	Gear wheel					ZR250 8.6 bar(e) 280KW/ 3.3KVO	
1020	0211 1402 00	12	Cap screw					ZR250 8.6 bar(e) 280KW/ 6.6KVO	
1030	1616 6207 07	1	Gear wheel					ZR250 8.6 bar(e) 300KW/ 3.3KVO	
1035	1616 6275 00	1	Washer					ZR250 8.6 bar(e) 300KW/ 6.6KVO	
1040	1616 6208 05	1	Gear wheel					ZR250 8.6 bar(e) 300KW/ 3.3KVO	
1050	1621 3608 00	2	Hex.nipple					ZR250 8.6 bar(e) 300KW/ 6.6KVO	
			ZR200 7.5 bar(e) 240KW/ 3.3KVO		1010	1616 6206 11	1	Gear wheel	
			ZR200 7.5 bar(e) 240KW/ 6.6KVO		1020	0211 1402 00	12	Cap screw	
			ZR200 7.5 bar(e) 255KW/ 3.3KVO		1030	1616 6221 02	1	Gear wheel	
			ZR200 7.5 bar(e) 255KW/ 6.6KVO		1035	1616 6275 00	1	Washer	
					1040	1616 6220 02	1	Gear wheel	
					1045	1616 6274 00	1	Washer	
					1050	1621 3608 00	2	Hex.nipple	
1010	1616 6206 10	1	Gear wheel					ZR250 10 bar(e) 255KW/ 3.3KVO	
1020	0211 1402 00	12	Cap screw					ZR250 10 bar(e) 255KW/ 6.6KVO	
1030	1616 6207 11	1	Gear wheel					ZR250 10 bar(e) 280KW/ 3.3KVO	
1040	1616 6208 09	1	Gear wheel					ZR250 10 bar(e) 280KW/ 6.6KVO	
1050	0686 3115 46	2	Plug					ZR250 10 bar(e) 280KW/ 3.3KVO	
			ZR200 8.6 bar(e) 220KW/ 3.3KVO					ZR250 10 bar(e) 280KW/ 6.6KVO	
			ZR200 8.6 bar(e) 220KW/ 6.6KVO		1010	1616 6206 10	1	Gear wheel	
			ZR200 8.6 bar(e) 240KW/ 3.3KVO		1020	0211 1402 00	12	Cap screw	
					1030	1616 6207 01	1	Gear wheel	

# 3




## Gears

## 3

Ref.	Part number	Qty	Name	Remarks	Ref.	Part number	Qty	Name	Remarks
1035	1616 6275 00	1	Washer					ZT200 10 bar(e)	
1040	1616 6208 01	1	Gear wheel					200KW,6.6KV S	
1050	1621 3608 00	2	Hex.nipple		1010	1616 6206 08	1	Gear wheel	
			ZR275 7.5 bar(e) 320KW/ 3.3KVO		1020	0211 1402 00	12	Cap screw	
			ZR275 7.5 bar(e) 320KW/ 6.6KVO		1030	1616 6207 04	1	Gear wheel	
			ZR275 7.5 bar(e) 345KW/ 3.3KVO		1040	1616 6208 02	1	Gear wheel	
			ZR275 7.5 bar(e) 345KW/ 6.6KVO		1050	1621 3608 00	2	Hex.nipple	
1010	1616 6206 03	1	Bull gear					ZT250 7.5 bar(e)	
1020	0211 1402 00	12	Cap screw					250KW,3.3KV S	
1030	1616 6207 14	1	Pinion lp stage					ZT250 7.5 bar(e)	
1035	1616 6275 00	1	Washer					250KW,6.6KV S	
1040	1616 6208 12	1	Pinion hp stage		1010	1616 6206 12	1	Gear wheel	
1050	1621 3608 00	2	Hex.nipple		1020	0211 1402 00	12	Cap screw	
			ZT160 7.5 bar(e)		1030	1616 6221 01	1	Gear wheel	
			160KW,3.3KV S		1040	1616 6220 01	1	Gear wheel	
			ZT160 7.5 bar(e)		1050	1621 3608 00	2	Hex.nipple	
			160KW,6.6KV S					ZT250 8.6 bar(e)	
1010	1616 6206 13	1	Gear wheel					250KW,3.3KV S	
1020	0211 1402 00	12	Cap screw		1010	1616 6206 11	1	Gear wheel	
1030	1616 6207 12	1	Gear wheel		1020	0211 1402 00	12	Cap screw	
1040	1616 6208 02	1	Gear wheel		1030	1616 6221 02	1	Gear wheel	
1050	1621 3608 00	2	Hex.nipple		1040	1616 6220 02	1	Gear wheel	
			ZT160 8.6 bar(e)		1050	1621 3608 00	2	Hex.nipple	
			160KW,3.3KV S					ZT250 10 bar(e)	
			ZT200 8.6 bar(e)					250KW,6.6KV S	
			200KW,3.3KV S		1010	1616 6206 10	1	Gear wheel	
			ZT160 8.6 bar(e)		1020	0211 1402 00	12	Cap screw	
			160KW,6.6KV S		1030	1616 6207 01	1	Gear wheel	
1010	1616 6206 06	1	Gear wheel		1040	1616 6208 01	1	Gear wheel	
1020	0211 1402 00	12	Cap screw		1050	1621 3608 00	2	Hex.nipple	
1030	1616 6207 16	1	Gear wheel					ZT275 7.5 bar(e)	
1040	1616 6208 15	1	Gear wheel					275KW,3.3KV S	
1050	1621 3608 00	2	Hex.nipple					ZT 275 7.5 bar(e)	
			ZT160 10 bar(e)					275KW,6.6KV S	
			160KW,3.3KV S		1010	1616 6206 03	1	Bull gear	
			ZT160 10 bar(e)		1020	0211 1402 00	12	Cap screw	
			160KW,6.6KV S		1030	1616 6207 14	1	Pinion lp stage	
1010	1616 6206 04	1	Gear wheel		1040	1616 6208 12	1	Pinion hp stage	
1020	0211 1402 00	12	Cap screw		1050	1621 3608 00	2	Hex.nipple	
1030	1616 6207 07	1	Gear wheel					ZT275 8.6 bar(e)	
1040	1616 6208 05	1	Gear wheel					275KW,3.3KV S	
1050	1621 3608 00	2	Hex.nipple					ZT275 8.6 bar(e)	
			ZT200 7.5 bar(e)					275KW,6.6KV S	
			200KW,3.3KV S		1010	1616 6206 12	1	Gear wheel	
			ZT200 7.5 bar(e)		1020	0211 1402 00	12	Cap screw	
			200KW,6.6KV S		1030	1616 6221 01	1	Gear wheel	
1010	1616 6206 09	1	Gear wheel		1035	1616 6275 00	1	Washer	
1020	0211 1402 00	12	Cap screw		1040	1616 6220 01	1	Gear wheel	
1030	1616 6207 02	1	Gear wheel		1045	1616 6274 00	1	Washer	
1040	1616 6208 01	1	Gear wheel		1050	1621 3608 00	2	Hex.nipple	
1050	1621 3608 00	2	Hex.nipple					ZT275 10 bar(e)	
			ZT200 8.6 bar(e)					275KW,3.3KV S	
			200KW,6.6KV S					ZT275 10 bar(e)	
1010	1616 6206 15	1	Gear wheel					275KW,6.6KV S	
1020	0211 1402 00	12	Cap screw		1010	1616 6206 11	1	Gear wheel	
1030	1616 6207 03	1	Gear wheel		1020	0211 1402 00	12	Cap screw	
1040	1616 6208 11	1	Gear wheel		1030	1616 6221 02	1	Gear wheel	
1050	1621 3608 00	2	Hex.nipple		1040	1616 6220 02	1	Gear wheel	
			ZT 200 10 bar(e)		1050	1621 3608 00	2	Hex.nipple	
			200KW,3.3KV S						

4




## Mounts on gearcasing - ZR

4

Ref.	Partnumber	Qty	Name	Remarks	Ref.	Partnumber	Qty	Name	Remarks
	ZR160 7.5 bar(e) 190KW/ 3.3KVO				1010	1621 3957 00	1	Pipe	
	ZR160 7.5 bar(e) 190KW/ 6.6KVO				1120	0580 0013 32	2	Connector	
	ZR160 7.5 bar(e) 200KW/ 3.3KVO				1130	0661 1000 25	2	Seal washer	
	ZR160 7.5 bar(e) 200KW/ 6.6KVO				1131	0580 0013 32	2	Connector	
	ZR160 8.6 bar(e) 175KW/ 3.3KVO				1132	0661 1000 25	2	Seal washer	
	ZR160 8.6 bar(e) 175KW/ 6.6KVO				2010	0663 2107 81	1	O-Ring	
	ZR160 8.6 bar(e) 190KW/ 3.3KVO				2015	0211 1335 03	4	Hex.socket cap screw	
	ZR160 8.6 bar(e) 190KW/ 6.6KVO				2020	1614 8671 00	1	Housing	
	ZR160 10 bar(e) 165KW/ 3.3KVO				2025	0661 1000 25	1	Seal washer	
	ZR160 10 bar(e) 165KW/ 6.6KVO				2030	1624 1633 09	1	Filter element	
	ZR160 10 bar(e) 175KW/ 3.3KVO				2035	0661 1000 30	1	Seal washer	
	ZR160 10 bar(e) 175KW/ 6.6KVO				2040	1614 8672 00	1	Plug	
	ZR250 7.5 bar(e) 300KW/ 3.3KVO				3010	1621 1865 00	1	Housing	
	ZR250 7.5 bar(e) 300KW/ 6.6KVO				3015	1623 5071 00	1	Filter	
	ZR250 7.5 bar(e) 320KW/ 3.3KVO				3020	0663 2107 84	1	O-Ring	
	ZR250 7.5 bar(e) 320KW/ 6.6KVO				3025	1614 8222 00	1	Cover	
	ZR250 8.6 bar(e) 280KW/ 3.3KVO				3030	0211 1247 03	2	Hex sock. Screw	
	ZR250 8.6 bar(e) 280KW/ 6.6KVO							ZR200 7.5 bar(e) 240KW/ 3.3KVO	
	ZR250 8.6 bar(e) 300KW/ 3.3KVO							ZR200 7.5 bar(e) 240KW/ 6.6KVO	
	ZR250 8.6 bar(e) 300KW/ 6.6KVO							ZR200 7.5 bar(e) 255KW/ 3.3KVO	
	ZR250 10 bar(e) 255KW/ 3.3KVO							ZR200 7.5 bar(e) 255KW/ 6.6KVO	
	ZR250 10 bar(e) 255KW/ 6.6KVO							ZR200 8.6 bar(e) 220KW/ 3.3KVO	
	ZR250 10 bar(e) 280KW/ 3.3KVO							ZR200 8.6 bar(e) 220KW/ 6.6KVO	
	ZR250 10 bar(e) 280KW/ 6.6KVO							ZR200 8.6 bar(e) 240KW/ 3.3KVO	
	ZR275 7.5 bar(e) 320KW/ 3.3KVO							ZR200 8.6 bar(e) 240KW/ 6.6KVO	
	ZR275 7.5 bar(e) 320KW/ 6.6KVO							ZR200 10 bar(e) 200KW/ 6.6KVO	
	ZR275 7.5 bar(e) 345KW/ 3.3KVO							ZR200 10 bar(e) 220KW/ 3.3KVO	
	ZR275 7.5 bar(e) 345KW/ 6.6KVO							ZR200 10 bar(e) 220KW/ 6.6KVO	
					1010	1621 3957 00	1	Pipe	
					1120	0580 0013 32	2	Connector	
					1130	0661 1000 25	2	Seal washer	
					2010	0663 2107 81	1	O-Ring	
					2015	0211 1335 03	4	Hex.socket cap screw	
					2020	1614 8671 00	1	Housing	
					2025	0661 1000 25	1	Seal washer	
					2030	1624 1633 09	1	Filter element	
					2035	0661 1000 30	1	Seal washer	
					2040	1614 8672 00	1	Plug	
					3010	1621 1865 00	1	Housing	
					3015	1623 5071 00	1	Filter	
					3020	0663 2107 84	1	O-Ring	
					3025	1614 8222 00	1	Cover	
					3030	0211 1247 03	2	Hex sock. screw	


# 5



**Mounts on gearcasing - ZT****5**

Ref.	Part number	Qty	Name	Remarks	Ref.	Part number	Qty	Name	Remarks
			<b>Breather arrangement complete</b>		2020	1614 8671 00	1	Housing	
1010	1621 1865 00	1	Housing		2025	0661 1000 25	1	Seal washer	
1015	1623 5071 00	1	Filter		2030	1624 1633 09	1	Filter element	
1017	0663 9032 01	1	O-Ring		2035	0661 1000 30	1	Seal washer	
1020	0663 2107 84	1	O-Ring		2040	1614 8672 00	1	Plug	
1025	1614 8222 00	1	Cover		3090	1621 7454 00	1	Pipe	
1030	0211 1247 03	2	Hex sock. Screw		3095	1621 7481 00	1	Pipe	
2010	0663 2107 81	1	O-Ring		3100	0580 0013 32	2	Connector	
2015	0211 1335 03	4	Hex.socket cap screw		3110	0661 1000 25	2	Seal washer	


# 6



**Compressor drive****6**

<b>Ref.</b>	<b>Partnumber</b>	<b>Qty</b>	<b>Name</b>	<b>Remarks</b>	<b>Ref.</b>	<b>Partnumber</b>	<b>Qty</b>	<b>Name</b>	<b>Remarks</b>
1005	1616 6200 00	1	Drive shaft		1065	0508 1100 50	1	Roller bearing	
1010	1616 6201 00	1	Retainer		1070	0335 2169 00	1	Internal circlip	
1015	0502 1090 55	1	Ball bearing		1075	0335 1147 00	1	External clip	
1020	1616 6427 00	1	Beraing housing		1080	1616 6295 00	1	Key	
1025	0147 1369 00	4	Hex.bolt		1085	0337 0009 24	1	Parallel key	
1030	0661 1000 49	4	Seal washer		1110	0663 2107 59	1	O-Ring	
1050	0663 2107 47	1	O-Ring		1115	0147 1363 03	4	Hex.bolt	
1055	0147 1962 29	2	Hex.bolt		1140	1619 6032 01	1	Nipple	
1060	0295 3120 00	1	Lock nut		2005	1616 6202 00	1	Seal arrangement	

7




## Air Inlet

7

Ref.	Partnumber	Qty	Name	Remarks	Ref.	Partnumber	Qty	Name	Remarks
			ZR160 7.5 bar(e) 190KW/ 3.3KVO					ZR250 10 bar(e) 255KW/ 3.3KVO	
			ZR160 7.5 bar(e) 190KW/ 6.6KVO					ZR250 10 bar(e) 255KW/ 6.6KVO	
			ZR160 7.5 bar(e) 200KW/ 3.3KVO					ZR250 10 bar(e) 280KW/ 3.3KVO	
			ZR160 7.5 bar(e) 200KW/ 6.6KVO					ZR250 10 bar(e) 280KW/ 6.6KVO	
			ZR160 8.6 bar(e) 175KW/ 3.3KVO					ZR275 7.5 bar(e) 320KW/ 3.3KVO	
			ZR160 8.6 bar(e) 175KW/ 6.6KVO					ZR275 7.5 bar(e) 320KW/ 6.6KVO	
			ZR160 8.6 bar(e) 190KW/ 3.3KVO					ZR275 7.5 bar(e) 345KW/ 3.3KVO	
			ZR160 8.6 bar(e) 190KW/ 6.6KVO					ZR275 7.5 bar(e) 345KW/ 6.6KVO	
			ZR160 10 bar(e) 165KW/ 3.3KVO	1010	1621 3752 00	1		Pipe	
			ZR160 10 bar(e) 165KW/ 6.6KVO	1020	0686 3716 04	1		Plug	
			ZR160 10 bar(e) 175KW/ 3.3KVO	1030	0580 0013 32	2		Connector	
			ZR160 10 bar(e) 175KW/ 6.6KVO	1040	0686 3716 29	2		Hex.plug	
			ZR160 10 bar(e) 175KW/ 3.3KVO	1050	0661 1000 25	2		Seal washer	
			ZR160 10 bar(e) 175KW/ 6.6KVO	1105	0661 1000 25	1		Seal washer	
			ZR200 7.5 bar(e) 240KW/ 3.3KVO	1121	1621 5284 00	1		Support solenoid	
			ZR200 7.5 bar(e) 240KW/ 6.6KVO	1125	1079 1472 05	2		Screw	
			ZR200 7.5 bar(e) 255KW/ 3.3KVO	1131	1621 5285 00	1		Manifold	
			ZR200 7.5 bar(e) 255KW/ 6.6KVO	1135	0147 1170 03	4		Hex.bolt	
			ZR200 8.6 bar(e) 220KW/ 3.3KVO	1136	9096 4953 00	1		Foam holder	
			ZR200 8.6 bar(e) 220KW/ 6.6KVO	1137	1614 6600 00	2		Disc	
			ZR200 8.6 bar(e) 240KW/ 3.3KVO	1138	0661 1000 25	1		Seal washer	
			ZR200 8.6 bar(e) 240KW/ 6.6KVO	1141	0580 0013 32	3		Connector	
			ZR200 10 bar(e) 200KW/ 3.3KVO	1145	0661 1000 25	3		Seal washer	
			ZR200 10 bar(e) 200KW/ 6.6KVO	1150	1623 6353 04	3		Flexible	
			ZR200 10 bar(e) 220KW/ 3.3KVO	1155	0580 0013 32	2		Connector	
			ZR200 10 bar(e) 220KW/ 6.6KVO	1160	0661 1000 25	2		Seal washer	
			ZR200 10 bar(e) 220KW/ 3.3KVO	1165	0580 2404 00	1		Pipe coupling	
			ZR200 10 bar(e) 220KW/ 6.6KVO	2020	1621 3639 00	1		Gasket	
			ZR200 10 bar(e) 220KW/ 3.3KVO	2030	0147 1482 00	2		Hex.bolt	
			ZR200 10 bar(e) 220KW/ 6.6KVO	2040	0266 2114 00	2		Hexagon nut	
			ZR200 10 bar(e) 220KW/ 3.3KVO	2050	0147 1962 35	2		Hex.bolt	
			ZR200 10 bar(e) 220KW/ 6.6KVO	2060	0301 2378 00	4		Plain washer	
			ZR200 10 bar(e) 220KW/ 3.3KVO	2070	1621 3120 00	1		Valve seat	
			ZR200 10 bar(e) 220KW/ 6.6KVO	2120	1623 1987 00	1		Muffler	
			ZR200 10 bar(e) 220KW/ 3.3KVO		<b>1621 3305 83</b>	<b>1</b>		<b>Valve</b>	
			ZR200 10 bar(e) 220KW/ 6.6KVO	3010	1621 3305 07	• 1		Unloader assembly	
			ZR200 10 bar(e) 220KW/ 3.3KVO	3020	1621 0037 00	• 1		Piston	
			ZR200 10 bar(e) 220KW/ 6.6KVO	3030	0500 4510 03	• 2		Plain bearing	
			ZR250 7.5 bar(e) 300KW/ 3.3KVO	3040	2102 0067 00	• 1		Spring	
			ZR250 7.5 bar(e) 300KW/ 6.6KVO	3050	1621 4908 00	• 1		Diaphragm	
			ZR250 7.5 bar(e) 300KW/ 3.3KVO	3060	1621 3504 00	• 1		Valve cover	
			ZR250 7.5 bar(e) 300KW/ 6.6KVO	3070	0147 1364 03	• 8		Hex.bolt	
			ZR250 7.5 bar(e) 320KW/ 3.3KVO	3080	2250 5578 00	• 1		Valve-h p unloader	
			ZR250 7.5 bar(e) 320KW/ 6.6KVO	3090	0335 1130 00	• 1		Circlip	
			ZR250 8.6 bar(e) 280KW/ 3.3KVO	3100	1621 3820 00	• 1		Hex.bolt	
			ZR250 8.6 bar(e) 280KW/ 6.6KVO	3110	0261 1099 29	• 1		Nut	
			ZR250 8.6 bar(e) 280KW/ 3.3KVO	3120	1621 3760 00	• 1		Valve	
			ZR250 8.6 bar(e) 280KW/ 6.6KVO	3130	2255 0022 00	• 1		Shaft	
			ZR250 8.6 bar(e) 300KW/ 3.3KVO	3140	1621 0030 00	• 1		Ring	
			ZR250 8.6 bar(e) 300KW/ 6.6KVO	3150	2254 7041 00	• 1		Bearing block	
			ZR250 8.6 bar(e) 300KW/ 3.3KVO	3160	2255 0038 00	• 1		Lock nut	
			ZR250 8.6 bar(e) 300KW/ 6.6KVO	3170	0301 2178 01	• 1		Plain washer	
			ZR250 8.6 bar(e) 300KW/ 3.3KVO	<b>3180</b>	<b>1202 8884 00</b>	<b>• 2</b>		<b>Pivot</b>	
			ZR250 8.6 bar(e) 300KW/ 6.6KVO		0108 1242 00	•• 2		Elastic pin	
				3190	1619 7142 00	• 2		Washer	
				3200	1619 7087 00	• 2		Sleeve bearing	

7




## Air Inlet

7

Ref.	Partnumber	Qty	Name	Remarks	Ref.	Partnumber	Qty	Name	Remarks
3210	1621 0039 00	• 2	Flange					275KW,3.3KV S	
3220	0147 1247 03	• 6	Hex.bolt					ZT 275 7.5 bar(e)	
3230	0266 2111 00	• 2	Hex.nut					275KW,6.6KV S	
3240	0277 1311 00	• 2	Hex.nut					ZT275 8.6 bar(e)	
3280	1621 4290 00	• 1	Manifold					275KW,3.3KV S	
3285	1613 4036 00	• 1	Gasket					ZT275 8.6 bar(e)	
3300	0663 2107 90	• 1	O-Ring					275KW,6.6KV S	
3310	0663 2108 63	• 1	O-Ring					ZT275 10 bar(e)	275KW,3.3KV S
3320	0211 1963 78	• 2	Hex.cap screw					S	
3330	1621 3753 00	• 1	Pipe					ZT275 10 bar(e)	275KW,6.6KV S
3340	0580 0014 47	• 1	Pipe coupling					S	
3350	0661 1000 25	• 1	Seal washer		1010	1621 4202 00	1	Pipe	
4040	1615 7884 00	12	Clip		1020	0686 3716 04	1	Plug	
5070	0147 1249 00	2	Hex.bolt		1030	0580 0013 32	2	Connector	
5075	0291 1128 15	2	Nut		1040	0661 1000 25	2	Seal washer	
5080	0296 1110 00	2	Wing nut		1050	0661 1000 25	1	Seal washer	
5085	1619 2766 02	4	Paint stripping bolt		1121	1621 5284 00	1	Support solenoid vlv	
	<b>1621 5387 81</b>	<b>1</b>	<b>Filter</b>		1125	1079 1472 05	2	Screw	
6010	1621 1389 00	• 1	Filter element		1131	1621 5285 00	1	Manifold	
6015	1621 2245 00	• 2	Clamp		1135	0147 1170 03	4	Hex.bolt	
	<b>1621 5387 80</b>	<b>• 1</b>	<b>Air inlet filter complete</b>		1136	9096 4953 00	1	Foam holder	
7005	1621 4883 00	•• 1	Ring		1141	0580 0013 32	3	Connector	
7010	1621 5386 00	•• 1	Manifold		1145	0661 1000 25	3	Seal washer	
7015	1621 5387 00	•• 1	Housing		1150	1623 6353 04	3	Flexible	
7020	1621 5388 00	•• 1	Outlet		1155	0580 0013 32	2	Connector	
8010	1621 4206 80	• 1	Hose		1160	0661 1000 25	2	Seal washer	
8030	0347 6124 00	• 2	Hose clip		1165	0580 2404 00	1	Pipe coupling	
			ZT160 7.5 bar(e)		1175	0147 1480 00	1	Hex.bolt	
			160KW,3.3KV S		2020	1621 3639 00	1	Gasket	
			ZT160 7.5 bar(e)		2030	0147 1482 00	2	Hex.bolt	
			160KW,6.6KV S		2040	0266 2114 00	2	Hexagon nut	
			ZT160 8.6 bar(e)		2050	0147 1962 35	2	Hex.bolt	
			160KW,3.3KV S		2060	0301 2378 00	4	Plain washer	
			ZT160 8.6 bar(e)		2070	1621 3120 00	1	Valve seat	
			160KW,6.6KV S		2120	1623 1987 00	1	Muffler	
			ZT160 10 bar(e)			<b>1621 3305 83</b>	<b>1</b>	<b>Valve</b>	
			160KW,3.3KV S		3010	1621 3305 07	• 1	Unloader assembly	
			ZT160 10 bar(e)		3020	1621 0037 00	• 1	Piston	
			160KW,6.6KV S		3030	0500 4510 03	• 2	Plain bearing	
			ZT200 7.5 bar(e)		3040	2102 0067 00	• 1	Spring	
			200KW,3.3KV S		3050	1621 4908 00	• 1	Diaphragm	
			ZT200 7.5 bar(e)		3060	1621 3504 00	• 1	Valve cover	
			200KW,6.6KV S		3070	0147 1364 03	• 8	Hex.bolt	
			ZT200 8.6 bar(e)		3080	2250 5578 00	• 1	Valve-h p unloader	
			200KW,3.3KV S		3090	0335 1130 00	• 1	Circlip	
			ZT200 8.6 bar(e)		3100	1621 3820 00	• 1	Hex.bolt	
			200KW,6.6KV S		3110	0261 1099 29	• 1	Nut	
			ZT 200 10 bar(e)		3120	1621 3760 00	• 1	Valve	
			200KW,3.3KV S		3130	2255 0022 00	• 1	Shaft	
			ZT200 10 bar(e)		3140	1621 0030 00	• 1	Ring	
			200KW,6.6KV S		3150	2254 7041 00	• 1	Bearing block	
			ZT250 7.5 bar(e)		3160	2255 0038 00	• 1	Lock nut	
			250KW,3.3KV S		3170	0301 2178 01	• 1	Plain washer	
			ZT250 7.5 bar(e)		<b>3180</b>	<b>1202 8884 00</b>	<b>• 2</b>	<b>Pivot</b>	
			250KW,6.6KV S			0108 1242 00	•• 2	Elastic pin	
			ZT250 8.6 bar(e)		3190	1619 7142 00	• 2	Washer	
			250KW,3.3KV S		3200	1619 7087 00	• 2	Sleeve bearing	
			ZT250 8.6 bar(e)		3210	1621 0039 00	• 2	Flange	
			250KW,6.6KV S		3220	0147 1247 03	• 6	Hex.bolt	
			ZT250 10 bar(e)		3230	0266 2111 00	• 2	Hex.nut	
			250KW,3.3KV S		3240	0277 1311 00	• 2	Hex.nut	
			ZT250 10 bar(e)		3280	1621 4290 00	• 1	Manifold	
			250KW,6.6KV S		3285	1613 4036 00	• 1	Gasket	
			ZT275 7.5 bar(e)		3300	0663 2107 90	• 1	O-Ring	

7




## Air Inlet

7

Ref.	Partnumber	Qty	Name	Remarks	Ref.	Partnumber	Qty	Name	Remarks
3310	0663 2108 63	• 1	O-Ring			<b>1621 5387 81</b>	<b>1</b>	<b>Filter</b>	
3320	0211 1963 78	• 2	Hex.cap screw		6010	1621 1389 00	• 1	Filter element	
3330	1621 3753 00	• 1	Pipe		6015	1621 2245 00	• 2	Clamp	
3340	0580 0014 47	• 1	Pipe coupling			<b>1621 5387 80</b>	<b>• 1</b>	<b>Air inlet filter complete</b>	
3350	0661 1000 25	• 1	Seal washer		7005	1621 4883 00	•• 1	Ring	
4040	1615 7884 00	12	Clip		7010	1621 5386 00	•• 1	Manifold	
5070	0147 1249 00	2	Hex.bolt		7015	1621 5387 00	•• 1	Housing	
5075	0291 1128 15	2	Nut		7020	1621 5388 00	•• 1	Outlet	
5080	0296 1110 00	2	Wing nut		8010	1621 4206 80	1	Hose	
5085	1619 2766 02	4	Paint stripping bolt		8030	0347 6124 00	• 2	Hose clip	


8



**Airflow HP Inlet - ZR****8**

<b>Ref.</b>	<b>Partnumber</b>	<b>Qty</b>	<b>Name</b>	<b>Remarks</b>	<b>Ref.</b>	<b>Partnumber</b>	<b>Qty</b>	<b>Name</b>	<b>Remarks</b>
1010	0663 2107 76	2	O-Ring		1050	0160 6105 00	4	Screw	
1015	0147 1402 03	2	Hex. head screw		1055	1619 2766 00	2	Paint stripping bolt	
1020	0147 1962 32	2	Bolt		1060	1619 2766 00	4	Paint stripping bolt	
1025	0266 2112 00	2	Hexagon nut		2010	1621 4054 00	1	Pipe	
1030	0147 1402 03	4	Hex. head screw		2020	0686 3716 07	1	Plug	
1045	0160 6105 00	4	Screw		2030	0661 1000 30	1	Seal washer	


# 9



**Airflow HP Inlet - ZT****9**

<b>Ref.</b>	<b>Partnumber</b>	<b>Qty</b>	<b>Name</b>	<b>Remarks</b>	<b>Ref.</b>	<b>Partnumber</b>	<b>Qty</b>	<b>Name</b>	<b>Remarks</b>
1010	9096 4385 00	1	Pipe		1060	0634 1001 10	2	Pipe coupling	
1020	0663 2106 58	1	O-Ring		1070	9096 4386 00	1	Pipe	
1030	0147 1406 00	2	Hex.bolt		1080	0603 4106 03	1	Hex.nipple	
1040	0147 1409 00	2	Hex.bolt		1090	0803 5011 10	1	Silencer	
1050	0266 2112 00	2	Hexagon nut						

# 10




**Air flow - HP Outlet - ZR**

10

Ref.	Partnumber	Qty	Name	Remarks	Ref.	Partnumber	Qty	Name	Remarks
1005	1621 3127 00	1	Pipe		2010	2001 0225 00	1	Bush	
1006	0686 3716 04	1	Plug		3020	1604 9851 01	1	Valve	
1007	0661 1000 25	1	Seal washer		3030	2102 0827 00	1	Spring	
1010	0663 2106 58	1	O-Ring		3040	1621 3467 00	1	Valve seat	
1015	0147 1402 03	4	Hex. head screw		3050	0663 2107 50	1	O-Ring	
1020	0147 1962 29	4	Hex.bolt		3060	0663 2107 79	1	O-Ring	
1055	0663 2107 80	1	O-Ring		3070	0147 1363 03	4	Hex.bolt	
1060	0147 1402 03	4	Hex. head screw		3080	0663 2107 49	1	O-Ring	
1150	1621 3013 00	3	Hex.bolt		3090	1621 3198 00	1	Silencer	
1155	0663 2107 50	1	O-Ring		3100	0663 2107 50	1	O-Ring	
1160	0663 2107 12	1	O-Ring		3120	1623 5751 00	1	Insulation	
2005	1621 3199 00	1	Valve housing		3130	0147 1402 03	8	Hex. head screw	

# 11




## Air flow - HP Outlet - ZT

11

Ref.	Partnumber	Qty	Name	Remarks	Ref.	Partnumber	Qty	Name	Remarks
1005	1621 3127 00	1	Pipe		3020	1604 9851 01	1	Valve	
1006	0686 3716 04	1	Plug		3030	2102 0827 00	1	Spring	
1007	0661 1000 25	1	Seal washer		3040	1621 3467 00	1	Valve seat	
1010	0663 2106 58	1	O-Ring		3050	0663 2107 50	1	O-Ring	
1015	0147 1402 03	4	Hex. head screw		3060	0663 2107 79	1	O-Ring	
1020	0147 1962 29	4	Hex.bolt		3070	0147 1363 03	4	Hex.bolt	
1055	0663 2107 80	1	O-Ring		3080	0663 2107 49	1	O-Ring	
1060	0147 1402 03	4	Hex. head screw		3090	1621 3198 10	1	Silencer	
1150	1621 3013 00	3	Hex.bolt		3100	0663 2107 50	1	O-Ring	
1155	0663 2107 50	1	O-Ring		3120	1623 5751 00	1	Insulation	
1160	0663 2107 12	1	O-Ring		3130	0147 1402 03	8	Hex. head screw	
2005	1621 3199 10	1	Valve housing		3140	0661 1000 32	2	Seal washer	
2010	2001 0225 00	1	Bush						

# 12




**Air flow - LP Outlet - ZR**

12

<u>Ref.</u>	<u>Partnumber</u>	<u>Qty</u>	<u>Name</u>	<u>Remarks</u>	<u>Ref.</u>	<u>Partnumber</u>	<u>Qty</u>	<u>Name</u>	<u>Remarks</u>
1005	1621 3109 11	1	Outlet		1030	0147 1497 00	1	Hex bolt	
1010	0663 2106 20	1	O-Ring		1045	0663 2106 26	1	O-Ring	
1015	0663 2107 77	1	O-Ring		1050	0147 1962 35	2	Hex.bolt	
1020	0147 1403 03	3	Hex.bolt						

# 13




## Air flow - LP Outlet - ZT

13

Ref.	Partnumber	Qty	Name	Remarks	Ref.	Partnumber	Qty	Name	Remarks
1010	1621 6218 11	1	Adaptor		1150	0663 2106 58	1	O-Ring	
1020	0663 2106 97	1	O-Ring		1160	1621 1426 11	1	Connection	
1030	0211 1960 28	5	Cap screw		1165	0211 1960 28	1	Cap screw	
1040	1621 6178 11	2	Pipe		1175	0147 1478 03	5	Hex.bolt	
1050	0663 2106 58	2	O-Ring		1180	1621 2811 00	1	Flange	
1060	0663 2108 49	2	O-Ring		1190	0663 2107 80	1	O-Ring	
1070	0147 1479 00	12	Hex.bolt		1200	0147 1402 03	4	Hex. head screw	
1080	0147 1489 00	1	Hex.bolt		2010	1621 1425 08	1	Silencer	
1090	9096 4382 00	1	Pipe		2030	0663 2106 20	2	O-Ring	
1100	1621 2799 00	1	Bracket		2040	1623 5753 00	1	Insulation	
1110	0101 1951 53	2	Pin		2050	0663 2106 98	1	O-Ring	
1120	0147 1476 03	2	Hex. head screw		2060	1621 1424 11	1	Collector	
1140	0147 1477 03	4	Hex. head screw						


# 14



**Air outlet - ZT pack with aftercooler****14**

<b>Ref.</b>	<b>Partnumber</b>	<b>Qty</b>	<b>Name</b>	<b>Remarks</b>	<b>Ref.</b>	<b>Partnumber</b>	<b>Qty</b>	<b>Name</b>	<b>Remarks</b>
1010	9096 4383 00	1	Pipe		1050	1624 4132 85	1	Coupling	
1020	0663 2107 80	1	O-Ring		1060	0147 1323 00	2	Hex.bolt	
1030	0147 1402 03	4	Hex. head screw		1070	0301 2335 00	2	Plain washer	
1040	9096 4387 00	1	Pipe						


# 15



**Air outlet - ZT connection air****15**

<b>Ref.</b>	<b>Partnumber</b>	<b>Qty</b>	<b>Name</b>	<b>Remarks</b>	<b>Ref.</b>	<b>Partnumber</b>	<b>Qty</b>	<b>Name</b>	<b>Remarks</b>
1010	1623 2121 00	1	Compensator		1040	1613 5983 01	1	Hex.plug	
1020	0147 1480 03	4	Hex.bolt		1050	1621 4217 00	2	Plate	
1030	0266 2114 00	4	Hexagon nut		1060	1079 1472 05	2	Screw	

# 16




## Water system - ZR

16

Ref.	Partnumber	Qty	Name	Remarks	Ref.	Partnumber	Qty	Name	Remarks
1005	1621 9553 00	1	Pipe		1186	1621 3815 00	1	Pipe	
1006	0686 3716 44	1	Hexagon plug		1187	0686 3716 44	1	Hexagon plug	
1007	0661 1000 25	1	Seal washer		1188	0661 1000 25	1	Seal washer	
1010	0663 2107 86	1	O-Ring		1189	0147 1413 00	2	Hex.bolt	
1015	0147 1962 30	2	Hex.bolt		2001	9096 4399 00	1	Pipe	
1020	0147 1412 00	2	Hex.bolt		2002	0663 2107 79	1	O-Ring	
1025	0663 2107 81	1	O-Ring		2003	0211 1960 28	4	Cap screw	
1051	1621 9554 00	1	Pipe		2005	1623 2121 00	1	Compensator	
1052	0686 3716 44	1	Hexagon plug		2010	0147 1480 03	4	Hex.bolt	
1053	0661 1000 25	1	Seal washer		2015	1613 5983 01	1	Hex.plug	
1055	0663 2107 86	2	O-Ring		2020	9096 4400 00	2	Pipe	
1060	0147 1412 00	2	Hex.bolt		2025	0663 3143 00	2	O-Ring	
1066	0147 1413 00	2	Hex.bolt		2030	0211 1487 03	8	Cap screw	
1155	0663 2107 86	1	O-Ring		2040	1623 3125 00	2	Compensator	
1156	1621 3045 00	1	Flange		2045	0147 1478 03	8	Hex.bolt	
1157	0663 2107 86	2	O-Ring		2046	0266 2114 00	8	Hexagon nut	
1160	0147 1365 03	2	Hex.bolt		2050	0686 9170 00	2	Hex.plug	
1185	0607 1100 76	1	Socket						


# 17



## Drain system - ZR

Ref.	Partnumber	Qty	Name	Remarks	Ref.	Partnumber	Qty	Name	Remarks
<b>Electrical wiring</b>					<b>Safety valve complete</b>				
1010	1621 6932 01	1	Wiring for drain		2010	0830 1008 23	2	Safety valve	
1020	0697 9809 06	1	Lock nut		2020	0661 1000 32	2	Seal washer	
1030	1089 0659 57	1	Sensor		2030	0830 1008 13	1	Safety valve	
1040	0147 1320 03	1	Hex.bolt		2040	0661 1000 32	1	Seal washer	
1050	0661 1000 25	1	Seal washer		2050	0605 8700 75	1	Bushing	
1060	1089 0659 57	1	Sensor					ZR160 7.5 bar(e) 190KW/ 3.3KVO	
1070	0661 1000 25	1	Seal washer					ZR160 7.5 bar(e) 190KW/ 6.6KVO	
1080	1089 9439 18	1	Valve					ZR160 7.5 bar(e) 200KW/ 3.3KVO	
1090	1088 1001 01	1	Warning mark					ZR160 7.5 bar(e) 200KW/ 6.6KVO	
1100	1089 9439 16	1	Valve					ZR160 8.6 bar(e) 175KW/ 3.3KVO	
1110	1088 1001 01	1	Warning mark					ZR160 8.6 bar(e) 175KW/ 6.6KVO	
			ZR250 7.5 bar(e) 300KW/ 3.3KVO					ZR160 8.6 bar(e) 190KW/ 6.6KVO	
			ZR250 7.5 bar(e) 300KW/ 6.6KVO					ZR160 10 bar(e) 165KW/ 3.3KVO	
			ZR250 7.5 bar(e) 320KW/ 3.3KVO					ZR160 10 bar(e) 165KW/ 6.6KVO	
			ZR250 7.5 bar(e) 320KW/ 6.6KVO					ZR160 10 bar(e) 175KW/ 3.3KVO	
			ZR250 8.6 bar(e) 280KW/ 3.3KVO					ZR160 10 bar(e) 175KW/ 6.6KVO	
			ZR250 8.6 bar(e) 280KW/ 6.6KVO					ZR200 7.5 bar(e) 240KW/ 3.3KVO	
			ZR250 8.6 bar(e) 300KW/ 3.3KVO					ZR200 7.5 bar(e) 240KW/ 6.6KVO	
			ZR250 8.6 bar(e) 300KW/ 6.6KVO					ZR200 7.5 bar(e) 255KW/ 3.3KVO	
			ZR275 7.5 bar(e) 320KW/ 3.3KVO					ZR200 7.5 bar(e) 255KW/ 6.6KVO	
			ZR275 7.5 bar(e) 320KW/ 6.6KVO					ZR200 8.6 bar(e) 220KW/ 3.3KVO	
			ZR275 7.5 bar(e) 345KW/ 3.3KVO					ZR200 8.6 bar(e) 220KW/ 6.6KVO	
			ZR275 7.5 bar(e) 345KW/ 6.6KVO					ZR200 8.6 bar(e) 240KW/ 3.3KVO	
			<b>Safety valve complete</b>					ZR200 8.6 bar(e) 240KW/ 6.6KVO	
2010	0830 1008 23	2	Safety valve					<b>Safety valve complete</b>	
2020	0661 1000 32	2	Seal washer		2010	0830 1008 23	2	Safety valve	
2030	0830 1008 09	1	Safety valve		2020	0661 1000 32	2	Seal washer	
2040	0661 1000 32	1	Seal washer		2030	0830 1008 08	1	Safety valve	
2050	0605 8700 75	1	Bushing		2040	0661 1000 31	1	Washer	
			ZR200 10 bar(e) 200KW/ 3.3KVO		2050	0605 8400 19	1	Bushing	
			ZR200 10 bar(e) 200KW/ 6.6KVO					<b>Drains complete</b>	
			ZR200 10 bar(e) 220KW/ 3.3KVO		3010	1621 5106 00	1	Support for hat drain	
			ZR200 10 bar(e) 220KW/ 6.6KVO		3020	1619 2766 00	1	Paint stripping bolt	
			ZR250 10 bar(e) 255KW/ 3.3KVO		3030	0147 1170 03	4	Hex.bolt	
			ZR250 10 bar(e) 255KW/ 6.6KVO		3040	0581 1200 29	1	Pipe coupling	
			ZR250 10 bar(e) 280KW/ 3.3KVO		3050	0070 6002 06	AR	Nylon tube	
			ZR250 10 bar(e) 280KW/ 6.6KVO						

# 17




**Drain system - ZR**

17

<b>Ref.</b>	<b>Part number</b>	<b>Qty</b>	<b>Name</b>	<b>Remarks</b>	<b>Ref.</b>	<b>Part number</b>	<b>Qty</b>	<b>Name</b>	<b>Remarks</b>
3060	0581 0001 41	1	Pipe coupling		3140	0070 6002 06	AR	Nylon tube	
3070	0571 0020 23	1	Hose nipple		3150	0581 0001 41	1	Pipe coupling	
3080	0075 4005 56	AR	Hose		3160	0571 0020 23	1	Hose nipple	
3090	0347 6103 00	2	Hose clip		3170	0075 4005 56	AR	Hose	
3100	0571 0020 38	1	Hose nipple		3180	0347 6103 00	2	Hose clip	
3110	8204 0940 34	1	Valve		3190	0571 0020 38	1	Hose nipple	
3120	1503 2564 04	1	Nipple		3200	0571 0020 23	2	Hose nipple	
3130	0581 1200 29	1	Pipe coupling						

# 18




## Drain system - ZT

18

Ref.	Part number	Qty	Name	Remarks	Ref.	Part number	Qty	Name	Remarks
			<b>Water separator complete</b>					<b>Drain pipes complete</b>	
1010	0663 2107 33	1	O-Ring		5010	0580 0014 43	1	Pipe coupling	
1020	0211 1403 00	4	Hex.socket cap screw		5020	0661 1000 29	1	Washer	
1030	0301 2358 00	4	Plain washer		5030	1621 5228 00	1	Pipe for drains	
1040	0686 3716 30	1	Plug		5040	0580 0014 43	1	Pipe coupling	
1050	0661 1000 25	1	Seal washer		5050	1621 5227 00	1	Cover	
1060	0686 3716 10	1	Plug		5060	0686 4202 03	1	Plug	
1070	0661 1000 32	1	Seal washer		5070	0581 0034 01	1	Pipe coupling	
1080	1621 2354 00	1	Flange		5080	0661 1000 29	1	Washer	
1090	0663 2107 33	1	O-Ring		5090	0663 2108 94	4	O-Ring	
1100	0147 1407 03	4	Hex.bolt		5100	0147 1408 03	8	Bolt	
1110	0301 2358 00	8	Plain washer		5110	0303 1274 01	2	Plain washer	
1120	0266 2112 00	4	Hexagon nut		5120	0661 1000 27	2	Seal washer	
	<b>1623 1855 81</b>	<b>1</b>	<b>Housing</b>		5130	1621 7656 00	1	Pipe	
2010		• 1	Valve housing		5140	0581 0000 72	1	Male adapter	
2020	1621 3238 00	• 1	Spacer		5150	0581 0000 72	2	Male adapter	
2030	1614 6516 00	• 1	Swirler		5160	0571 0020 23	1	Hose nipple	
2040	1621 3487 00	• 1	Impinger		5170	0075 4005 56	AR	Hose	
2050	0663 6140 00	• 1	O-Ring		5180	0347 6103 00	2	Hose clip	
2060	0147 1383 03	• 1	Hex.bolt		5190	0571 0020 38	1	Hose nipple	
2070	1621 5087 00	• 1	Rod		5200	8204 0940 34	1	Valve	
2080	0301 2121 01	• 1	Plain washer		5210	1503 2564 04	1	Nipple	
2090	1621 5086 00	• 1	Plate		5220	0686 9130 00	2	Hex.plug	
2100	0301 2121 01	• 1	Plain washer		5230	0686 3716 04	1	Plug	
2110	0147 1962 65	• 1	Hex.bolt					<b>With aftercooler</b>	
2120	0663 2108 94	• 1	O-Ring		5070	0581 0034 01	1	Pipe coupling	
2130	0147 1407 03	• 4	Hex.bolt		5160	0571 0020 23	1	Hose nipple	
2140	0301 2358 00	• 8	Plain washer		5170	0075 4005 56	AR	Hose	
2150	0266 2112 00	• 4	Hexagon nut		5180	0347 6103 00	2	Hose clip	
2160	0147 1107 04	• 1	Screw		5190	0571 0020 38	1	Hose nipple	
	<b>2000 0227 65</b>	<b>1</b>	<b>Elec.system</b>					ZT 275 7.5 bar(e)	
3010	1621 6934 01	• 1	Wiring for drain					275KW,6.6KV S	
3020	0697 9809 06	• 1	Lock nut					ZT275 7.5 bar(e)	
3030	0147 1320 03	• 1	Hex.bolt					275KW,3.3KV S	
3040	0147 1320 03	• 1	Hex.bolt					ZT275 8.6 bar(e)	
3050	0661 1000 25	• 1	Seal washer					275KW,3.3KV S	
3060	1089 0659 57	• 2	Sensor					ZT275 8.6 bar(e)	
3070	0661 1000 25	• 1	Seal washer					275KW,6.6KV S	
3080	1089 9439 18	• 1	Valve					<b>Safety valve complete</b>	
3090	1088 1001 01	• 1	Warning mark		6010	0830 1008 23	2	Safety valve	
3100	1089 9439 16	• 1	Valve		6020	0661 1000 32	2	Seal washer	
3110	1088 1001 01	• 1	Warning mark		6030	0830 1008 09	1	Safety valve	
	<b>1621 4396 80</b>	<b>1</b>	<b>Cover for coolers</b>		6040	0661 1000 32	1	Seal washer	
4010		• 1	Cover for cooler		6050	0605 8700 75	1	Bushing	
4020	1621 7941 00	• 1	Bushing					ZT160 10 bar(e)	
4030	0661 1000 27	• 1	Seal washer					160KW,3.3KV S	
4040	0661 1000 27	• 1	Seal washer					ZT160 10 bar(e)	
4050	1621 4418 00	• 1	Plate					160KW,6.6KV S	
4060	0147 1962 65	• 4	Hex.bolt					ZT200 10 bar(e)	
4070	0147 1962 65	• 4	Hex.bolt					200KW,6.6KV S	

# 18




## Drain system - ZT

18

Ref.	Part number	Qty	Name	Remarks	Ref.	Part number	Qty	Name	Remarks
			ZT 200 10 bar(e) 200KW,3.3KV S					ZT200 7.5 bar(e) 200KW,6.6KV S	
			ZT250 10 bar(e) 250KW,3.3KV S					ZT200 8.6 bar(e) 200KW,3.3KV S	
			ZT250 10 bar(e) 250KW,6.6KV S					ZT200 8.6 bar(e) 200KW,6.6KV S	
			ZT275 10 bar(e) 275KW,3.3KV S					<b>Safety valve complete</b>	
6010	0830 1008 23	2	Safety valve		6010	0830 1008 23	2	Safety valve	
6020	0661 1000 32	2	Seal washer		6020	0661 1000 32	2	Seal washer	
6030	0830 1008 13	1	Safety valve		6030	0830 1008 08	1	Safety valve	
6040	0661 1000 32	1	Seal washer		6040	0661 1000 31	1	Washer	
6050	0605 8700 75	1	Bushing		6050	0605 8400 19	1	Bushing	
			ZT160 7.5 bar(e) 160KW,3.3KV S					ZT250 7.5 bar(e) 250KW,3.3KV S	
			ZT160 7.5 bar(e) 160KW,6.6KV S					ZT250 7.5 bar(e) 250KW,6.6KV S	
			ZT160 8.6 bar(e) 160KW,3.3KV S					ZT250 8.6 bar(e) 250KW,3.3KV S	
			ZT160 8.6 bar(e) 160KW,6.6KV S					ZT250 8.6 bar(e) 250KW,6.6KV S	
			ZT200 7.5 bar(e) 200KW,3.3KV S					<b>Safety valve complete</b>	
					6010	0830 1008 23	2	Safety valve	
					6020	0661 1000 32	2	Seal washer	
					6030	0830 1008 09	1	Safety valve	
					6040	0661 1000 32	1	Seal washer	
					6050	0605 8400 19	2	Bushing	

# 19




## Coolers - ZR

19

Ref.	Partnumber	Qty	Name	Remarks	Ref.	Partnumber	Qty	Name	Remarks
1010	1621 3289 00	1	Cover		3270	0663 2106 95	1	O-Ring	
1030	0663 2108 00	1	O-Ring		3280	1621 0528 00	2	Ring	
1040	0147 1363 03	2	Hex.bolt		3290	0101 1951 51	2	Pin	
1060	0663 2107 81	1	O-Ring		3300	0686 3716 04	5	Plug	
1070	9096 4104 00	2	Pin		3310	0661 1000 25	5	Seal washer	
1080	0147 1477 00	6	Hex.bolt		3320	0244 4184 00	4	Round head drive screw	
1100	0663 2108 94	2	O-Ring		3330	1621 1397 02	1	Water seperator	
1110	0147 1962 30	8	Hex.bolt		3340	1621 3330 02	1	Cover	
1120	9096 4165 00	1	Pipe		3350	0663 2107 25	1	O-Ring	
1130	0663 6147 00	1	O-Ring		3360	0147 1962 31	4	Hex.bolt	
1140	0686 3716 04	3	Plug		3361	0686 3716 04	2	Plug	
1150	0661 1000 25	3	Seal washer		3362	0661 1000 25	2	Seal washer	
1151	0244 4184 00	4	Round head drive screw		3370	1621 5361 00	1	Water seperator	
	<b>1621 4396 80</b>	<b>2</b>	<b>Cover for coolers</b>		3380	1621 3527 00	1	Gasket	
2010		• 1	Cover for cooler		3390	0147 1323 02	4	Hex head screw	
2020	1621 7941 00	• 1	Bushing		3400	0301 2135 01	1	Washer	
	0661 1000 27	• 1	Seal washer		3410	0663 2107 56	1	O-Ring	
	0661 1000 27	• 1	Seal washer		3420	0147 1962 33	8	Hex.bolt	
2030	1621 4418 00	• 1	Plate		3425	1079 9905 49	1	Lable	
2040	0147 1962 65	• 4	Hex.bolt		3440	1621 1435 02	1	Water separator	
2041	0147 1962 65	• 4	Hex.bolt		3450	1621 3556 00	1	Water separator	
3080	1621 7003 08	1	Cooler core		3460	0147 1960 58	4	Hex.bolt	
3090	0663 2107 53	1	O-Ring		3470	0301 2135 01	1	Washer	
3110	0663 2107 54	1	O-Ring		3480	0663 2106 95	1	O-Ring	
3120	0663 2107 55	1	O-Ring		3490	0147 1962 33	6	Hex.bolt	
3130	0147 1962 31	8	Hex.bolt		3491	0246 1955 39	2	Stud	
3140	1621 7002 08	1	Cooler core		3492	0261 1090 65	2	Hex.nut	
3150	0663 2107 48	1	O-Ring		<b>4010</b>	<b>1621 3151 10</b>	<b>1</b>	<b>Cooler shell</b>	
3170	0663 2107 51	1	O-Ring		4030	1621 3154 10	1	Cover i/c	
3180	0663 2107 52	1	O-Ring		4040	0147 1962 31	4	Hex.bolt	
3190	0147 1962 31	8	Hex.bolt		4050	1621 3155 10	1	Cover a/c	
3200	1621 4076 00	1	Seal ring		4070	1621 3071 00	3	Cover	
3210	0663 2107 57	1	O-Ring		4075	0663 2107 86	3	O-Ring	
3220	0663 2107 56	1	O-Ring		4080	0147 1962 29	6	Hex.bolt	
3230	1621 0528 00	2	Ring		4100	1621 3059 00	1	Cover	
3240	0101 1951 51	2	Pin		4105	0663 2107 25	1	O-Ring	
3250	1621 4077 00	1	Seal ring		4106	0147 1402 03	4	Hex. head screw	
3260	0663 2107 58	1	O-Ring						

# 20




## Coolers - ZT

20

Ref.	Partnumber	Qty	Name	Remarks	Ref.	Partnumber	Qty	Name	Remarks
1010	9096 4381 00	2	Pipe		2170	0301 2358 00	6	Plain washer	
1030	0663 2107 14	1	O-Ring		2190	0147 1360 03	4	Hex. head screw	
1040	1621 2777 00	2	Tie rod		2200	0301 2344 00	2	Plain washer	
1050	0266 2112 00	8	Hexagon nut		2210	1621 2780 00	1	Plate	
1060	0301 2358 00	4	Plain washer		2220	1088 0801 53	2	Gromet type a	
1070	0147 1360 03	8	Hex. head screw		2230	1619 5337 01	2	Paint stripping bolt	
1080	0301 2344 00	8	Plain washer		2240	1623 6191 00	2	Pipe	
2020	1621 2778 00	1	Support		2250	0634 1001 09	2	Pipe coupl. Victaulic	
2040	0147 1401 03	4	Hex bolt		3010	1621 2797 80	1	Coolers	
2050	1621 2795 00	1	Inter cooler		3030	0663 2106 95	2	O-Ring	
2060	0663 2108 26	1	O-Ring		3050	0147 1326 03	12	Hex.bolt	
2065	0147 1403 03	2	Hex.bolt		3060	0147 1325 03	8	Hex.bolt	
2071	0147 1402 03	1	Hex. head screw		3080	0663 2106 95	2	O-Ring	
2080	0301 2358 00	1	Plain washer		3100	0147 1326 03	16	Hex.bolt	
2090	0211 1964 75	1	Hex.cap screw		3110	0211 1325 03	8	Screw	
2100	1621 2796 00	1	After cooler		3130	0147 1320 03	4	Hex.bolt	
2110	0663 2108 26	1	O-Ring		4015	0686 3716 04	1	Plug	
2115	0147 1403 03	2	Hex.bolt		4016	0661 1000 25	1	Seal washer	
2121	0147 1402 03	1	Hex. head screw		4040	0663 2133 00	1	O-Ring	
2130	0301 2358 00	1	Plain washer		4045	0663 2133 00	1	O-Ring	
2140	0211 1964 75	1	Hex.cap screw		4050	0147 1363 03	4	Hex.bolt	
2150	1621 2779 00	1	Support		4070	0301 2344 00	2	Plain washer	
2160	0147 1402 03	6	Hex. head screw						


# 21



**Coolers - cooling system - ZT**
**21**

Ref.	Partnumber	Qty	Name	Remarks	Ref.	Partnumber	Qty	Name	Remarks
1010	1623 9863 08	2	Fan radial		1100	1621 2530 00	1	Strip	
1020	1503 0786 00	2	Rotation arrow		1110	1619 2766 00	2	Paint stripping bolt	
1030	1621 2447 00	2	Support		1120	0147 1249 00	2	Hex.bolt	
1040	0147 1400 03	8	Hex. head screw		1130	0266 2108 00	2	Hex.nut	
1050	0301 2358 00	8	Plain washer		1140	2000 0225 29	1	Cale box	
1060	0147 1400 03	8	Hex. head screw					<b>Kit-decal</b>	
1070	0301 2358 00	8	Plain washer		2005	1088 1001 02	1	Warning mark	
1080	1619 2766 00	2	Paint stripping bolt		2010	1088 1001 04	3	Warning mark	
1090	1619 2766 00	2	Paint stripping bolt		2015	1503 0786 00	2	Rotaion arrow	

# 22



## Oil system - ZR

22


Ref.	Partnumber	Qty	Name	Remarks	Ref.	Partnumber	Qty	Name	Remarks
1005	1616 5537 00	1	Level indicator		2005	1623 7121 00	1	Oil cooler	
	0663 2104 37	4	O-Ring		2010	0663 2107 81	4	O-Ring	
1030	0603 5115 03	1	Hex.nipple		2015	0147 1323 00	3	Hex.bolt	
1035	1619 6153 05	1	Ball valve		2020	0603 4102 00	1	Hex.nipple	
1040	0571 0020 17	1	Hose nipple		2025	8202 0310 04	1	Ball valve	
1045	0347 6105 00	1	Hose clamp		2030	0686 3716 04	4	Plug	
1050	0075 4005 51	AR	Hose		2035	0661 1000 25	4	Seal washer	
1055	1613 2685 00	1	Hose support					<b>Oil system complete</b>	
1060	0147 1323 00	1	Hex.bolt		3005	1614 8747 00	1	Oil filter	
1095	1621 3116 00	1	Pipe		3010	1621 4024 00	1	Nipple	
1100	0581 2024 34	1	Male coupling		4005	1616 5439 00	1	Distance ring	
1105	0580 2501 42	1	Elbow coupling		4010	1621 5783 00	2	Eccentric ring	
1110	0661 1000 29	1	Washer		4015	1616 6127 00	2	Pump element	
1135	1621 0383 00	1	Valve		4020	0101 1951 36	1	Pin	
1140	1621 7254 00	1	Spring		4025	0102 0244 00	1	Pin	
1145	0335 2120 00	1	Circlip		4030	1616 6461 00	1	Pump cover	
1150	1621 0137 00	1	Plug		4035	0663 2106 16	1	O-Ring	
1155	0661 1000 29	1	Washer		4040	0147 1327 03	3	Hex.bolt	



## Oil system - ZT

Ref.	Partnumber	Qty	Name	Remarks	Ref.	Partnumber	Qty	Name	Remarks
1005	1616 5537 00	1	Level indicator		1356	0147 1363 03	4	Hex.bolt	
	0663 2104 37	4	O-Ring		1385	1621 9553 00	1	Pipe	
1030	0603 5115 03	1	Hex.nipple		1386	0686 3716 44	1	Hexagon plug	
1035	1619 6153 05	1	Ball valve		1387	0661 1000 25	1	Seal washer	
1040	0571 0020 17	1	Hose nipple		1390	0663 2107 86	1	O-Ring	
1045	0347 6105 00	1	Hose clamp		1395	0147 1962 30	2	Hex.bolt	
1050	0075 4005 51	AR	Hose		1400	0147 1412 00	2	Hex.bolt	
1055	1613 2685 00	1	Hose support		1405	0663 2107 81	1	O-Ring	
1060	0147 1323 00	1	Hex.bolt		1431	1621 9554 00	1	Pipe	
1095	1621 3116 00	1	Pipe		1432	0686 3716 44	1	Hexagon plug	
1100	0581 2024 34	1	Male coupling		1433	0661 1000 25	1	Seal washer	
1105	0580 2501 42	1	Elbow coupling		1435	0663 2107 86	2	O-Ring	
1110	0661 1000 29	1	Washer		1440	0147 1412 00	2	Hex.bolt	
1135	1621 0383 00	1	Valve		1442	0147 1413 00	2	Hex.bolt	
1140	1621 7254 00	1	Spring		1486	1621 4150 00	1	Pipe	
1145	0335 2120 00	1	Circlip		1490	0663 2107 90	1	O-Ring	
1150	1621 0137 00	1	Plug		1495	0147 1363 03	2	Hex.bolt	
1155	0661 1000 29	1	Washer		1505	0663 2107 86	1	O-Ring	
1195	1621 3219 00	3	Drain plug		1510	0147 1413 00	2	Hex.bolt	
1260	1621 3783 00	1	Housing		1515	9096 4489 00	1	Pipe	
1265	0663 2107 81	3	O-Ring		1520	9096 4488 00	1	Pipe	
1270	0147 1326 03	3	Hex.bolt					<b>Oil system complete</b>	
1275	2255 0831 00	1	Valve		2005	1614 8747 00	1	Oil filter	
1280	1621 2960 00	1	Spring		2010	1621 4024 00	1	Nipple	
1285	0661 1000 30	1	Seal washer		3005	1616 5439 00	1	Distance ring	
1290	2255 0833 03	1	Plug		3010	1621 5783 00	2	Eccentric ring	
1300	0653 1100 00	3	Copper washer		3015	1616 6127 00	2	Pump element	
1305	0663 3125 00	3	O-Ring		3020	0101 1951 36	1	Pin	
1310	0661 1000 31	2	Washer		3025	0102 0244 00	1	Pin	
1315	9096 4491 00	2	Nipple		3030	1616 6461 00	1	Pump cover	
1320	9096 4490 00	2	Flexible pipe		3035	0663 2106 16	1	O-Ring	
1351	0663 2107 90	2	O-Ring		3040	0147 1327 03	3	Hex.bolt	


# 24



## Drive arrangement

Ref.	Partnumber	Qty	Name	Remarks	Ref.	Partnumber	Qty	Name	Remarks
			ZR160 7.5 bar(e) 190KW/ 3.3KVO		3095	9096 3690 07	1	Coupling	
			ZR160 8.6 bar(e) 190KW/ 3.3KVO		3100	9096 4948 00	1	Motor support	
			<b>Drive arrg.complete with 190kw</b>		3110	0147 1413 00	2	Hex.bolt	
1005	1621 1428 00	1	Coupling housing		3115	0147 1480 00	2	Hex.bolt	
1010	0147 1405 03	8	Hex.bolt		3120	0147 1480 00	1	Hex.bolt	
1040	1621 1534 02	1	Coupling half		3125	0261 1090 51	2	Hex.nut	
1045	1619 6467 04	1	Set-rubbers		3130	0266 2114 00	2	Hexagon nut	
1050	1621 1535 01	1	Coupling half		3135	0301 2378 00	2	Plain washer	
1060	0147 1554 00	8	Hex.bolt		3140	0301 2378 00	1	Plain washer	
1062	0147 1554 00	2	Hex.bolt		3145	0301 2393 00	2	Plain washer	
1085	9096 4731 13	1	Reducing ring		3150	0301 2358 00	2	Plain washer	
2000	9096 4997 00	1	Motor		3155	0333 2149 00	2	Spring washer	
2106	1621 1673 00	2	Guard					ZR160 10 bar(e) 165KW/ 3.3KVO	
3010	9096 4671 00	2	Anti vibration mount					<b>Drive arrg.complete with 165kw</b>	
3020	0147 1962 35	2	Hex.bolt	1005	1621 1428 00	1	Coupling housing		
3030	0147 1400 00	4	Hex.bolt	1010	0147 1405 03	8	Hex.bolt		
3040	0301 2358 00	4	Plain washer	1040	1621 1534 02	1	Coupling half		
3060	1621 3148 00	1	Support	1045	1619 6467 04	1	Set-rubbers		
3065	0147 1401 00	4	Hex.bolt	1050	1621 1535 01	1	Coupling half		
3066	0300 0274 92	4	Washer	1060	0147 1554 00	8	Hex.bolt		
3070	9096 3915 00	2	Rubber buffer	1062	0147 1554 00	2	Hex.bolt		
3080	0147 1400 00	4	Hex.bolt	1085	9096 4731 13	1	Reducing ring		
3090	0301 2358 00	4	Plain washer	2000	9096 4995 00	1	Motor		
3095	9096 3690 07	1	Coupling - Motor.	2106	1621 1673 00	2	Guard		
3100	9096 4948 00	1	Motor support	3010	9096 4671 00	2	Anti vibration mount		
3110	0147 1413 00	2	Hex.bolt	3020	0147 1962 35	2	Hex.bolt		
3115	0147 1480 00	2	Hex.bolt	3030	0147 1400 00	4	Hex.bolt		
3120	0147 1480 00	1	Hex.bolt	3040	0301 2358 00	4	Plain washer		
3125	0261 1090 51	2	Hex.nut	3060	1621 3148 00	1	Support		
3130	0266 2114 00	2	Hexagon nut	3065	0147 1401 00	4	Hex.bolt		
3135	0301 2378 00	2	Plain washer	3066	0300 0274 92	4	Washer		
3140	0301 2378 00	1	Plain washer	3070	9096 3915 00	2	Rubber buffer		
3145	0301 2393 00	2	Plain washer	3080	0147 1400 00	4	Hex.bolt		
3150	0301 2358 00	2	Plain washer	3090	0301 2358 00	4	Plain washer		
3155	0333 2149 00	2	Spring washer	3095	9096 3690 07	1	Coupling - Motor		
			ZR160 8.6 bar(e) 175KW/ 3.3KVO		3100	9096 4948 00	1	Motor support	
			ZR160 10 bar(e) 175KW/ 3.3KVO		3110	0147 1413 00	2	Hex.bolt	
			<b>Drive arrg.complete with 175kw</b>		3115	0147 1480 00	2	Hex.bolt	
1005	1621 1428 00	1	Coupling housing		3120	0147 1480 00	1	Hex.bolt	
1010	0147 1405 03	8	Hex.bolt		3125	0261 1090 51	2	Hex.nut	
1040	1621 1534 02	1	Coupling half		3130	0266 2114 00	2	Hexagon nut	
1045	1619 6467 04	1	Set-rubbers		3135	0301 2378 00	2	Plain washer	
1050	1621 1535 01	1	Coupling half		3140	0301 2378 00	1	Plain washer	
1060	0147 1554 00	8	Hex.bolt		3145	0301 2393 00	2	Plain washer	
1062	0147 1554 00	2	Hex.bolt		3150	0301 2358 00	2	Plain washer	
1085	9096 4731 13	1	Reducing ring		3155	0333 2149 00	2	Spring washer	
2000	9096 4996 00	1	Motor					ZR200 7.5 bar(e) 240KW/ 3.3KVO	
2106	1621 1673 00	2	Guard					ZR200 8.6 bar(e) 240KW/ 3.3KVO	
3010	9096 4671 00	2	Anti vibration mount					<b>Drive arrg.complete with 240kw</b>	
3020	0147 1962 35	2	Hex.bolt	1005	1621 1428 00	1	Coupling housing		
3030	0147 1400 00	4	Hex.bolt	1010	0147 1405 03	8	Hex.bolt		
3040	0301 2358 00	4	Plain washer	1040	1621 1534 02	1	Coupling half		
3060	1621 3148 00	1	Support	1045	1619 6467 04	1	Set-rubbers		
3065	0147 1401 00	4	Hex.bolt	1050	1621 1535 01	1	Coupling half		
3066	0300 0274 92	4	Washer	1060	0147 1554 00	8	Hex.bolt		
3070	9096 3915 00	2	Rubber buffer	1062	0147 1554 00	2	Hex.bolt		
3080	0147 1400 00	4	Hex.bolt	1085	9096 4731 13	1	Reducing ring		
3090	0301 2358 00	4	Plain washer	2000	9096 5000 00	1	Motor		
				2106	1621 1673 00	2	Guard		


# 24



## Drive arrangement

Ref.	Partnumber	Qty	Name	Remarks	Ref.	Partnumber	Qty	Name	Remarks
3010	9096 4671 00	2	Anti vibration mount					<b>Drive arrg.complete with 200kw</b>	
3020	0147 1962 35	2	Hex.bolt		1005	1621 1428 00	1	Coupling housing	
3030	0147 1400 00	4	Hex.bolt		1010	0147 1405 03	8	Hex.bolt	
3040	0301 2358 00	4	Plain washer		1040	1621 1534 02	1	Coupling half	
3060	1621 3148 00	1	Support		1045	1619 6467 04	1	Set-rubbers	
3065	0147 1401 00	4	Hex.bolt		1050	1621 1535 01	1	Coupling half	
3066	0300 0274 92	4	Washer		1060	0147 1554 00	8	Hex.bolt	
3070	9096 3915 00	2	Rubber buffer		1062	0147 1554 00	2	Hex.bolt	
3080	0147 1400 00	4	Hex.bolt		1085	9096 4731 13	1	Reducing ring	
3090	0301 2358 00	4	Plain washer		2000	9096 4998 00	1	Motor	
3095	9096 3690 07	1	Coupling - Motor.		2106	1621 1673 00	2	Guard	
3100	9096 4948 00	1	Motor support		3010	9096 4671 00	2	Anti vibration mount	
3110	0147 1413 00	2	Hex.bolt		3020	0147 1962 35	2	Hex.bolt	
3115	0147 1480 00	2	Hex.bolt		3030	0147 1400 00	4	Hex.bolt	
3120	0147 1480 00	1	Hex.bolt		3040	0301 2358 00	4	Plain washer	
3125	0261 1090 51	2	Hex.nut		3060	1621 3148 00	1	Support	
3130	0266 2114 00	2	Hexagon nut		3065	0147 1401 00	4	Hex.bolt	
3135	0301 2378 00	2	Plain washer		3066	0300 0274 92	4	Washer	
3140	0301 2378 00	1	Plain washer		3070	9096 3915 00	2	Rubber buffer	
3145	0301 2393 00	2	Plain washer		3080	0147 1400 00	4	Hex.bolt	
3150	0301 2358 00	2	Plain washer		3090	0301 2358 00	4	Plain washer	
3155	0333 2149 00	2	Spring washer		3095	9096 3690 07	1	Coupling - Motor.	
			ZR200 8.6 bar(e) 220KW/ 3.3KVO		3100	9096 4948 00	1	Motor support	
			ZR200 10 bar(e) 220KW/ 3.3KVO		3110	0147 1413 00	2	Hex.bolt	
			<b>Drive arrg.complete with 220kw</b>		3115	0147 1480 00	2	Hex.bolt	
1005	1621 1428 00	1	Coupling housing		3120	0147 1480 00	1	Hex.bolt	
1010	0147 1405 03	8	Hex.bolt		3125	0261 1090 51	2	Hex.nut	
1040	1621 1534 02	1	Coupling half		3130	0266 2114 00	2	Hexagon nut	
1045	1619 6467 04	1	Set-rubbers		3135	0301 2378 00	2	Plain washer	
1050	1621 1535 01	1	Coupling half		3140	0301 2378 00	1	Plain washer	
1060	0147 1554 00	8	Hex.bolt		3145	0301 2393 00	2	Plain washer	
1062	0147 1554 00	2	Hex.bolt		3150	0301 2358 00	2	Plain washer	
1085	9096 4731 13	1	Reducing ring		3155	0333 2149 00	2	Spring washer	
2000	9096 4998 00	1	Motor					ZR250 7.5 bar(e) 300KW/ 3.3KVO	
2106	1621 1673 00	2	Guard					ZR250 8.6 bar(e) 300KW/ 3.3KVO	
3010	9096 4671 00	2	Anti vibration mount					<b>Drive arrg.complete with 300kw</b>	
3020	0147 1962 35	2	Hex.bolt		1005	1621 3729 00	1	Coupling housing	
3030	0147 1400 00	4	Hex.bolt		1010	0147 1405 03	8	Hex.bolt	
3040	0301 2358 00	4	Plain washer		1040	1621 1534 02	1	Coupling half	
3060	1621 3148 00	1	Support		1045	1619 6467 04	1	Set-rubbers	
3065	0147 1401 00	4	Hex.bolt		1050	1621 1535 01	1	Coupling half	
3066	0300 0274 92	4	Washer		1060	0147 1554 00	8	Hex.bolt	
3070	9096 3915 00	2	Rubber buffer		1061	0147 1632 03	2	Bolt	
3080	0147 1400 00	4	Hex.bolt		2000	9096 5003 00	1	Motor	
3090	0301 2358 00	4	Plain washer		2106	1621 1673 00	2	Guard	
3095	9096 3690 07	1	Coupling - Motor.		3010	9096 3915 00	2	Rubber buffer	
3100	9096 4948 00	1	Motor support		3020	0147 1962 35	2	Hex.bolt	
3110	0147 1413 00	2	Hex.bolt		3030	0147 1400 00	4	Hex.bolt	
3115	0147 1480 00	2	Hex.bolt		3040	0301 2358 00	4	Plain washer	
3120	0147 1480 00	1	Hex.bolt		3041	0147 1552 03	8	Bolt	
3125	0261 1090 51	2	Hex.nut		3060	1621 3148 00	1	Support	
3130	0266 2114 00	2	Hexagon nut		3065	0147 1401 00	4	Hex.bolt	
3135	0301 2378 00	2	Plain washer		3066	0300 0274 92	4	Washer	
3140	0301 2378 00	1	Plain washer		3070	9096 3915 00	2	Rubber buffer	
3145	0301 2393 00	2	Plain washer		3080	0147 1398 00	4	Hex.bolt	
3150	0301 2358 00	2	Plain washer		3090	0301 2358 00	4	Plain washer	
3155	0333 2149 00	2	Spring washer		3095	9096 3690 02	1	Coupling half	
			ZR200 10 bar(e) 200KW/ 3.3KVO		3100	9096 4947 00	1	Motor support	
			ZR160 7.5 bar(e) 200KW/ 3.3KVO		3110	0147 1413 00	2	Hex.bolt	
					3115	0147 1962 35	2	Hex.bolt	

# 24



## Drive arrangement


Ref.	Partnumber	Qty	Name	Remarks	Ref.	Partnumber	Qty	Name	Remarks
3120	0147 1480 00	1	Hex.bolt		3040	0147 1400 00	4	Hex.bolt	
3125	1903 2058 13	2	Hex nut		3041	0301 2358 00	4	Plain washer	
3130	0266 2114 00	2	Hexagon nut		3060	1621 3148 00	1	Support	
3135	0300 0274 53	2	Plain washer		3065	0147 1401 00	4	Hex.bolt	
3140	0301 2378 00	1	Plain washer		3066	0300 0274 92	4	Washer	
3145	0301 2408 00	2	Washer		3070	9096 3915 00	2	Rubber buffer	
3150	0301 2358 00	2	Plain washer		3080	0147 1400 00	4	Hex.bolt	
3155	0333 2153 00	2	Spring washer		3090	0301 2358 00	4	Plain washer	
			ZR250 8.6 bar(e) 280KW/ 3.3KVO		3095	9096 3690 07	1	Coupling - Motor.	
			ZR250 10 bar(e) 280KW/ 3.3KVO		3100	9096 4948 00	1	Motor support	
			<b>Drive arrg.complete with 280kw</b>		3110	0147 1413 00	2	Hex.bolt	
1005	1621 3729 00	1	Coupling housing		3115	0147 1480 00	2	Hex.bolt	
1010	0147 1405 03	8	Hex.bolt		3120	0147 1480 00	1	Hex.bolt	
1040	1621 1534 02	1	Coupling half		3125	0261 1090 51	2	Hex.nut	
1045	1619 6467 04	1	Set-rubbers		3130	0301 2378 00	2	Plain washer	
1050	1621 1535 01	1	Coupling half		3135	0266 2114 00	2	Hexagon nut	
1060	0147 1554 00	8	Hex.bolt		3140	0301 2378 00	1	Plain washer	
1061	0147 1632 03	2	Bolt		3145	0333 2149 00	2	Spring washer	
2000	9096 5002 00	1	Motor		3150	0301 2358 00	2	Plain washer	
2106	1621 1673 00	2	Guard		3155	0301 2393 00	2	Plain washer	
3010	9096 3915 00	2	Rubber buffer					ZR275 7.5 bar(e) 320KW/ 3.3KVO	
3020	0147 1962 35	2	Hex.bolt					<b>Drive arrg.complete with 320kw</b>	
3030	0147 1400 00	4	Hex.bolt		1005	1621 3729 00	1	Coupling housing	
3040	0301 2358 00	4	Plain washer		1010	0147 1405 03	8	Hex.bolt	
3041	0147 1552 03	8	Bolt		1040	1621 1534 02	1	Coupling half	
3060	1621 3148 00	1	Support		1045	1619 6467 04	1	Set-rubbers	
3065	0147 1401 00	4	Hex.bolt		1050	1621 1535 01	1	Coupling half	
3066	0300 0274 92	4	Washer		1060	0147 1554 00	8	Hex.bolt	
3070	9096 3915 00	2	Rubber buffer		1061	0147 1632 03	2	Bolt	
3080	0147 1398 00	4	Hex.bolt		2000	9096 5004 00	1	Motor	
3090	0301 2358 00	4	Plain washer		2106	1621 1673 00	2	Guard	
3095	9096 3690 02	1	Coupling half		3010	9096 3915 00	2	Rubber buffer	
3100	9096 4947 00	1	Motor support		3020	0147 1962 35	2	Hex.bolt	
3110	0147 1413 00	2	Hex.bolt		3030	0147 1400 00	4	Hex.bolt	
3115	0147 1962 35	2	Hex.bolt		3040	0301 2358 00	4	Plain washer	
3120	0147 1480 00	1	Hex.bolt		3041	0147 1552 03	8	Bolt	
3125	1903 2058 13	2	Hex nut		3060	1621 3148 00	1	Support	
3130	0266 2114 00	2	Hexagon nut		3065	0147 1401 00	4	Hex.bolt	
3135	0300 0274 53	2	Plain washer		3066	0300 0274 92	4	Washer	
3140	0301 2378 00	1	Plain washer		3070	9096 3915 00	2	Rubber buffer	
3145	0301 2408 00	2	Washer		3080	0147 1398 00	4	Hex.bolt	
3150	0301 2358 00	2	Plain washer		3090	0301 2358 00	4	Plain washer	
3155	0333 2153 00	2	Spring washer		3095	9096 3690 07	1	Coupling - Motor.	
			ZR250 10 bar(e) 255KW/ 3.3KVO		3100	9096 4947 00	1	Motor support	
			ZR200 7.5 bar(e) 255KW/ 3.3KVO		3110	0147 1413 00	2	Hex.bolt	
			<b>Drive arrg.complete with 255kw</b>		3115	0147 1962 35	2	Hex.bolt	
1005	1621 1428 00	1	Coupling housing		3120	0147 1480 00	1	Hex.bolt	
1010	0147 1405 03	8	Hex.bolt		3125	1903 2058 13	2	Hex nut	
1040	1621 1534 02	1	Coupling half		3130	0266 2114 00	2	Hexagon nut	
1050	1621 1535 01	1	Coupling half		3135	0300 0274 53	2	Plain washer	
1060	0147 1554 00	8	Hex.bolt		3140	0301 2378 00	1	Plain washer	
1062	0147 1554 00	2	Hex.bolt		3145	0301 2408 00	2	Washer	
1085	9096 4731 13	1	Reducing ring		3150	0301 2358 00	2	Plain washer	
2000	9096 5001 00	1	Motor		3155	0333 2153 00	2	Spring washer	
2106	1621 1673 00	2	Guard		3160	9096 4955 00	1	Motor baffle	
3010	1619 6467 04	1	Set-rubbers					ZR275 7.5 bar(e) 345KW/ 3.3KVO	
3020	9096 4671 00	2	Anti vibration mount					<b>Drive arrg.complete with 345kw</b>	
3030	0147 1962 35	2	Hex.bolt		1005	1621 3729 00	1	Coupling housing	
					1010	0147 1405 03	8	Hex.bolt	
					1040	1621 1534 02	1	Coupling half	



## Drive arrangement

Ref.	Part number	Qty	Name	Remarks	Ref.	Part number	Qty	Name	Remarks
1045	1619 6467 04	1	Set-rubbers		3135	0300 0274 53	2	Plain washer	
1050	1621 1535 01	1	Coupling half		3140	0301 2378 00	1	Plain washer	
1060	0147 1554 00	8	Hex.bolt		3145	0301 2408 00	2	Washer	
1061	0147 1632 03	2	Bolt		3150	0301 2358 00	2	Plain washer	
1085	9096 4731 14	1	Reducer ring		3155	0333 2153 00	2	Spring washer	
2000	9096 5005 00	1	Motor					ZR160 10 bar(e) 175KW/ 6.6KVO	
2106	1621 1673 00	2	Guard					ZR160 8.6 bar(e) 175KW/ 6.6KVO	
3010	9096 3915 00	2	Rubber buffer					<b>Drive arrg.complete with 175kw</b>	
3020	0147 1962 35	2	Hex.bolt		1005	1621 3729 00	1	Coupling housing	
3030	0147 1400 00	4	Hex.bolt		1010	0147 1405 03	8	Hex.bolt	
3040	0301 2358 00	4	Plain washer		1040	1621 1534 02	1	Coupling half	
3041	0147 1552 03	8	Bolt		1045	1619 6467 04	1	Set-rubbers	
3060	1621 3148 00	1	Support		1050	1621 1535 01	1	Coupling half	
3065	0147 1401 00	4	Hex.bolt		1060	0147 1554 00	8	Hex.bolt	
3066	0300 0274 92	4	Washer		1061	0147 1632 03	2	Bolt	
3070	9096 3915 00	2	Rubber buffer		2000	9096 5007 00	1	Motor	
3080	0147 1398 00	4	Hex.bolt		2106	1621 1673 00	2	Guard	
3090	0301 2358 00	4	Plain washer		3010	9096 3915 00	2	Rubber buffer	
3095	9096 3690 10	1	Coupling		3020	0147 1962 35	2	Hex.bolt	
3100	9096 4947 00	1	Motor support		3030	0147 1400 00	4	Hex.bolt	
3110	0147 1413 00	2	Hex.bolt		3040	0301 2358 00	4	Plain washer	
3115	0147 1962 35	2	Hex.bolt		3041	0147 1552 03	8	Bolt	
3120	0147 1480 00	1	Hex.bolt		3060	1621 3148 00	1	Support	
3125	1903 2058 13	2	Hex nut		3065	0147 1401 00	4	Hex.bolt	
3130	0266 2114 00	2	Hexagon nut		3066	0300 0274 92	4	Washer	
3135	0300 0274 53	2	Plain washer		3070	9096 3915 00	2	Rubber buffer	
3140	0301 2378 00	1	Plain washer		3080	0147 1398 00	4	Hex.bolt	
3145	0301 2408 00	2	Washer		3090	0301 2358 00	4	Plain washer	
3150	0301 2358 00	2	Plain washer		3095	9096 3690 03	1	Coupling half	
3155	0333 2153 00	2	Spring washer		3100	9096 4946 00	1	Motor support	
3160	9096 4955 60	1	Motor baffle		3110	0147 1413 00	2	Hex.bolt	
			ZR160 7.5 bar(e) 190KW/ 6.6KVO		3115	0147 1962 35	2	Hex.bolt	
			ZR160 8.6 bar(e) 190KW/ 6.6KVO		3120	0147 1480 00	1	Hex.bolt	
			<b>Drive arrg.complete with 190kw</b>		3125	1903 2058 13	2	Hex nut	
1005	1621 3729 00	1	Coupling housing		3130	0266 2114 00	2	Hexagon nut	
1010	0147 1405 03	8	Hex.bolt		3135	0300 0274 53	2	Plain washer	
1040	1621 1534 02	1	Coupling half		3140	0301 2378 00	1	Plain washer	
1045	1619 6467 04	1	Set-rubbers		3145	0301 2408 00	2	Washer	
1050	1621 1535 01	1	Coupling half		3150	0301 2358 00	2	Plain washer	
1060	0147 1554 00	8	Hex.bolt		3155	0333 2153 00	2	Spring washer	
1061	0147 1632 03	2	Bolt					ZR160 10 bar(e) 165KW/ 6.6KVO	
2000	9096 5008 00	1	Motor					<b>Drive arrg.complete with 165kw</b>	
2106	1621 1673 00	2	Guard		1005	1621 3729 00	1	Coupling housing	
3010	9096 3915 00	2	Rubber buffer		1010	0147 1405 03	8	Hex.bolt	
3020	0147 1962 35	2	Hex.bolt		1040	1621 1534 02	1	Coupling half	
3030	0147 1400 00	4	Hex.bolt		1045	1619 6467 04	1	Set-rubbers	
3040	0301 2358 00	4	Plain washer		1050	1621 1535 01	1	Coupling half	
3041	0147 1552 03	8	Bolt		1060	0147 1554 00	8	Hex.bolt	
3060	1621 3148 00	1	Support		1061	0147 1632 03	2	Bolt	
3065	0147 1401 00	4	Hex.bolt		2000	9096 5006 00	1	Motor	
3066	0300 0274 92	4	Washer		2106	1621 1673 00	2	Guard	
3070	9096 3915 00	2	Rubber buffer		3010	9096 3915 00	2	Rubber buffer	
3080	0147 1398 00	4	Hex.bolt		3020	0147 1962 35	2	Hex.bolt	
3090	0301 2358 00	4	Plain washer		3030	0147 1400 00	4	Hex.bolt	
3095	9096 3690 03	1	Coupling half		3040	0301 2358 00	4	Plain washer	
3100	9096 4946 00	1	Motor support		3041	0147 1552 03	8	Bolt	
3110	0147 1413 00	2	Hex.bolt		3060	1621 3148 00	1	Support	
3115	0147 1962 35	2	Hex.bolt		3065	0147 1401 00	4	Hex.bolt	
3120	0147 1480 00	1	Hex.bolt		3066	0300 0274 92	4	Washer	
3125	1903 2058 13	2	Hex nut						
3130	0266 2114 00	2	Hexagon nut						

# 24



## Drive arrangement


Ref.	Partnumber	Qty	Name	Remarks	Ref.	Partnumber	Qty	Name	Remarks
3070	9096 3915 00	2	Rubber buffer		1060	0147 1554 00	8	Hex.bolt	
3080	0147 1398 00	4	Hex.bolt		1061	0147 1632 03	2	Bolt	
3090	0301 2358 00	4	Plain washer		2000	9096 5010 00	1	Motor	
3095	9096 3690 03	1	Coupling half		2106	1621 1673 00	2	Guard	
3100	9096 4946 00	1	Motor support		3010	9096 3915 00	2	Rubber buffer	
3110	0147 1413 00	2	Hex.bolt		3020	0147 1962 35	2	Hex.bolt	
3115	0147 1962 35	2	Hex.bolt		3030	0147 1400 00	4	Hex.bolt	
3120	0147 1480 00	1	Hex.bolt		3040	0301 2358 00	4	Plain washer	
3125	1903 2058 13	2	Hex nut		3041	0147 1552 03	8	Bolt	
3130	0266 2114 00	2	Hexagon nut		3060	1621 3148 00	1	Support	
3135	0300 0274 53	2	Plain washer		3065	0147 1401 00	4	Hex.bolt	
3140	0301 2378 00	1	Plain washer		3066	0300 0274 92	4	Washer	
3145	0301 2408 00	2	Washer		3070	9096 3915 00	2	Rubber buffer	
3150	0301 2358 00	2	Plain washer		3080	0147 1398 00	4	Hex.bolt	
3155	0333 2153 00	2	Spring washer		3090	0301 2358 00	4	Plain washer	
			ZR200 7.5 bar(e) 240KW/ 6.6KVO		3095	9096 3690 03	1	Coupling half	
			ZR200 8.6 bar(e) 240KW/ 6.6KVO		3100	9096 4946 00	1	Motor support	
			<b>Drive arrg.complete with 240kw</b>		3110	0147 1413 00	2	Hex.bolt	
1005	1621 3729 00	1	Coupling housing		3115	0147 1962 35	2	Hex.bolt	
1010	0147 1405 03	8	Hex.bolt		3120	0147 1480 00	1	Hex.bolt	
1040	1621 1534 02	1	Coupling half		3125	1903 2058 13	2	Hex nut	
1045	1619 6467 04	1	Set-rubbers		3130	0266 2114 00	2	Hexagon nut	
1050	1621 1535 01	1	Coupling half		3135	0300 0274 53	2	Plain washer	
1060	0147 1554 00	8	Hex.bolt		3140	0301 2378 00	1	Plain washer	
1061	0147 1632 03	2	Bolt		3145	0301 2408 00	2	Washer	
2000	9096 5011 00	1	Motor		3150	0301 2358 00	2	Plain washer	
2106	1621 1673 00	2	Guard		3155	0333 2153 00	2	Spring washer	
3010	9096 3915 00	2	Rubber buffer					ZR200 10 bar(e) 200KW/ 6.6KVO	
3020	0147 1962 35	2	Hex.bolt					ZR160 7.5 bar(e) 200KW/ 6.6KVO	
3030	0147 1400 00	4	Hex.bolt					<b>Drive arrg.complete with 200kw</b>	
3040	0301 2358 00	4	Plain washer		1005	1621 3729 00	1	Coupling housing	
3041	0147 1552 03	8	Bolt		1010	0147 1405 03	8	Hex.bolt	
3060	1621 3148 00	1	Support		1040	1621 1534 02	1	Coupling half	
3065	0147 1401 00	4	Hex.bolt		1045	1619 6467 04	1	Set-rubbers	
3066	0300 0274 92	4	Washer		1050	1621 1535 01	1	Coupling half	
3070	9096 3915 00	2	Rubber buffer		1060	0147 1554 00	8	Hex.bolt	
3080	0147 1398 00	4	Hex.bolt		1061	0147 1632 03	2	Bolt	
3090	0301 2358 00	4	Plain washer		2000	9096 5009 00	1	Motor	
3095	9096 3690 03	1	Coupling half		2106	1621 1673 00	2	Guard	
3100	9096 4946 00	1	Motor support		3010	9096 3915 00	2	Rubber buffer	
3110	0147 1413 00	2	Hex.bolt		3020	0147 1962 35	2	Hex.bolt	
3115	0147 1962 35	2	Hex.bolt		3030	0147 1400 00	4	Hex.bolt	
3120	0147 1480 00	1	Hex.bolt		3040	0301 2358 00	4	Plain washer	
3125	1903 2058 13	2	Hex nut		3041	0147 1552 03	8	Bolt	
3130	0266 2114 00	2	Hexagon nut		3060	1621 3148 00	1	Support	
3135	0300 0274 53	2	Plain washer		3065	0147 1401 00	4	Hex.bolt	
3140	0301 2378 00	1	Plain washer		3066	0300 0274 92	4	Washer	
3145	0301 2408 00	2	Washer		3070	9096 3915 00	2	Rubber buffer	
3150	0301 2358 00	2	Plain washer		3080	0147 1398 00	4	Hex.bolt	
3155	0333 2153 00	2	Spring washer		3090	0301 2358 00	4	Plain washer	
			ZR200 8.6 bar(e) 220KW/ 6.6KVO		3095	9096 3690 03	1	Coupling half	
			ZR200 10 bar(e) 220KW/ 6.6KVO		3100	9096 4946 00	1	Motor support	
			<b>Drive arrg.complete with 220kw</b>		3110	0147 1413 00	2	Hex.bolt	
1005	1621 3729 00	1	Coupling housing		3115	0147 1962 35	2	Hex.bolt	
1010	0147 1405 03	8	Hex.bolt		3120	0147 1480 00	1	Hex.bolt	
1040	1621 1534 02	1	Coupling half		3125	1903 2058 13	2	Hex nut	
1045	1619 6467 04	1	Set-rubbers		3130	0266 2114 00	2	Hexagon nut	
1050	1621 1535 01	1	Coupling half		3135	0300 0274 53	2	Plain washer	
					3140	0301 2378 00	1	Plain washer	
					3145	0301 2408 00	2	Washer	
					3150	0301 2358 00	2	Plain washer	



## Drive arrangement

Ref.	Partnumber	Qty	Name	Remarks	Ref.	Partnumber	Qty	Name	Remarks
3155	0333 2153 00	2	Spring washer ZR250 7.5 bar(e) 300KW/ 6.6KVO ZR250 8.6 bar(e) 300KW/ 6.6KVO <b>Drive arrg.complete with 300kw</b>		3090	0301 2358 00	4	Plain washer	
1005	1621 3729 00	1	Coupling housing		3095	9096 3690 02	1	Coupling half	
1010	0147 1405 03	8	Hex.bolt		3100	9096 4947 00	1	Motor support	
1040	1621 1534 02	1	Coupling half		3110	0147 1413 00	2	Hex.bolt	
1045	1619 6467 04	1	Set-rubbers		3115	0147 1962 35	2	Hex.bolt	
1050	1621 1535 01	1	Coupling half		3120	0147 1480 00	1	Hex.bolt	
1060	0147 1554 00	8	Hex.bolt		3125	1903 2058 13	2	Hex nut	
1061	0147 1632 03	2	Bolt		3130	0266 2114 00	2	Hexagon nut	
2000	9096 5014 00	1	Motor		3135	0300 0274 53	2	Plain washer	
2106	1621 1673 00	2	Guard		3140	0301 2378 00	1	Plain washer	
3010	9096 3915 00	2	Rubber buffer		3145	0301 2408 00	2	Washer	
3020	0147 1962 35	2	Hex.bolt		3150	0301 2358 00	2	Plain washer	
3030	0147 1400 00	4	Hex.bolt		3155	0333 2153 00	2	Spring washer ZR250 10 bar(e) 255KW/ 6.6KVO ZR200 7.5 bar(e) 255KW/ 6.6KVO <b>Drive arrg.complete with 255kw</b>	
3040	0301 2358 00	4	Plain washer		1005	1621 3729 00	1	Coupling housing	
3041	0147 1552 03	8	Bolt		1010	0147 1405 03	8	Hex.bolt	
3060	1621 3148 00	1	Support		1040	1621 1534 02	1	Coupling half	
3065	0147 1401 00	4	Hex.bolt		1045	1619 6467 04	1	Set-rubbers	
3066	0300 0274 92	4	Washer		1050	1621 1535 01	1	Coupling half	
3070	9096 3915 00	2	Rubber buffer		1060	0147 1554 00	8	Hex.bolt	
3080	0147 1398 00	4	Hex.bolt		1061	0147 1632 03	2	Bolt	
3090	0301 2358 00	4	Plain washer		2000	9096 5012 00	1	Motor	
3095	9096 3690 02	1	Coupling half		2106	1621 1673 00	2	Guard	
3100	9096 4947 00	1	Motor support		3010	9096 3915 00	2	Rubber buffer	
3110	0147 1413 00	2	Hex.bolt		3020	0147 1962 35	2	Hex.bolt	
3115	0147 1962 35	2	Hex.bolt		3030	0147 1400 00	4	Hex.bolt	
3120	0147 1480 00	1	Hex.bolt		3040	0301 2358 00	4	Plain washer	
3125	1903 2058 13	2	Hex nut		3041	0147 1552 03	8	Bolt	
3130	0266 2114 00	2	Hexagon nut		3060	1621 3148 00	1	Support	
3135	0300 0274 53	2	Plain washer		3065	0147 1401 00	4	Hex.bolt	
3140	0301 2378 00	1	Plain washer		3066	0300 0274 92	4	Washer	
3145	0301 2408 00	2	Washer		3070	9096 3915 00	2	Rubber buffer	
3150	0301 2358 00	2	Plain washer		3080	0147 1398 00	4	Hex.bolt	
3155	0333 2153 00	2	Spring washer ZR250 8.6 bar(e) 280KW/ 6.6KVO ZR250 10 bar(e) 280KW/ 6.6KVO <b>Drive arrg.complete with 280kw</b>		3090	0301 2358 00	4	Plain washer	
1005	1621 3729 00	1	Coupling housing		3095	9096 3690 02	1	Coupling half	
1010	0147 1405 03	8	Hex.bolt		3100	9096 4947 00	1	Motor support	
1040	1621 1534 02	1	Coupling half		3110	0147 1413 00	2	Hex.bolt	
1045	1619 6467 04	1	Set-rubbers		3115	0147 1962 35	2	Hex.bolt	
1050	1621 1535 01	1	Coupling half		3120	0147 1480 00	1	Hex.bolt	
1060	0147 1554 00	8	Hex.bolt		3125	1903 2058 13	2	Hex nut	
1061	0147 1632 03	2	Bolt		3130	0266 2114 00	2	Hexagon nut	
2000	9096 5013 00	1	Motor		3135	0300 0274 53	2	Plain washer	
2106	1621 1673 00	2	Guard		3140	0301 2378 00	1	Plain washer	
3010	9096 3915 00	2	Rubber buffer		3145	0301 2408 00	2	Washer	
3020	0147 1962 35	2	Hex.bolt		3150	0301 2358 00	2	Plain washer	
3030	0147 1400 00	4	Hex.bolt		3155	0333 2153 00	2	Spring washer ZR275 7.5 bar(e) 320KW/ 6.6KVO <b>Drive arrg.complete with 320kw</b>	
3040	0301 2358 00	4	Plain washer		1005	1621 3729 00	1	Coupling housing	
3041	0147 1552 03	8	Bolt		1010	0147 1405 03	8	Hex.bolt	
3060	1621 3148 00	1	Support		1040	1621 1534 02	1	Coupling half	
3065	0147 1401 00	4	Hex.bolt		1045	1619 6467 04	1	Set-rubbers	
3066	0300 0274 92	4	Washer		1050	1621 1535 01	1	Coupling half	
3070	9096 3915 00	2	Rubber buffer		1060	0147 1554 00	8	Hex.bolt	
3080	0147 1398 00	4	Hex.bolt		1061	0147 1632 03	2	Bolt	
					2000	9096 5015 00	1	Motor	
					2106	1621 1673 00	2	Guard	


# 24



## Drive arrangement

Ref.	Part number	Qty	Name	Remarks	Ref.	Part number	Qty	Name	Remarks
3010	9096 3915 00	2	Rubber buffer						<b>Drive arrg.complete with 320kw</b>
3020	0147 1962 35	2	Hex.bolt		1005	1621 3729 00	1	Coupling housing	
3030	0147 1400 00	4	Hex.bolt		1010	0147 1405 03	8	Hex.bolt	
3040	0301 2358 00	4	Plain washer		1040	1621 1534 02	1	Coupling half	
3041	0147 1552 03	8	Bolt		1045	1619 6467 04	1	Set-rubbers	
3060	1621 3148 00	1	Support		1050	1621 1535 01	1	Coupling half	
3065	0147 1401 00	4	Hex.bolt		1060	0147 1554 00	8	Hex.bolt	
3066	0300 0274 92	4	Washer		1061	0147 1632 03	2	Bolt	
3070	9096 3915 00	2	Rubber buffer		2000	9096 5020 00	1	Motor	
3080	0147 1398 00	4	Hex.bolt		2106	1621 1673 00	2	Guard	
3090	0301 2358 00	4	Plain washer		3010	9096 3915 00	2	Rubber buffer	
3095	9096 3690 07	1	Coupling - Motor.		3020	0147 1962 35	2	Hex.bolt	
3100	9096 4947 00	1	Motor support		3030	0147 1400 00	4	Hex.bolt	
3110	0147 1413 00	2	Hex.bolt		3040	0301 2358 00	4	Plain washer	
3115	0147 1962 35	2	Hex.bolt		3041	0147 1552 03	8	Bolt	
3120	0147 1480 00	1	Hex.bolt		3060	1621 3148 00	1	Support	
3125	1903 2058 13	2	Hex nut		3065	0147 1401 00	4	Hex.bolt	
3130	0266 2114 00	2	Hexagon nut		3066	0300 0274 92	4	Washer	
3135	0300 0274 53	2	Plain washer		3070	9096 3915 00	2	Rubber buffer	
3140	0301 2378 00	1	Plain washer		3080	0147 1398 00	4	Hex.bolt	
3145	0301 2408 00	2	Washer		3090	0301 2358 00	4	Plain washer	
3150	0301 2358 00	2	Plain washer		3095	9096 3690 02	1	Coupling half	
3155	0333 2153 00	2	Spring washer		3100	9096 4947 00	1	Motor support	
			ZR275 7.5 bar(e) 345KW/ 6.6KVO		3110	0147 1413 00	2	Hex.bolt	
			<b>Drive arrg.complete with 345kw</b>		3115	0147 1962 35	2	Hex.bolt	
1005	1621 3729 00	1	Coupling housing		3120	0147 1480 00	1	Hex.bolt	
1010	0147 1405 03	8	Hex.bolt		3125	1903 2058 13	2	Hex nut	
1040	1621 1534 02	1	Coupling half		3130	0266 2114 00	2	Hexagon nut	
1045	1619 6467 04	1	Set-rubbers		3135	0300 0274 53	2	Plain washer	
1050	1621 1535 01	1	Coupling half		3140	0301 2378 00	1	Plain washer	
1060	0147 1554 00	8	Hex.bolt		3145	0301 2408 00	2	Washer	
1061	0147 1632 03	2	Bolt		3150	0301 2358 00	2	Plain washer	
1085	9096 4731 14	1	Reducer ring		3155	0333 2153 00	2	Spring washer	
2000	9096 5016 00	1	Motor					ZR250 7.5 bar(e) 320KW/ 6.6KVO	
2106	1621 1673 00	2	Guard					<b>Drive arrg.complete with 320kw</b>	
3010	9096 3915 00	2	Rubber buffer		1005	1621 3729 00	1	Coupling housing	
3020	0147 1962 35	2	Hex.bolt		1010	0147 1405 03	8	Hex.bolt	
3030	0147 1400 00	4	Hex.bolt		1040	1621 1534 02	1	Coupling half	
3040	0301 2358 00	4	Plain washer		1045	1619 6467 04	1	Set-rubbers	
3041	0147 1552 03	8	Bolt		1050	1621 1535 01	1	Coupling half	
3060	1621 3148 00	1	Support		1060	0147 1554 00	8	Hex.bolt	
3065	0147 1401 00	4	Hex.bolt		1061	0147 1632 03	2	Bolt	
3066	0300 0274 92	4	Washer		2000	9096 5021 00	1	Motor	
3070	9096 3915 00	2	Rubber buffer		2106	1621 1673 00	2	Guard	
3080	0147 1398 00	4	Hex.bolt		3010	9096 3915 00	2	Rubber buffer	
3090	0301 2358 00	4	Plain washer		3020	0147 1962 35	2	Hex.bolt	
3095	9096 3690 07	1	Coupling - Motor.		3030	0147 1400 00	4	Hex.bolt	
3100	9096 4947 00	1	Motor support		3040	0301 2358 00	4	Plain washer	
3110	0147 1413 00	2	Hex.bolt		3041	0147 1552 03	8	Bolt	
3115	0147 1962 35	2	Hex.bolt		3060	1621 3148 00	1	Support	
3120	0147 1480 00	1	Hex.bolt		3065	0147 1401 00	4	Hex.bolt	
3125	1903 2058 13	2	Hex nut		3066	0300 0274 92	4	Washer	
3130	0266 2114 00	2	Hexagon nut		3070	9096 3915 00	2	Rubber buffer	
3135	0300 0274 53	2	Plain washer		3080	0147 1398 00	4	Hex.bolt	
3140	0301 2378 00	1	Plain washer		3090	0301 2358 00	4	Plain washer	
3145	0301 2408 00	2	Washer		3095	9096 3690 02	1	Coupling half	
3150	0301 2358 00	2	Plain washer		3100	9096 4947 00	1	Motor support	
3155	0333 2153 00	2	Spring washer		3110	0147 1413 00	2	Hex.bolt	
3160	9096 4955 00	1	Motor baffle		3115	0147 1962 35	2	Hex.bolt	
			ZR250 7.5 bar(e) 320KW/ 3.3KVO		3120	0147 1480 00	1	Hex.bolt	


# 24



## Drive arrangement

Ref.	Partnumber	Qty	Name	Remarks	Ref.	Partnumber	Qty	Name	Remarks
3125	1903 2058 13	2	Hex nut		3020	0147 1962 35	2	Hex.bolt	
3130	0266 2114 00	2	Hexagon nut		3030	0147 1400 00	4	Hex.bolt	
3135	0300 0274 53	2	Plain washer		3040	0301 2358 00	4	Plain washer	
3140	0301 2378 00	1	Plain washer		3060	1621 3148 00	1	Support	
3145	0301 2408 00	2	Washer		3065	0147 1401 00	4	Hex.bolt	
3150	0301 2358 00	2	Plain washer		3066	0300 0274 92	4	Washer	
3155	0333 2153 00	2	Spring washer		3070	9096 3915 00	2	Rubber buffer	
			ZT160 7.5 bar(e)		3080	0147 1400 00	4	Hex.bolt	
			160KW,3.3KV S		3090	0301 2358 00	4	Plain washer	
			ZT160 8.6 bar(e)		3095	9096 3690 07	1	Coupling	
			160KW,3.3KV S		3100	9096 4948 00	1	Motor support	
			ZT160 10 bar(e)		3110	0147 1413 00	2	Hex.bolt	
			160KW,3.3KV S		3115	0147 1480 00	2	Hex.bolt	
			<b>Drive arrg.complete</b>		3120	0147 1480 00	1	Hex.bolt	
1005	1621 1428 00	1	Coupling housing		3125	0261 1090 51	2	Hex.nut	
1010	0147 1405 03	8	Hex.bolt		3130	0266 2114 00	2	Hexagon nut	
1040	1621 1534 02	1	Coupling half		3135	0301 2378 00	2	Plain washer	
1045	1619 6467 04	1	Set-rubbers		3140	0301 2378 00	1	Plain washer	
1050	1621 1535 01	1	Coupling half		3145	0301 2393 00	2	Plain washer	
1060	0147 1554 00	8	Hex.bolt		3150	0301 2358 00	2	Plain washer	
1085	9096 4731 13	1	Reducing ring		3155	0333 2149 00	2	Spring washer	
2000	9096 4904 00	1	Motor					ZT250 7.5 bar(e)	
2106	1621 1673 00	2	Guard					250KW,3.3KV S	
3010	9096 4671 00	2	Anti vibration mount					ZT250 8.6 bar(e)	
3020	0147 1962 35	2	Hex.bolt					250KW,3.3KV S	
3030	0147 1400 00	4	Hex.bolt					ZT250 10 bar(e)	
3040	0301 2358 00	4	Plain washer					250KW,3.3KV S	
3060	1621 3148 00	1	Support					<b>Drive arrg.complete</b>	
3065	0147 1401 00	4	Hex.bolt		1005	1621 3729 00	1	Coupling housing	
3066	0300 0274 92	4	Washer		1010	0147 1405 03	8	Hex.bolt	
3070	9096 3915 00	2	Rubber buffer		1040	1621 1534 02	1	Coupling half	
3080	0147 1400 00	4	Hex.bolt		1045	1619 6467 04	1	Set-rubbers	
3090	0301 2358 00	4	Plain washer		1050	1621 1535 01	1	Coupling half	
3095	9096 3690 07	1	Coupling - Motor.side		1060	0147 1554 00	8	Hex.bolt	
3100	9096 4948 00	1	Motor support		1061	0147 1632 03	2	Bolt	
3105	0147 1554 00	2	Hex.bolt		2000	9096 4906 00	1	Motor	
3110	0147 1413 00	2	Hex.bolt		2106	1621 1673 00	2	Guard	
3115	0147 1480 00	2	Hex.bolt		3010	9096 3915 00	2	Rubber buffer	
3120	0147 1480 00	1	Hex.bolt		3020	0147 1962 35	2	Hex.bolt	
3125	0261 1090 51	2	Hex.nut		3030	0147 1400 00	4	Hex.bolt	
3130	0266 2114 00	2	Hexagon nut		3040	0301 2358 00	4	Plain washer	
3135	0301 2378 00	2	Plain washer		3041	0147 1552 03	8	Bolt	
3140	0301 2378 00	1	Plain washer		3060	1621 3148 00	1	Support	
3145	0301 2393 00	2	Plain washer		3065	0147 1401 00	4	Hex.bolt	
3150	0301 2358 00	2	Plain washer		3066	0300 0274 92	4	Washer	
3155	0333 2149 00	2	Spring washer		3070	9096 3915 00	2	Rubber buffer	
			ZT200 7.5 bar(e)		3080	0147 1398 00	4	Hex.bolt	
			200KW,3.3KV S		3090	0301 2358 00	4	Plain washer	
			ZT200 8.6 bar(e)		3095	9096 3690 07	1	Coupling	
			200KW,3.3KV S		3100	9096 4948 00	1	Motor support	
			ZT 200 10 bar(e)		3110	0147 1413 00	2	Hex.bolt	
			200KW,3.3KV S		3115	0147 1962 35	2	Hex.bolt	
			<b>Drive arrg.complete</b>		3120	0147 1480 00	1	Hex.bolt	
1005	1621 1428 00	1	Coupling housing		3125	1903 2058 13	2	Hex nut	
1010	0147 1405 03	8	Hex.bolt		3130	0266 2114 00	2	Hexagon nut	
1040	1621 1534 02	1	Coupling half		3135	0300 0274 53	2	Plain washer	
1045	1619 6467 04	1	Set-rubbers		3140	0301 2378 00	1	Plain washer	
1050	1621 1535 01	1	Coupling half		3145	0301 2408 00	2	Washer	
1060	0147 1554 00	8	Hex.bolt		3150	0301 2358 00	2	Plain washer	
1061	0147 1554 00	2	Hex.bolt		3155	0333 2153 00	2	Spring washer	
1085	9096 4731 13	1	Reducing ring					ZT275 7.5 bar(e)	
2000	9096 4905 00	1	Motor					275KW,3.3KV S	
2106	1621 1673 00	2	Guard					<b>Drive arrg.complete</b>	
3010	9096 4671 00	2	Anti vibration mount		1005	1621 3729 00	1	Coupling housing	


# 24



## Drive arrangement

Ref.	Partnumber	Qty	Name	Remarks	Ref.	Partnumber	Qty	Name	Remarks
1010	0147 1405 03	8	Hex.bolt		3140	0301 2378 00	1	Plain washer	
1040	1621 1534 02	1	Coupling half		3145	0301 2408 00	2	Washer	
1045	1619 6467 04	1	Set-rubbers		3150	0301 2358 00	2	Plain washer	
1050	1621 1535 01	1	Coupling half		3155	0333 2153 00	2	Spring washer	
1060	0147 1554 00	8	Hex.bolt					ZT160 7.5 bar(e)	
1061	0147 1632 03	2	Bolt					160KW,6.6KV S	
2000	9096 4907 00	1	Motor					ZT160 8.6 bar(e)	
2106	1621 1673 00	2	Guard					160KW,6.6KV S	
3010	9096 3915 00	2	Rubber buffer					ZT160 10 bar(e)	
3020	0147 1962 35	2	Hex.bolt					160KW,6.6KV S	
3030	0147 1400 00	4	Hex.bolt					<b>Drive arrg.complete</b>	
3040	0301 2358 00	4	Plain washer		1005	1621 3729 00	1	Coupling housing	
3041	0147 1552 03	8	Bolt		1010	0147 1405 03	8	Hex.bolt	
3060	1621 3148 00	1	Support		1040	1621 1534 02	1	Coupling half	
3065	0147 1401 00	4	Hex.bolt		1045	1619 6467 04	1	Set-rubbers	
3066	0300 0274 92	4	Washer		1050	1621 1535 01	1	Coupling half	
3070	9096 3915 00	2	Rubber buffer		1060	0147 1554 00	8	Hex.bolt	
3080	0147 1398 00	4	Hex.bolt		1061	0147 1632 03	2	Bolt	
3090	0301 2358 00	4	Plain washer		2000	9096 4910 00	1	Motor	
3095	9096 3690 07	1	Coupling		2106	1621 1673 00	2	Guard	
3100	9096 4946 00	1	Motor support		3010	9096 4671 00	2	Anti vibration mount	
3110	0147 1413 00	2	Hex.bolt		3020	0147 1962 35	2	Hex.bolt	
3115	0147 1962 35	2	Hex.bolt		3030	0147 1400 00	4	Hex.bolt	
3120	0147 1480 00	1	Hex.bolt		3040	0301 2358 00	4	Plain washer	
3125	1903 2058 13	2	Hex nut		3060	1621 3148 00	1	Support	
3130	0266 2114 00	2	Hexagon nut		3065	0147 1401 00	4	Hex.bolt	
3135	0300 0274 53	2	Plain washer		3066	0300 0274 92	4	Washer	
3140	0301 2378 00	1	Plain washer		3070	9096 3915 00	2	Rubber buffer	
3145	0301 2408 00	2	Washer		3080	0147 1398 00	4	Hex.bolt	
3150	0301 2358 00	2	Plain washer		3090	0301 2358 00	4	Plain washer	
3155	0333 2153 00	2	Spring washer		3095	9096 3690 03	1	Coupling half	
			ZT275 8.6 bar(e)		3100	9096 4946 00	1	Motor support	
			275KW,3.3KV S		3110	0147 1413 00	2	Hex.bolt	
			ZT275 10 bar(e)		3115	0147 1962 35	2	Hex.bolt	
			275KW,3.3KV S		3120	0147 1480 00	1	Hex.bolt	
			<b>Drive arrg.complete</b>		3125	1903 2058 13	2	Hex nut	
1005	1621 3729 00	1	Coupling housing		3130	0266 2114 00	2	Hexagon nut	
1010	0147 1405 03	8	Hex.bolt		3135	0300 0274 53	2	Plain washer	
1040	1621 1534 02	1	Coupling half		3140	0301 2378 00	1	Plain washer	
1045	1619 6467 04	1	Set-rubbers		3145	0301 2408 00	2	Washer	
1050	1621 1535 01	1	Coupling half		3150	0301 2358 00	2	Plain washer	
1060	0147 1554 00	8	Hex.bolt		3155	0333 2153 00	2	Spring washer	
1061	0147 1632 03	2	Bolt					ZT200 7.5 bar(e)	
2000	9096 4917 00	1	Motor					200KW,6.6KV S	
2106	1621 1673 00	2	Guard					ZT200 8.6 bar(e)	
3010	9096 3915 00	2	Rubber buffer					200KW,6.6KV S	
3020	0147 1962 35	2	Hex.bolt					ZT200 10 bar(e)	
3030	0147 1400 00	4	Hex.bolt					200KW,6.6KV S	
3040	0301 2358 00	4	Plain washer					<b>Drive arrg.complete</b>	
3041	0147 1552 03	8	Bolt		1005	1621 3729 00	1	Coupling housing	
3060	1621 3148 00	1	Support		1010	0147 1405 03	8	Hex.bolt	
3065	0147 1401 00	4	Hex.bolt		1040	1621 1534 02	1	Coupling half	
3066	0300 0274 92	4	Washer		1045	1619 6467 04	1	Set-rubbers	
3070	9096 3915 00	2	Rubber buffer		1050	1621 1535 01	1	Coupling half	
3080	0147 1398 00	4	Hex.bolt		1060	0147 1554 00	8	Hex.bolt	
3090	0301 2358 00	4	Plain washer		1061	0147 1632 03	2	Bolt	
3095	9096 3690 02	1	Coupling half		2000	9096 4911 00	1	Motor	
3100	9096 4947 00	1	Motor support		2106	1621 1673 00	2	Guard	
3110	0147 1413 00	2	Hex.bolt		3010	9096 4671 00	2	Anti vibration mount	
3115	0147 1962 35	2	Hex.bolt		3020	0147 1962 35	2	Hex.bolt	
3120	0147 1480 00	1	Hex.bolt		3030	0147 1400 00	4	Hex.bolt	
3125	1903 2058 13	2	Hex nut		3040	0301 2358 00	4	Plain washer	
3130	0266 2114 00	2	Hexagon nut		3060	1621 3148 00	1	Support	
3135	0300 0274 53	2	Plain washer		3065	0147 1401 00	4	Hex.bolt	

# 24




## Drive arrangement

24

Ref.	Partnumber	Qty	Name	Remarks	Ref.	Partnumber	Qty	Name	Remarks
3066	0300 0274 92	4	Washer		3120	0147 1480 00	1	Hex.bolt	
3070	9096 3915 00	2	Rubber buffer		3125	1903 2058 13	2	Hex nut	
3080	0147 1398 00	4	Hex.bolt		3130	0266 2114 00	2	Hexagon nut	
3090	0301 2358 00	4	Plain washer		3135	0300 0274 53	2	Plain washer	
3095	9096 3690 03	1	Coupling half		3140	0301 2378 00	1	Plain washer	
3100	9096 4946 00	1	Motor support		3145	0301 2408 00	2	Washer	
3110	0147 1413 00	2	Hex.bolt		3150	0301 2358 00	2	Plain washer	
3115	0147 1962 35	2	Hex.bolt		3155	0333 2153 00	2	Spring washer	
3120	0147 1480 00	1	Hex.bolt					ZT 275 7.5 bar(e)	
3125	1903 2058 13	2	Hex nut					275KW,6.6KV S	
3130	0266 2114 00	2	Hexagon nut					ZT275 8.6 bar(e)	
3135	0300 0274 53	2	Plain washer					275KW,6.6KV S	
3140	0301 2378 00	1	Plain washer					ZT275 10 bar(e)	
3145	0301 2408 00	2	Washer					275KW,6.6KV S	
3150	0301 2358 00	2	Plain washer					<b>Drive arrg.complete</b>	
3155	0333 2153 00	2	Spring washer		1005	1621 3729 00	1	Coupling housing	
			ZT250 7.5 bar(e)		1010	0147 1405 03	8	Hex.bolt	
			250KW,6.6KV S		1040	1621 1534 02	1	Coupling half	
			ZT250 8.6 bar(e)		1045	1619 6467 04	1	Set-rubbers	
			250KW,6.6KV S		1050	1621 1535 01	1	Coupling half	
			ZT250 10 bar(e)		1060	0147 1554 00	8	Hex.bolt	
			250KW,6.6KV S		1061	0147 1632 03	2	Bolt	
			<b>Drive arrg.complete</b>		2000	9096 4916 00	1	Motor	
1005	1621 3729 00	1	Coupling housing		2106	1621 1673 00	2	Guard	
1010	0147 1405 03	8	Hex.bolt		3010	9096 3915 00	2	Rubber buffer	
1040	1621 1534 02	1	Coupling half		3020	0147 1962 35	2	Hex.bolt	
1045	1619 6467 04	1	Set-rubbers		3030	0147 1400 00	4	Hex.bolt	
1050	1621 1535 01	1	Coupling half		3040	0301 2358 00	4	Plain washer	
1060	0147 1554 00	8	Hex.bolt		3041	0147 1552 03	8	Bolt	
1061	0147 1632 03	2	Bolt		3060	1621 3148 00	1	Support	
2000	9096 4912 00	1	Motor		3065	0147 1401 00	4	Hex.bolt	
2106	1621 1673 00	2	Guard		3066	0300 0274 92	4	Washer	
3010	9096 3915 00	2	Rubber buffer		3070	9096 3915 00	2	Rubber buffer	
3020	0147 1962 35	2	Hex.bolt		3080	0147 1398 00	4	Hex.bolt	
3030	0147 1400 00	4	Hex.bolt		3090	0301 2358 00	4	Plain washer	
3040	0301 2358 00	4	Plain washer		3095	9096 3690 02	1	Coupling half	
3041	0147 1552 03	8	Bolt		3100	9096 4947 00	1	Motor support	
3060	1621 3148 00	1	Support		3110	0147 1413 00	2	Hex.bolt	
3065	0147 1401 00	4	Hex.bolt		3115	0147 1962 35	2	Hex.bolt	
3066	0300 0274 92	4	Washer		3120	0147 1480 00	1	Hex.bolt	
3070	9096 3915 00	2	Rubber buffer		3125	1903 2058 13	2	Hex nut	
3080	0147 1398 00	4	Hex.bolt		3130	0266 2114 00	2	Hexagon nut	
3090	0301 2358 00	4	Plain washer		3135	0300 0274 53	2	Plain washer	
3095	9096 3690 02	1	Coupling half		3140	0301 2378 00	1	Plain washer	
3100	9096 4947 00	1	Motor support		3145	0301 2408 00	2	Washer	
3110	0147 1413 00	2	Hex.bolt		3150	0301 2358 00	2	Plain washer	
3115	0147 1962 35	2	Hex.bolt		3155	0333 2153 00	2	Spring washer	


# 25



## Regulation system - ZR

Ref.	Partnumber	Qty	Name	Remarks	Ref.	Partnumber	Qty	Name	Remarks
1005	1621 2602 00	1	Plate		1190	1089 0574 70	1	Temp sensor	
1010	1619 2766 00	2	Paint stripping bolt		1195	1089 0574 70	1	Temp sensor	
1015	1089 9154 02	1	Key cubicle		1200	1089 0574 70	1	Temp sensor	
1020	0160 6038 00	4	Slotted screw		1205	1089 0574 70	1	Temp sensor	
1025	0301 2315 00	4	Plain washer		1210	1089 0574 70	1	Temp sensor	
1030	0147 1322 03	11	Hex. head screw		1215	1089 0574 70	1	Temp sensor	
1035	0147 1246 00	1	Hex.bolt		1220	1089 0574 70	1	Temp sensor	
1040	0333 3227 00	3	Spring washer		1225	1089 0574 70	1	Temp sensor	
1045	0333 3220 00	1	Lock washer		1230	1089 0574 70	1	Temp sensor	
1050	0266 2110 00	1	Hexagon nut		1235	1089 0574 70	1	Temp sensor	
1055	0266 2108 00	1	Hex.nut		1240	1089 0574 70	1	Temp sensor	
1060	0211 1397 03	1	Cap screw		1245	1619 2766 00	6	Paint stripping bolt	
1065	0333 3237 00	1	Lock washer		1250	0348 0102 09	2	Cable tie	
1070	1621 6816 00	1	Wire harness		1255	1619 5898 01	2	Hex.bolt	
1075	1088 1301 01	10	Cable tie		1260	1089 0640 44	1	Solenoid valve	
1080	0348 0102 08	4	Cable tie		1265	1900 0710 32	1	Regulator Kit	
1085	1619 2766 00	1	Paint stripping bolt		2005	1623 6353 05	1	Flexible hose assembly	
1090	0348 0102 09	2	Cable tie		2010	0580 0013 32	1	Connector	
1095	0291 1108 00	2	Lock nut		2015	0661 1000 25	1	Seal washer	
1100	0147 1360 03	4	Hex. head screw		2020	1621 1382 00	1	Flange	
1105	1089 9625 16	1	Pressure sensor		2025	1621 0735 00	1	Filter element	
<b>1110</b>	<b>1621 1247 80</b>	<b>1</b>	<b>Nipple</b>		2030	1621 1383 00	1	Flange	
	1621 1247 00	• 1	Nipple		2035	0663 2132 00	1	O-Ring	
	1621 1248 00	• 1	Nipple		2040	0147 1252 03	2	Hex.bolt	
	1621 1249 00	• 1	Bushing		2045	0266 2108 00	2	Hex.nut	
1115	0661 1000 25	1	Seal washer		2050	0603 4100 44	2	Hex. nipple	
<b>1120</b>	<b>1621 1247 80</b>	<b>1</b>	<b>Nipple</b>		2055	1621 7443 00	1	Valve	
	1621 1247 00	• 1	Nipple		2060	0580 0013 32	1	Connector	
	1621 1248 00	• 1	Nipple		2065	0661 1000 25	1	Seal washer	
	1621 1249 00	• 1	Bushing		2070	1623 6353 05	1	Flexible hose assembly	
1125	0661 1000 25	1	Seal washer		2075	0580 0506 00	1	Straight coupling	
1130	1089 9625 12	1	Pressure sensor		2080	0661 1000 25	1	Seal washer	
<b>1135</b>	<b>1621 1247 80</b>	<b>1</b>	<b>Nipple</b>		2085	0580 3404 00	1	Pipe coupling	
	1621 1247 00	• 1	Nipple		2090	1621 7672 00	1	Support	
	1621 1248 00	• 1	Nipple		2095	0147 1322 03	2	Hex. head screw	
	1621 1249 00	• 1	Bushing		2100	0211 1170 03	4	Hexagon socket screw Connection	
1140	0661 1000 25	1	Seal washer		2150	0580 0506 00	1	Str.coupling	
1145	1089 9625 18	1	Pressure sensor		2160	0661 1000 25	1	Seal washer	
1150	1089 0590 21	1	Solenoid valve		2175	1903 4701 07	1	Equal tee	
1155	1619 2689 00	1	Filter plug		3005	1621 3189 00	1	Bracket	
1160	0663 2108 63	3	O-Ring		3010	0147 1397 03	1	Hex.bolt	
1165	0211 1251 03	4	Hex.socket cap screw		3015	1613 0801 05	1	Hose clamp	
1170	1614 6596 00	2	Knurled nut		3020	0147 1244 00	1	Hex.bolt	
1175	0223 4000 35	2	Shoulder screw		3025	0266 2108 00	1	Hex.nut	
1180	1079 9901 67	1	Lable						
1185	1619 2766 00	4	Paint stripping bolt						

# 26




## Regulation system - ZT

26

Ref.	Partnumber	Qty	Name	Remarks	Ref.	Partnumber	Qty	Name	Remarks
1005	1621 6818 00	1	Wire harness		1125	1089 0574 70	1	Temp sensor	
1010	1088 1301 01	10	Cable tie		1130	1089 0574 70	1	Temp sensor	
1015	1619 2766 00	1	Paint stripping bolt		1135	1089 0574 70	1	Temp sensor	
1020	0291 1108 00	2	Lock nut		1140	1089 0574 70	1	Temp sensor	
1025	0147 1360 03	4	Hex. head screw		1145	1089 0574 70	1	Temp sensor	
1030	1089 9625 16	1	Pressure sensor		1150	1619 2766 00	6	Paint stripping bolt	
1035	1089 9625 12	1	Pressure sensor		1155	1619 5898 01	4	Hex.bolt	
<b>1040</b>	<b>1621 1247 80</b>	<b>1</b>	<b>Nipple</b>		1160	1900 0710 32	1	Regulator	
	1621 1247 00	• 1	Nipple		1165	1089 0640 44	1	Solenoid valve	
	1621 1248 00	• 1	Nipple					<b>Kit</b>	
	1621 1249 00	• 1	Bushing		2005	1621 7655 00	1	Pipe	
1045	0661 1000 25	1	Seal washer		2010	0580 0013 32	1	Connector	
<b>1050</b>	<b>1621 1247 80</b>	<b>1</b>	<b>Nipple</b>		2015	0661 1000 25	1	Seal washer	
	1621 1247 00	• 1	Nipple		2020	1621 1382 00	1	Flange	
	1621 1248 00	• 1	Nipple		2025	1621 0735 00	1	Filter element	
	1621 1249 00	• 1	Bushing		2030	1621 1383 00	1	Flange	
1055	0661 1000 25	1	Seal washer		2035	0663 2132 00	1	O-Ring	
1060	1089 9625 12	1	Pressure sensor		2040	0147 1252 03	2	Hex.bolt	
<b>1065</b>	<b>1621 1247 80</b>	<b>1</b>	<b>Nipple</b>		2045	0266 2108 00	2	Hex.nut	
	1621 1247 00	• 1	Nipple		2050	0603 4100 44	2	Hex. nipple	
	1621 1248 00	• 1	Nipple		2055	1621 7443 00	1	Valve	
	1621 1249 00	• 1	Bushing		2060	0580 0013 32	1	Connector	
1070	0661 1000 25	1	Seal washer		2065	0661 1000 25	1	Seal washer	
1075	1089 9625 18	1	Pressure sensor		2070	1623 6353 03	1	Flexible hose assembly	
1080	1089 0590 21	1	Solenoid valve		2075	1621 7672 00	1	Support	
1085	1619 2689 00	1	Filter plug		2080	0147 1322 03	2	Hex. head screw	
1090	0663 2108 63	3	O-Ring		2085	0211 1170 03	4	Hexagon socket screw	
1095	1623 2495 00	1	Blow down valve					<b>Connection</b>	
1100	0211 1251 03	4	Hex.socket cap screw		3005	0580 0506 00	1	Str.coupling	
1105	1614 6596 00	2	Knurled nut		3010	0661 1000 25	1	Seal washer	
1110	0223 4000 35	2	Shoulder screw		3015	0580 3404 00	1	Pipe coupling	
1115	1619 2766 00	4	Paint stripping bolt					<b>Connection</b>	
1120	1089 0574 70	1	Temp sensor		3020	1903 4701 07	1	Equal tee	

27




## Bodywork Cubicle Box

27

Ref.	Partnumber	Qty	Name	Remarks	Ref.	Partnumber	Qty	Name	Remarks
			<b>For ZR</b>						
1010	9096 4181 00	1	Cubicle		1020	1621 2547 00	2	Hinge	
1020	1621 2547 00	2	Hinge		1030	0216 1204 00	4	Screw	
1030	0216 1204 00	4	Screw		1050	0266 2110 00	6	Hexagon nut	
1040	0160 6105 00	4	Screw		1055	0301 2315 00	4	Plain washer	
1045	1619 6449 00	AR	Seal		1060	9096 4569 15	1	Cubicle Door	
1050	0266 2110 00	2	Hexagon nut		1070	0989 4220 07	2	Grommet	
1055	0301 2335 00	4	Plain washer		1075	0111 1313 00	2	Split pin	
1060	9096 4569 15	1	Cubicle door		1090	0301 2335 00	20	Plain washer	
1065	1621 2596 00	1	Handgrip		1095	1089 9154 02	1	Key cubicle	
1070	0989 4220 07	2	Grommet		1100	1614 6567 00	1	Seal	
1075	0111 1313 00	2	Split pin		1105	1621 1309 00	1	Bracket	
1080	1619 2766 00	2	Paint stripping bolt		1110	1614 6562 00	4	Clamp	
1085	1614 7146 00	1	Flange		1115	1614 6563 00	4	Clamp	
1090	0301 2335 00	12	Plain washer		1120	0147 1961 27	8	Bolt	
			<b>For ZT</b>		1125	0301 2321 00	8	Plain washer	
1010	9096 4181 00	1	Cubicle Box						

# 28




## Bodywork Inlet Silencer

28

Ref.	Partnumber	Qty	Name	Remarks	Ref.	Partnumber	Qty	Name	Remarks
			<b>For ZR</b>		1030	1619 2766 00	6	Paint stripping bolt	
1010	9096 4952 10	1	Air inlet duct assembly		1035	1619 2766 00	1	Paint stripping bolt	
1020	1621 2667 00	2	Plate		1040	1619 2766 00	2	Paint stripping bolt	
1030	1619 2766 00	12	Paint stripping bolt		1045	1619 2766 02	4	Paint stripping bolt	
1050	9096 4565 00	1	Roof		1050	9096 4565 00	1	Roof	
1060	1621 2554 00	1	Bracket		1060	1621 2554 00	1	Bracket	
1090	9096 4953 50	1	Foam holder		1070	0333 3227 00	3	Spring washer	
			<b>For ZT</b>		1080	0147 1322 03	7	Hex. head screw	
1010	9096 4952 10	1	Air Inlet Duct		1090	9096 4953 50	1	Foam holder	
1020	1621 2667 00	2	Plate						

# 29



## Bodywork ZR - Baffle

29

Ref.	Partnumber	Qty	Name	Remarks	Ref.	Partnumber	Qty	Name	Remarks
			ZR160 7.5 bar(e) 190KW/ 3.3KVO					ZR160 7.5 bar(e) 190KW/ 6.6KVO	
			ZR160 8.6 bar(e) 175KW/ 3.3KVO					ZR160 8.6 bar(e) 175KW/ 6.6KVO	
			ZR160 10 bar(e) 165KW/ 3.3KVO					ZR160 10 bar(e) 165KW/ 6.6KVO	
			ZR200 7.5 bar(e) 240KW/ 3.3KVO					ZR200 7.5 bar(e) 240KW/ 6.6KVO	
			ZR200 8.6 bar(e) 220KW/ 3.3KVO					ZR200 8.6 bar(e) 220KW/ 6.6KVO	
			ZR200 10 bar(e) 200KW/ 3.3KVO					ZR200 10 bar(e) 200KW/ 6.6KVO	
			ZR250 10 bar(e) 255KW/ 3.3KVO					ZR160 7.5 bar(e) 200KW/ 6.6KVO	
			ZR160 7.5 bar(e) 200KW/ 3.3KVO					ZR160 8.6 bar(e) 190KW/ 6.6KVO	
			ZR160 8.6 bar(e) 190KW/ 3.3KVO					ZR160 10 bar(e) 175KW/ 6.6KVO	
			ZR160 10 bar(e) 175KW/ 3.3KVO					ZR200 7.5 bar(e) 255KW/ 6.6KVO	
			ZR200 7.5 bar(e) 255KW/ 3.3KVO					ZR200 8.6 bar(e) 240KW/ 6.6KVO	
			ZR200 8.6 bar(e) 240KW/ 3.3KVO					ZR200 10 bar(e) 220KW/ 6.6KVO	
			ZR200 10 bar(e) 220KW/ 3.3KVO		1010	1619 2766 00	18	Paint stripping bolt	
1010	1619 2766 00	18	Paint stripping bolt		1020	1621 2402 00	1	Bracket	
1020	1621 2402 00	1	Bracket		1025	9096 4782 00	1	Baffle	
1025	9096 4782 00	1	Baffle		1030	1621 2885 00	1	Silencer	
1030	1621 2885 00	1	Silencer		1035	1621 2503 00	2	Plate	
1035	1621 2503 00	2	Plate		1045	9096 4755 00	1	Baffle	
1045	9096 4755 00	1	Baffle		1050	1621 2504 00	2	Plate	
1050	1621 2504 00	2	Plate		1060	1079 1472 05	4	Screw	
1060	1079 1472 05	4	Screw		2005	9096 4957 00	1	Plate	
2005	9096 4957 00	1	Plate		2015	9096 4748 00	1	Panel	
2015	9096 4748 00	1	Panel		2020	1619 2766 00	2	Paint stripping bolt	
2020	1619 2766 00	2	Paint stripping bolt		2030	9096 4749 00	1	Panel	
2030	9096 4749 00	1	Panel		2035	1619 2766 00	2	Paint stripping bolt	
2035	1619 2766 00	2	Paint stripping bolt		2045	9096 4229 10	1	Panel	
2045	9096 4229 10	1	Panel		2050	1079 1472 05	4	Screw	
2050	1079 1472 05	4	Screw		2055	1621 2823 00	1	Bracket	
2055	1621 2823 00	1	Bracket		2075	9096 4580 00	1	Baffle	
2075	9096 4580 00	1	Baffle		2080	9096 4955 10	1	Motor baffle	
2080	9096 4955 10	1	Motor baffle		2105	0301 2335 00	2	Plain washer	
2105	0301 2335 00	2	Plain washer					ZR250 7.5 bar(e) 300KW/ 3.3KVO	




## Bodywork ZR - Baffle

29

Ref.	Partnumber	Qty	Name	Remarks	Ref.	Partnumber	Qty	Name	Remarks
			ZR250 8.6 bar(e) 280KW/ 3.3KVO		2035	1619 2766 00	2	Paint stripping bolt	
			ZR250 7.5 bar(e) 300KW/ 6.6KVO		2045	9096 4229 10	1	Panel	
			ZR250 8.6 bar(e) 280KW/ 6.6KVO		2050	1079 1472 05	4	Screw	
			ZR250 10 bar(e) 255KW/ 6.6KVO		2055	1621 2823 00	1	Bracket	
			ZR250 7.5 bar(e) 320KW/ 3.3KVO		2075	9096 4580 00	1	Baffle	
			ZR250 8.6 bar(e) 300KW/ 3.3KVO		2080	9096 4955 00	1	Motor baffle	
			ZR250 10 bar(e) 280KW/ 3.3KVO					ZR275 7.5 bar(e) 320KW/ 3.3KVO	
			ZR250 7.5 bar(e) 320KW/ 6.6KVO					ZR275 7.5 bar(e) 320KW/ 6.6KVO	
			ZR250 8.6 bar(e) 300KW/ 3.3KVO					ZR275 7.5 bar(e) 345KW/ 3.3KVO	
			ZR250 10 bar(e) 280KW/ 3.3KVO					ZR275 7.5 bar(e) 345KW/ 6.6KVO	
			ZR250 7.5 bar(e) 320KW/ 6.6KVO		1010	1619 2766 00	18	Paint stripping bolt	
			ZR250 8.6 bar(e) 300KW/ 6.6KVO		1020	1621 2402 00	1	Bracket	
			ZR250 10 bar(e) 280KW/ 6.6KVO		1025	9096 4782 00	1	Baffle	
1010	1619 2766 00	18	Paint stripping bolt		1030	1621 2885 00	1	Silencer	
1020	1621 2402 00	1	Bracket		1035	1621 2503 00	2	Plate	
1025	9096 4782 00	1	Baffle		1045	9096 4755 00	1	Baffle	
1030	1621 2885 00	1	Silencer		1050	1621 2504 00	2	Plate	
1035	1621 2503 00	2	Plate		1060	1079 1472 05	4	Screw	
1045	9096 4755 00	1	Baffle		2005	9096 4957 00	1	Plate	
1050	1621 2504 00	2	Plate		2015	9096 4748 00	1	Panel	
1060	1079 1472 05	4	Screw		2020	1619 2766 00	2	Paint stripping bolt	
2005	9096 4957 00	1	Plate		2030	9096 4749 00	1	Panel	
2015	9096 4748 00	1	Panel		2035	1619 2766 00	2	Paint stripping bolt	
2020	1619 2766 00	2	Paint stripping bolt		2045	9096 4229 10	1	Panel	
2030	9096 4749 00	1	Panel		2050	1079 1472 05	4	Screw	
					2055	1621 2823 00	1	Bracket	
					2075	9096 4580 00	1	Baffle	
					2105	0301 2335 00	2	Plain washer	


# 30



## Bodywork ZT - Baffle

Ref.	Partnumber	Qty	Name	Remarks	Ref.	Partnumber	Qty	Name	Remarks
			ZT160 7.5 bar(e) 160KW,3.3KV S		1005	9096 4757 00	1	Baffle	
			ZT160 8.6 bar(e) 160KW,3.3KV S		1010	1619 2766 00	92	Paint stripping bolt	
			ZT160 10 bar(e) 160KW,3.3KV S		1015	9096 4758 00	1	Baffle	
			ZT200 7.5 bar(e) 200KW,3.3KV S		1030	1621 2911 00	1	Panel	
			ZT200 8.6 bar(e) 200KW,3.3KV S		<b>1040</b>	<b>1621 2913 00</b>	<b>1</b>	<b>Panel</b>	
			ZT250 7.5 bar(e) 250KW,3.3KV S			1619 2795 00	• 1	AR Rubber strip	
			ZT250 8.6 bar(e) 250KW,3.3KV S		1055	1621 2392 00	1	Panel	
			ZT250 10 bar(e) 250KW,3.3KV S		1080	1621 2912 00	1	Plate	
					1095	1621 2507 00	1	Profile	
					1120	1621 2446 00	1	Plate	
					1130	1621 2914 00	2	Plate	
					1140	1621 2497 00	4	Panel	
					1155	1621 2916 00	4	Foam Holder	
					1170	1621 2918 00	4	Foam Holder	
					1200	1621 2921 00	4	Foam Holder	
					2005	1621 2503 00	1	Plate	
					2015	1621 2504 00	1	Plate	
					2025	1621 2897 00	2	Plate	
1005	9096 4757 00	1	Baffle		2035	9096 4756 00	1	Baffle	
1010	1619 2766 00	92	Paint stripping bolt		<b>2045</b>	<b>1621 2885 00</b>	<b>1</b>	<b>Silencer</b>	
1015	9096 4758 00	1	Baffle			1621 2890 00	• 1	Profile	
1030	1621 2911 00	1	Panel		2055	9096 4755 00	1	Baffle	
<b>1040</b>	<b>1621 2913 00</b>	<b>1</b>	<b>Panel</b>		3005	9096 4957 00	1	Plate	
	1619 2795 00	• 1	AR Rubber strip		<b>3015</b>	<b>9096 4748 00</b>	<b>1</b>	<b>Panel</b>	
1055	1621 2392 00	1	Panel			1619 2473 00	• 1	AR Seal	
1080	1621 2912 00	1	Plate		3030	9096 4749 00	1	Panel	
1095	1621 2507 00	1	Profile		3045	9096 4229 10	1	Panel	
1120	1621 2446 00	1	Plate		3075	9096 4580 00	1	Baffle	
1130	1621 2914 00	2	Plate		3080	9096 4955 20	1	Motor baffle	
1140	1621 2497 00	4	Panel		3120	1621 2602 00	1	Plate	
1155	1621 2916 00	4	Foam Holder					ZT250 7.5 bar(e) 250KW,6.6KV S	
1170	1621 2918 00	4	Foam Holder					ZT250 8.6 bar(e) 250KW,6.6KV S	
1200	1621 2921 00	4	Foam Holder					ZT250 10 bar(e) 250KW,6.6KV S	
2005	1621 2503 00	1	Plate					ZT275 7.5 bar(e) 275KW,6.6KV S	
2015	1621 2504 00	1	Plate					ZT275 8.6 bar(e) 275KW,3.3KV S	
2025	1621 2897 00	2	Plate					ZT275 10 bar(e) 275KW,3.3KV S	
2035	9096 4756 00	1	Baffle					ZT275 10 bar(e) 275KW,6.6KV S	
<b>2045</b>	<b>1621 2885 00</b>	<b>1</b>	<b>Silencer</b>					ZT275 10 bar(e) 275KW,6.6KV S	
	1621 2890 00	• 1	Profile					ZT275 10 bar(e) 275KW,6.6KV S	
2055	9096 4755 00	1	Baffle					ZT275 10 bar(e) 275KW,6.6KV S	
3005	9096 4957 00	1	Plate					ZT275 10 bar(e) 275KW,6.6KV S	
<b>3015</b>	<b>9096 4748 00</b>	<b>1</b>	<b>Panel</b>					ZT275 10 bar(e) 275KW,6.6KV S	
	1619 2473 00	• 1	AR Seal					ZT275 10 bar(e) 275KW,6.6KV S	
3030	9096 4749 00	1	Panel					ZT275 10 bar(e) 275KW,6.6KV S	
3045	9096 4229 10	1	Panel					ZT275 10 bar(e) 275KW,6.6KV S	
3075	9096 4580 00	1	Baffle					ZT275 10 bar(e) 275KW,6.6KV S	
3080	9096 4955 20	1	Motor baffle		1005	9096 4757 00	1	Baffle	
3120	1621 2602 00	1	Plate		1010	1619 2766 00	92	Paint stripping bolt	
			ZT160 7.5 bar(e) 160KW,6.6KV S		1015	9096 4758 00	1	Baffle	
			ZT160 8.6 bar(e) 160KW,6.6KV S		1030	1621 2911 00	1	Panel	
			ZT160 10 bar(e) 160KW,6.6KV S		<b>1040</b>	<b>1621 2913 00</b>	<b>1</b>	<b>Panel</b>	
			ZT200 7.5 bar(e) 200KW,6.6KV S			1619 2795 00	• 1	AR Rubber strip	
			ZT200 8.6 bar(e) 200KW,6.6KV S		1055	1621 2392 00	1	Panel	
			ZT200 10 bar(e) 200KW,6.6KV S		1080	1621 2912 00	1	Plate	
					1095	1621 2507 00	1	Profile	
					1120	1621 2446 00	1	Plate	
					1130	1621 2914 00	2	Plate	
					1140	1621 2497 00	4	Panel	
					1155	1621 2916 00	4	Foam Holder	
					1170	1621 2918 00	4	Foam Holder	

# 30




## Bodywork ZT - Baffle

30

Ref.	Partnumber	Qty	Name	Remarks	Ref.	Partnumber	Qty	Name	Remarks
1200	1621 2921 00	4	Foam Holder		1080	1621 2912 00	1	Plate	
2005	1621 2503 00	1	Plate		1095	1621 2507 00	1	Profile	
2015	1621 2504 00	1	Plate		1120	1621 2446 00	1	Plate	
2025	1621 2897 00	2	Plate		1130	1621 2914 00	2	Plate	
2035	9096 4756 00	1	Baffle		1140	1621 2497 00	4	Panel	
<b>2045</b>	<b>1621 2885 00</b>	<b>1</b>	<b>Silencer</b>		1155	1621 2916 00	4	Foam Holder	
	1621 2890 00	• 1	Profile		1170	1621 2918 00	4	Foam Holder	
2055	9096 4755 00	1	Baffle		1200	1621 2921 00	4	Foam Holder	
3005	9096 4957 00	1	Plate		2005	1621 2503 00	1	Plate	
<b>3015</b>	<b>9096 4748 00</b>	<b>1</b>	<b>Panel</b>		2015	1621 2504 00	1	Plate	
	1619 2473 00	• AR	Seal		2025	1621 2897 00	2	Plate	
3030	9096 4749 00	1	Panel		2035	9096 4756 00	1	Baffle	
3045	9096 4229 10	1	Panel		<b>2045</b>	<b>1621 2885 00</b>	<b>1</b>	<b>Silencer</b>	
3075	9096 4580 00	1	Baffle			1621 2890 00	• 1	Profile	
3080	9096 4955 20	1	Motor baffle		2055	9096 4755 00	1	Baffle	
3120	1621 2602 00	1	Plate		3005	9096 4957 00	1	Plate	
			ZT275 7.5 bar(e) 275KW,3.3KVS		<b>3015</b>	<b>9096 4748 00</b>	<b>1</b>	<b>Panel</b>	
						1619 2473 00	• AR	Seal	
1005	9096 4757 00	1	Baffle		3030	9096 4749 00	1	Panel	
1010	1619 2766 00	92	Paint stripping bolt		3045	9096 4229 10	1	Panel	
1015	9096 4758 00	1	Baffle		3075	9096 4580 00	1	Baffle	
1030	1621 2911 00	1	Panel		3080	9096 4955 20	1	Motor baffle	
<b>1040</b>	<b>1621 2913 00</b>	<b>1</b>	<b>Panel</b>		3120	1621 2602 00	1	Plate	
	1619 2795 00	• AR	Rubber strip						
1055	1621 2392 00	1	Panel						

# 31



## Bodywork ZR - Doors and Stays

Ref.	Partnumber	Qty	Name	Remarks	Ref.	Partnumber	Qty	Name	Remarks
			ZR160 7.5 bar(e) 190KW/ 3.3KVO		5030	0298 1000 25	3	Nut	
			ZR160 7.5 bar(e) 200KW/ 3.3KVO		5035	0147 1334 00	2	Hex.bolt	
			ZR160 8.6 bar(e) 175KW/ 3.3KVO		5040	0261 1107 00	4	Nut	
			ZR160 8.6 bar(e) 190KW/ 3.3KVO		5045	0160 6105 00	2	Screw	
			ZR160 10 bar(e) 165KW/ 3.3KVO		6005	1619 2795 00	AR	Rubber strip	
			ZR160 10 bar(e) 175KW/ 3.3KVO					ZR160 7.5 bar(e) 190KW/ 6.6KVO	
			ZR200 7.5 bar(e) 240KW/ 3.3KVO					ZR160 7.5 bar(e) 200KW/ 6.6KVO	
			ZR200 7.5 bar(e) 255KW/ 3.3KVO					ZR160 8.6 bar(e) 175KW/ 6.6KVO	
			ZR200 8.6 bar(e) 220KW/ 3.3KVO					ZR160 8.6 bar(e) 190KW/ 6.6KVO	
			ZR200 8.6 bar(e) 240KW/ 3.3KVO					ZR160 10 bar(e) 165KW/ 6.6KVO	
			ZR200 10 bar(e) 200KW/ 3.3KVO					ZR160 10 bar(e) 175KW/ 6.6KVO	
			ZR200 10 bar(e) 220KW/ 3.3KVO					ZR200 7.5 bar(e) 240KW/ 6.6KVO	
			ZR250 10 bar(e) 255KW/ 3.3KVO					ZR200 7.5 bar(e) 255KW/ 6.6KVO	
			<b>Body work complete</b>					ZR200 8.6 bar(e) 220KW/ 6.6KVO	
1010	9096 4800 30	1	Frame					ZR200 8.6 bar(e) 240KW/ 6.6KVO	
			<b>Kit canopy</b>					ZR200 10 bar(e) 200KW/ 6.6KVO	
2005	1621 2477 00	2	Stay					ZR200 10 bar(e) 220KW/ 6.6KVO	
2025	1621 2478 00	2	Stay		1010	9096 4800 30	1	Frame	
2055	9096 4579 00	8	Stay					<b>Kit canopy</b>	
2075	9096 4232 10	4	Beam		2005	1621 2477 00	2	Stay	
2080	9096 4232 50	2	Beam		2025	1621 2478 00	2	Stay	
2095	1621 2632 00	2	Plate		2055	9096 4579 00	8	Stay	
2105	9096 4233 10	2	End panel		2075	9096 4232 10	4	Beam	
2110	9096 4235 10	1	End panel		2080	9096 4232 50	2	Beam	
<b>2120</b>	<b>9096 4236 10</b>	<b>1</b>	<b>End panel</b>		2095	1621 2632 00	2	Plate	
	0581 0000 86	• 2	Pipe coupling		2105	9096 4233 10	2	End panel	
	1621 9438 00	• 6	Pin		2110	9096 4235 10	1	End panel	
	1615 7884 00	• 6	Clip		<b>2120</b>	<b>9096 4236 10</b>	<b>1</b>	<b>End panel</b>	
2130	9095 4567 50	1	Roof			0581 0000 86	• 2	Pipe coupling	
2135	9096 4582 00	1	Roof			1621 9438 00	• 6	Pin	
2140	1619 2766 02	4	Paint stripping bolt			1615 7884 00	• 6	Clip	
2142	1619 2766 02	4	Paint stripping bolt		2130	9095 4567 50	1	Roof	
2145	1621 5747 00	4	Profile		2135	9096 4582 00	1	Roof	
2150	1621 5748 00	4	Profile		2140	1619 2766 02	4	Paint stripping bolt	
2155	1621 2544 00	8	Profile		2142	1619 2766 02	4	Paint stripping bolt	
2160	0300 0274 32	24	Plain washer		2145	1621 5747 00	4	Profile	
2165	0211 1247 03	24	Hex sock. screw		2150	1621 5748 00	4	Profile	
3050	1619 2766 00	6	Paint stripping bolt		2155	1621 2544 00	8	Profile	
4010	1621 2538 00	24	Hinge		2160	0300 0274 32	24	Plain washer	
4020	1619 2766 00	1	Paint stripping bolt		2165	0211 1247 03	24	Hex sock. screw	
4040	1619 2766 00	2	Paint stripping bolt		3050	1619 2766 00	6	Paint stripping bolt	
4045	9096 4568 00	2	Panel		4010	1621 2538 00	24	Hinge	
4050	1079 1472 05	4	Screw		4020	1619 2766 00	1	Paint stripping bolt	
4055	9096 4234 10	3	End panel		4040	1619 2766 00	2	Paint stripping bolt	
4071	0300 0274 94	8	Plain washer		4045	9096 4568 00	2	Panel	
5005	9096 4569 00	8	Door		4050	1079 1472 05	4	Screw	
5010	9096 4569 11	1	Door		4055	9096 4234 10	3	End panel	
5013	9096 4569 10	2	Door		4071	0300 0274 94	8	Plain washer	
5015	1621 0607 00	26	Pin		5005	9096 4569 00	8	Door	
5020	1089 9068 01	1	Key		5010	9096 4569 11	1	Door	
5025	0160 6105 00	16	Screw		5013	9096 4569 10	2	Door	



## Bodywork ZR - Doors and Stays

Ref.	Partnumber	Qty	Name	Remarks	Ref.	Partnumber	Qty	Name	Remarks
5015	1621 0607 00	26	Pin		5005	9096 4569 00	8	Door	
5020	1089 9068 01	1	Key		5010	9096 4569 11	1	Door	
5025	0160 6105 00	16	Screw		5013	9096 4569 10	2	Door	
5030	0298 1000 25	3	Nut		5015	1621 0607 00	26	Pin	
5035	0147 1334 00	2	Hex.bolt		5020	1089 9068 01	1	Key	
5040	0261 1107 00	4	Nut		5025	0160 6105 00	16	Screw	
5045	0160 6105 00	2	Screw		5030	0298 1000 25	3	Nut	
6005	1619 2795 00	AR	Rubber strip		5035	0147 1334 00	2	Hex.bolt	
			ZR250 7.5 bar(e) 300KW/ 3.3KVO		5040	0261 1107 00	4	Nut	
			ZR250 7.5 bar(e) 300KW/ 6.6KVO		5045	0160 6105 00	2	Screw	
			ZR250 7.5 bar(e) 320KW/ 3.3KVO		6005	1619 2795 00	AR	Rubber strip	
			ZR250 7.5 bar(e) 320KW/ 6.6KVO					ZR275 7.5 bar(e) 320KW/ 3.3KVO	
			ZR250 8.6 bar(e) 280KW/ 3.3KVO					ZR275 7.5 bar(e) 320KW/ 6.6KVO	
			ZR250 8.6 bar(e) 280KW/ 6.6KVO					ZR275 7.5 bar(e) 345KW/ 3.3KVO	
			ZR250 8.6 bar(e) 300KW/ 3.3KVO					ZR275 7.5 bar(e) 345KW/ 6.6KVO	
			ZR250 8.6 bar(e) 300KW/ 6.6KVO		1010	9096 4800 30	1	Frame	
			ZR250 10 bar(e) 255KW/ 6.6KVO					<b>Bodywork complete</b>	
			ZR250 10 bar(e) 280KW/ 3.3KVO		2005	1621 2477 00	2	Stay	
			ZR250 10 bar(e) 280KW/ 6.6KVO		2025	1621 2478 00	2	Stay	
			<b>Body work complete</b>		2055	9096 4579 00	8	Stay	
1010	9096 4800 30	1	Frame		2075	9096 4232 10	4	Beam	
			<b>Kit canopy</b>		2080	9096 4232 50	2	Beam	
2005	1621 2477 00	2	Stay		2095	1621 2632 00	2	Plate	
2025	1621 2478 00	2	Stay		2105	9096 4233 10	2	End panel	
2055	9096 4579 00	8	Stay		2110	9096 4235 10	1	End panel	
2075	9096 4232 10	4	Beam		<b>2120</b>	<b>9096 4236 10</b>	<b>1</b>	<b>End panel</b>	
2080	9096 4232 50	2	Beam			0581 0000 86	• 2	Pipe coupling	
2095	1621 2632 00	2	Plate			1621 9438 00	• 6	Pin	
2105	9096 4233 10	2	End panel			1615 7884 00	• 6	Clip	
2110	9096 4235 10	1	End panel		2130	9095 4567 50	1	Roof	
			<b>End panel</b>		2135	9096 4582 00	1	Roof	
	0581 0000 86	• 2	Pipe coupling		2140	1619 2766 02	4	Paint stripping bolt	
	1621 9438 00	• 6	Pin		2142	1619 2766 02	4	Paint stripping bolt	
	1615 7884 00	• 6	Clip		2145	1621 5747 00	4	Profile	
2130	9095 4567 50	1	Roof		2150	1621 5748 00	4	Profile	
2135	9096 4582 00	1	Roof		2155	1621 2544 00	8	Profile	
2140	1619 2766 02	4	Paint stripping bolt		2160	0300 0274 32	24	Plain washer	
2142	1619 2766 02	4	Paint stripping bolt		2165	0211 1247 03	24	Hex sock. screw	
2145	1621 5747 00	4	Profile		3050	1619 2766 00	6	Paint stripping bolt	
2150	1621 5748 00	4	Profile		4010	1621 2538 00	24	Hinge	
2155	1621 2544 00	8	Profile		4020	1619 2766 00	1	Paint stripping bolt	
2160	0300 0274 32	24	Plain washer		4040	1619 2766 00	2	Paint stripping bolt	
2165	0211 1247 03	24	Hex sock. screw		4045	9096 4568 00	2	Panel	
3050	1619 2766 00	6	Paint stripping bolt		4050	1079 1472 05	4	Screw	
4010	1621 2538 00	24	Hinge		4055	9096 4234 10	3	End panel	
4020	1619 2766 00	1	Paint stripping bolt		4071	0300 0274 94	8	Plain washer	
4040	1619 2766 00	2	Paint stripping bolt		5005	9096 4569 00	8	Door	
4045	9096 4568 00	2	Panel		5010	9096 4569 11	1	Door	
4050	1079 1472 05	4	Screw		5013	9096 4569 10	2	Door	
4055	9096 4234 10	3	End panel		5015	1621 0607 00	26	Pin	
4071	0300 0274 94	8	Plain washer		5020	1089 9068 01	1	Key	
					5025	0160 6105 00	4	Screw	
					5030	0160 6105 00	16	Screw	
					5035	0298 1000 25	3	Nut	
					5040	0147 1334 00	2	Hex.bolt	
					5045	0261 1107 00	4	Nut	
					6005	1619 2795 00	AR	Rubber strip	



**Bodywork ZR - Doors and Stays****31**

<b>Ref.</b>	<b>Part number</b>	<b>Qty</b>	<b>Name</b>	<b>Remarks</b>	<b>Ref.</b>	<b>Part number</b>	<b>Qty</b>	<b>Name</b>	<b>Remarks</b>
			<b>Kit-decal</b>						
7005	0690 1140 01	2	House mark		7030	1621 0478 00	1	Lable	
7010	1079 3301 29	5	Lable		7035	1079 9923 72	2	Lable	
7015	1079 9923 88	6	Lable		7040	1088 1001 04	2	Warning mark	
7020	1079 9922 35	1	Decal		7045	1079 9913 79	1	Inform. Lable	
7025	1079 9922 36	1	Decal		7050	1079 9913 69	2	Inform. Lable	
					7055	1079 9901 67	1	Lable	



## Bodywork ZT - Doors and Stays

Ref.	Partnumber	Qty	Name	Remarks	Ref.	Partnumber	Qty	Name	Remarks
			ZT160 7.5 bar(e)		1230	9096 4569 00	10	Door	
			160KW,3.3KV S		1235	9096 4569 10	1	Door	
			ZT160 8.6 bar(e)		1240	9096 4569 11	2	Door	
			160KW,3.3KV S		1245	9096 4569 13	3	Door	
			ZT160 10 bar(e)		1250	1621 2854 00	2	Bracket	
			160KW,3.3KV S		1255	1621 3333 00	1	Tran.Bracket	
			ZT200 7.5 bar(e)		1260	0211 1247 03	24	Hex socket Screw	
			200KW,3.3KV S		1265	0147 1320 03	2	Hex.bolt	
			ZT200 8.6 bar(e)		1270	1621 9438 01	12	Pin	
			200KW,3.3KV S					ZT250 7.5 bar(e)	
			ZT 200 10 bar(e)					250KW,6.6KV S	
			200KW,3.3KV S					ZT250 8.6 bar(e)	
			ZT250 7.5 bar(e)					250KW,6.6KV S	
			250KW,3.3KV S					ZT250 10 bar(e)	
			ZT250 8.6 bar(e)					250KW,6.6KV S	
			250KW,3.3KV S					ZT 275 7.5 bar(e)	
			ZT250 10 bar(e)					275KW,6.6KV S	
			250KW,3.3KV S					ZT275 8.6 bar(e)	
1005	9096 4351 10	1	Frame					275KW,3.3KV S	
1010	9096 4753 00	1	Stay					ZT275 8.6 bar(e)	
1015	9096 4752 00	1	Stay					275KW,6.6KV S	
1020	9096 4751 00	1	Stay					ZT275 10 bar(e)	
1025	1621 2864 00	2	Stay					275KW,3.3KV S	
1030	9096 4754 00	1	Stay					ZT275 10 bar(e)	
1035	1621 2865 00	1	Support					275KW,6.6KV S	
1040	1621 4246 00	1	Plate		1005	9096 4351 10	1	Frame	
1045	1621 2866 00	1	Stay		1010	9096 4753 00	1	Stay	
1050	1621 4250 00	1	Plate		1015	9096 4752 00	1	Stay	
1055	1621 2632 00	2	Plate		1020	9096 4751 00	1	Stay	
1060	9096 4242 00	2	Beam		1025	1621 2864 00	2	Stay	
1065	9096 4243 10	1	End Panel		1030	9096 4754 00	1	Stay	
1070	9096 4235 10	1	End Panel		1035	1621 2865 00	1	Support	
1075	9096 4233 10	1	End Panel		1040	1621 4246 00	1	Plate	
1080	9096 4244 00	1	End Panel		1045	1621 2866 00	1	Stay	
1085	9096 4567 50	1	Roof		1050	1621 4250 00	1	Plate	
1090	9096 4582 00	1	Roof		1055	1621 2632 00	2	Plate	
1095	9096 4606 00	1	Roof		1060	9096 4242 00	2	Beam	
1100	9096 4750 00	1	Roof		1065	9096 4243 10	1	End Panel	
1105	1621 2853 00	1	Baffle		1070	9096 4235 10	1	End Panel	
1110	1621 2852 00	1	Baffle		1075	9096 4233 10	1	End Panel	
1115	1621 5747 00	4	Profile		1080	9096 4244 00	1	End Panel	
1120	1621 5748 00	4	Profile		1085	9096 4567 50	1	Roof	
1125	1621 2544 00	8	Profile		1090	9096 4582 00	1	Roof	
1130	0300 0274 32	24	Plain washer		1095	9096 4606 00	1	Roof	
1135	9096 4245 10	1	End Panel		1100	9096 4750 00	1	Roof	
1140	9096 4628 00	4	Stay		1105	1621 2853 00	1	Baffle	
1145	1621 2701 00	4	Plate		1110	1621 2852 00	1	Baffle	
1150	9096 4246 10	1	End Panel		1115	1621 5747 00	4	Profile	
1155	1621 2550 00	12	Pin		1120	1621 5748 00	4	Profile	
1160	0581 0000 86	5	Pipe coupling		1125	1621 2544 00	8	Profile	
1165	1621 2477 00	1	Stay		1130	0300 0274 32	24	Plain washer	
1170	1621 2478 00	1	Stay		1135	9096 4245 10	1	End Panel	
1175	9096 4232 10	4	Beam		1140	9096 4628 00	4	Stay	
1177	9096 4232 50	2	Beam		1145	1621 2701 00	4	Plate	
1180	9096 4234 10	2	End Panel		1150	9096 4246 10	1	End Panel	
1185	9096 4569 14	1	Door		1155	1621 2550 00	12	Pin	
1190	1621 0607 00	36	Pin		1160	0581 0000 86	5	Pipe coupling	
1195	1089 9068 01	1	Key		1165	1621 2477 00	1	Stay	
1200	1202 6584 00	AR	Seal		1170	1621 2478 00	1	Stay	
1205	0147 1400 03	12	Hex. head screw		1175	9096 4232 10	4	Beam	
1210	9096 4579 00	6	Stay		1177	9096 4232 50	2	Beam	
1215	1619 2766 00	70	Paint stripping bolt		1180	9096 4234 10	2	End Panel	
1220	1621 2538 00	34	Hinge		1185	9096 4569 14	1	Door	
1225	9096 4568 00	1	Panel		1190	1621 0607 00	36	Pin	



## Bodywork ZT - Doors and Stays

Ref.	Partnumber	Qty	Name	Remarks	Ref.	Partnumber	Qty	Name	Remarks
1195	1089 9068 01	1	Key		1230	9096 4569 00	10	Door	
1200	1202 6584 00	AR	Seal		1235	9096 4569 10	1	Door	
1205	0147 1400 03	12	Hex. head screw		1240	9096 4569 11	2	Door	
1210	9096 4579 00	6	Stay		1245	9096 4569 13	3	Door	
1215	1619 2766 00	70	Paint stripping bolt		1250	1621 2854 00	2	Bracket	
1220	1621 2538 00	34	Hinge		1255	1621 3333 00	1	Tran.Bracket	
1225	9096 4568 00	1	Panel		1260	0211 1247 03	24	Hex socket Screw	
1230	9096 4569 00	10	Door		1265	0147 1320 03	2	Hex.bolt	
1235	9096 4569 10	1	Door		1270	1621 9438 01	12	Pin	
1240	9096 4569 11	2	Door					ZT160 7.5 bar(e)	
1245	9096 4569 13	3	Door					160KW,6.6KV S	
1250	1621 2854 00	2	Bracket					ZT160 8.6 bar(e)	
1255	1621 3333 00	1	Tran.Bracket					160KW,6.6KV S	
1260	0211 1247 03	24	Hex socket Screw					ZT160 10 bar(e)	
1265	0147 1320 03	2	Hex.bolt					160KW,6.6KV S	
1270	1621 9438 01	12	Pin					ZT200 7.5 bar(e)	
								200KW,6.6KV S	
								ZT200 8.6 bar(e)	
								200KW,6.6KV S	
								ZT200 10 bar(e)	
								200KW,6.6KV S	
1005	9096 4351 10	1	Frame		1005	9096 4351 10	1	Frame	
1010	9096 4753 00	1	Stay		1010	9096 4753 00	1	Stay	
1015	9096 4752 00	1	Stay		1015	9096 4752 00	1	Stay	
1020	9096 4751 00	1	Stay		1020	9096 4751 00	1	Stay	
1025	1621 2864 00	2	Stay		1025	1621 2864 00	2	Stay	
1030	9096 4754 00	1	Stay		1030	9096 4754 00	1	Stay	
1035	1621 2865 00	1	Support		1035	1621 2865 00	1	Support	
1040	1621 4246 00	1	Plate		1040	1621 4246 00	1	Plate	
1045	1621 2866 00	1	Stay		1045	1621 2866 00	1	Stay	
1050	1621 4250 00	1	Plate		1050	1621 4250 00	1	Plate	
1055	1621 2632 00	2	Plate		1055	1621 2632 00	2	Plate	
1060	9096 4242 00	2	Beam		1060	9096 4242 00	2	Beam	
1065	9096 4243 10	1	End Panel		1065	9096 4243 10	1	End Panel	
1070	9096 4235 10	1	End Panel		1070	9096 4235 10	1	End Panel	
1075	9096 4233 10	1	End Panel		1075	9096 4233 10	1	End Panel	
1080	9096 4244 00	1	End Panel		1080	9096 4244 00	1	End Panel	
1085	9096 4567 50	1	Roof		1085	9096 4567 50	1	Roof	
1090	9096 4582 00	1	Roof		1090	9096 4582 00	1	Roof	
1095	9096 4606 00	1	Roof		1095	9096 4606 00	1	Roof	
1100	9096 4750 00	1	Roof		1100	9096 4750 00	1	Roof	
1105	1621 2853 00	1	Baffle		1105	1621 2853 00	1	Baffle	
1110	1621 2852 00	1	Baffle		1110	1621 2852 00	1	Baffle	
1115	1621 5747 00	4	Profile		1115	1621 5747 00	4	Profile	
1120	1621 5748 00	4	Profile		1120	1621 5748 00	4	Profile	
1125	1621 2544 00	8	Profile		1125	1621 2544 00	8	Profile	
1130	0300 0274 32	24	Plain washer		1130	0300 0274 32	24	Plain washer	
1135	9096 4245 10	1	End Panel		1135	9096 4245 10	1	End Panel	
1140	9096 4628 00	4	Stay		1140	9096 4628 00	4	Stay	
1145	1621 2701 00	4	Plate		1145	1621 2701 00	4	Plate	
1150	9096 4246 10	1	End Panel		1150	9096 4246 10	1	End Panel	
1155	1621 2550 00	12	Pin		1155	1621 2550 00	12	Pin	
1160	0581 0000 86	5	Pipe coupling		1160	0581 0000 86	5	Pipe coupling	
1165	1621 2477 00	1	Stay		1165	1621 2477 00	1	Stay	
1170	1621 2478 00	1	Stay		1170	1621 2478 00	1	Stay	
1175	9096 4232 10	4	Beam		1175	9096 4232 10	4	Beam	
1177	9096 4232 50	2	Beam		1177	9096 4232 50	2	Beam	
1180	9096 4234 10	2	End Panel		1180	9096 4234 10	2	End Panel	
1185	9096 4569 14	1	Door		1185	9096 4569 14	1	Door	
1190	1621 0607 00	36	Pin		1190	1621 0607 00	36	Pin	
1195	1089 9068 01	1	Key		1195	1089 9068 01	1	Key	
1200	1202 6584 00	AR	Seal		1200	1202 6584 00	AR	Seal	
1205	0147 1400 03	12	Hex. head screw		1205	0147 1400 03	12	Hex. head screw	
1210	9096 4579 00	6	Stay		1210	9096 4579 00	6	Stay	
1215	1619 2766 00	70	Paint stripping bolt						
1220	1621 2538 00	34	Hinge						
1225	9096 4568 00	1	Panel						



## Bodywork ZT - Doors and Stays

32

Ref.	Partnumber	Qty	Name	Remarks	Ref.	Partnumber	Qty	Name	Remarks
1215	1619 2766 00	70	Paint stripping bolt		1270	1621 9438 01	12	Pin	
1220	1621 2538 00	34	Hinge					<b>Kit-decal</b>	
1225	9096 4568 00	1	Panel		2005	0690 1140 01	2	House mark	
1230	9096 4569 00	10	Door		2010	1079 9901 29	9	Lable	
1235	9096 4569 10	1	Door		2015	1079 9901 67	1	Lable	
1240	9096 4569 11	2	Door		2020	1079 9901 35	1	Decal	
1245	9096 4569 13	3	Door		2025	1079 9922 36	1	Decal	
1250	1621 2854 00	2	Bracket		2030	1079 9923 72	2	Lable	
1255	1621 3333 00	1	Tran.Bracket		2035	1079 9923 88	10	Lable	
1260	0211 1247 03	24	Hex socket Screw		2040	1621 0478 00	1	Lable	
1265	0147 1320 03	2	Hex.bolt						








## Electrical kit starter

Ref.	Partnumber	Qty	Name	Remarks	Ref.	Partnumber	Qty	Name	Remarks
	9096 4183 32	• 7.5	Power cable			9096 4183 21	• 1	Copper busbar with hardware	
	9096 4183 33	• 6.5	Power cable			9096 4183 22	• 6	Epoxy busbar support	
	9096 4183 34	• 4.5	Power cable			9096 4183 23	• 34	Terminal	
	9096 4183 35	• 4	Power cable			9096 4183 24	• 4	Earthing terminal	
	9096 4183 36	• 6	Earth cable			9096 4183 25	• 3	End clamp	
	9096 4183 37	• 1	Acrylic shourding set			9096 4183 26	• 11	End plate dd	
	1621 2232 00	• 1	Base plate for panel			9096 4183 27	• 171	Control cable	
	9096 4183 39	• 1	Consumable set			9096 4183 28	• 14.5	Control cable	
	9096 4183 40	• 2	Earth bolt			9096 4183 29	• 6	Control cable	
	9096 4183 41	• 2	Din rail channel			9096 4183 30	• 18.5	Control cable	
	9096 4183 42	• 4	Pvc channel			9096 4183 31	• 3	Control cable	
	9096 4183 43	• 1	Pvc channel			9096 4183 32	• 7.5	Power cable	
	9096 4183 44	• 1	Label set			9096 4183 33	• 6.5	Power cable	
1010	9096 4255 51	• 1	Service diagram			9096 4183 34	• 4.5	Power cable	
	9096 4183 46	• 1	Fan for cubical			9096 4183 35	• 4	Power cable	
	9096 4183 47	• 1	Filter			9096 4183 36	• 6	Earth cable	
	9096 4183 48	• 1	Din rail channel			9096 4183 37	• 1	Acrylic shourding set	
	9096 4183 23	• 10	Terminal			1621 2232 00	• 1	Base plate for panel	
	9096 4183 25	• 6	End clamp			9096 4183 39	• 1	Consumable set	
	9096 4183 26	• 5	End plate			9096 4183 40	• 2	Earth bolt	
	1621 4226 01	• 2	Label			9096 4183 41	• 2	Din rail channel	
	9096 4423 00	• 1	Temp.scanner			9096 4183 42	• 4	Pvc channel	
			ZR250 7.5 bar(e) 300KW/ 3.3KVO			9096 4183 43	• 1	Pvc channel	
			ZR250 7.5 bar(e) 300KW/ 6.6KVO		1010	9096 4183 44	• 1	Label set	
			ZR250 7.5 bar(e) 320KW/ 3.3KVO			9096 4255 51	• 1	Service diagram	
			ZR250 7.5 bar(e) 320KW/ 6.6KVO			9096 4183 46	• 1	Fan for cubical	
			ZR250 8.6 bar(e) 280KW/ 3.3KVO			9096 4183 47	• 1	Filter	
			ZR250 8.6 bar(e) 280KW/ 6.6KVO			9096 4183 48	• 1	Din rail channel	
			ZR250 8.6 bar(e) 300KW/ 3.3KVO			9096 4183 23	• 10	Terminal	
			ZR250 8.6 bar(e) 300KW/ 6.6KVO			9096 4183 25	• 6	End clamp	
			ZR250 10 bar(e) 255KW/ 3.3KVO			9096 4183 26	• 5	End plate dd	
			ZR250 10 bar(e) 255KW/ 6.6KVO			1621 4226 02	• 2	Label	
			ZR250 10 bar(e) 280KW/ 3.3KVO			9096 4423 00	• 1	Temp.scanner	
			ZR250 10 bar(e) 280KW/ 6.6KVO					ZR275 7.5 bar(e) 320KW/ 3.3KVO	
			<b>Zr250 modular pack complete</b>					ZR275 7.5 bar(e) 320KW/ 6.6KVO	
			<b>C.panel w/o starter</b>					ZR275 7.5 bar(e) 345KW/ 3.3KVO	
	9096 4961 00	• 1	Ac contactor					ZR275 7.5 bar(e) 345KW/ 6.6KVO	
	9096 4183 03	• 1	Aux. Contactor			9096 4961 00	• 1	<b>Zr275 modular pack complete</b>	
	9096 4183 04	• 1	Aux. Contactor			9096 4183 03	• 1	<b>C.panel w/o starter</b>	
	9096 4183 56	• 2	Ac contactor			9096 4183 04	• 1	Ac contactor	
	9096 4183 56	• 2	Ac contactor			9096 4183 56	• 2	Aux. Contactor	
	9096 4183 07	• 2	Aux relay			9096 4183 56	• 2	Ac contactor	
	9096 4183 57	• 4	Addon block			9096 4183 56	• 2	Aux relay	
	9096 4183 10	• 1	Transformer			9096 4183 07	• 2	Aux relay	
	9096 4183 11	• 1	Transformer			9096 4183 57	• 4	Addon block	
	9096 4183 12	• 1	Transformer			9096 4183 10	• 1	Transformer	
	9096 4183 58	• 2	Timer pod			9096 4183 11	• 1	Transformer	
	9096 4183 13	• 2	Mcb-1p,			9096 4183 12	• 1	Transformer	
	9096 4183 15	• 3	Mcb-1p,			9096 4183 58	• 2	Timer pod	
	9096 4183 18	• 1	Emergency stop			9096 4183 13	• 2	Mcb-1p,	
	9096 4183 19	• 3	Nc element			9096 4183 15	• 3	Mcb-1p,	
	9096 4183 20	• 1	Wago connector set			9096 4183 18	• 1	Emergency stop	
						9096 4183 19	• 3	Nc element	
						9096 4183 20	• 1	Wago connector set	
						9096 4183 21	• 1	Copper busbar with hardware	
						9096 4183 22	• 6	Epoxy busbar support	
						9096 4183 23	• 34	Terminal	
						9096 4183 24	• 4	Earthing terminal	
						9096 4183 25	• 3	End clamp	


33



## Electrical kit starter

Ref.	Partnumber	Qty	Name	Remarks	Ref.	Partnumber	Qty	Name	Remarks
	9096 4183 26	• 11	End plate dd			9096 4183 22	• 6	Epoxy busbar support	
	9096 4183 27	• 171	Control cable			9096 4183 23	• 44	Terminal	
	9096 4183 28	• 14.5	Control cable			9096 4183 49	• 3	Power terminal	
	9096 4183 29	• 6	Control cable			9096 4183 50	• 3	Power terminal	
	9096 4183 30	• 18.5	Control cable			9096 4183 51	• 2	Power terminal	
	9096 4183 31	• 3	Control cable			9096 4183 24	• 4	Earthing terminal	
	9096 4183 32	• 7.5	Power cable			9096 4183 25	• 3	End clamp	
	9096 4183 33	• 6.5	Power cable			9096 4183 26	• 11	End plate dd	
	9096 4183 34	• 4.5	Power cable			9096 4183 27	• 180	Control cable	
	9096 4183 35	• 4	Power cable			9096 4183 28	• 14.5	Control cable	
	9096 4183 36	• 6	Earth cable			9096 4183 29	• 6	Control cable	
	9096 4183 37	• 1	Acrylic shourding set			9096 4183 30	• 21	Control cable	
	1621 2232 00	• 1	Base plate for panel			9096 4183 31	• 3	Control cable	
	9096 4183 39	• 1	Consumable set			9096 4183 32	• 12.5	Power cable	
	9096 4183 40	• 2	Earth bolt			9096 4183 33	• 11.5	Power cable	
	9096 4183 41	• 2	Din rail channel			9096 4183 34	• 9.5	Power cable	
	9096 4183 42	• 4	Pvc channel			9096 4183 35	• 2	Power cable	
	9096 4183 43	• 1	Pvc channel			9096 4183 36	• 6	Earth cable	
	9096 4183 44	• 1	Label set			9096 4183 37	• 1	Acrylic shourding set	
1010	9096 4255 51	• 1	Service diagram			9096 5158 00	• 0	Base plate	
	9096 4183 46	• 1	Fan for cubical			9096 4183 39	• 1	Consumable	
	9096 4183 47	• 1	Filter			9096 4183 40	• 2	Earth bolt	
	9096 4183 48	• 1	Din rail channel			9096 4183 41	• 2	Din rail channel	
	9096 4183 23	• 10	Terminal			9096 4183 42	• 4	Pvc channel	
	9096 4183 25	• 6	End clamp			9096 4183 43	• 1	Packing box	
	9096 4183 26	• 5	End plate dd			9096 4183 44	• 1	Label set	
	1621 4226 03	• 2	Lable zr275		1010	9096 4255 51	• 1	Service diagram	
	9096 4423 00	• 1	Temp.scanner			9096 4183 46	• 1	Fan for cubical	
			ZT160 7.5 bar(e)			9096 4183 47	• 1	Filter	
			160KW,3.3KV S			9096 4183 48	• 1	Din rail channel	
			ZT160 7.5 bar(e)			9096 4183 25	• 6	End clamp	
			160KW,6.6KV S			9096 4183 26	• 5	End plate dd	
			ZT160 8.6 bar(e)			9096 5039 00	• 1	Earthing cable	
			160KW,3.3KV S			9096 5095 00	• 1	Wire harness	
			ZT160 10 bar(e)			1621 4226 12	• 2	Lable zt160	
			160KW,3.3KV S			9096 4423 00	• 1	Temp.scanner w/cables-	
			ZT160 8.6 bar(e)					masubus	
			160KW,6.6KV S			9096 4010 00	• 1	Kit-decal zt 160 275 pack	
			ZT160 10 bar(e)					ZT200 7.5 bar(e)	
			160KW,6.6KV S					200KW,3.3KV S	
			<b>Zt160 modular pack</b>					ZT200 7.5 bar(e)	
			<b>complete</b>					200KW,6.6KV S	
	<b>9096 4962 00</b>	<b>1</b>	<b>Kit starter w/0 starter</b>					ZT200 8.6 bar(e)	
	9096 4183 03	• 1	Ac contactor					200KW,3.3KV S	
	9096 4183 04	• 1	Aux. Contactor					ZT200 8.6 bar(e)	
	9096 4183 56	• 2	Relay					200KW,6.6KV S	
	9096 4183 56	• 2	Ac contactor-					ZT200 10 bar(e)	
	9096 4183 07	• 2	Aux relay					200KW,6.6KV S	
	9096 4183 57	• 4	Addon block					ZT 200 10 bar(e)	
	9096 4183 58	• 2	Timer pod					200KW,3.3KV S	
	9096 4183 03	• 2	Ac contactor					<b>Zt200 modular pack</b>	
	9096 4183 07	• 2	Aux relay					<b>complete</b>	
	9096 4184 03	• 2	Biametal overload relay			<b>9096 4962 00</b>	<b>1</b>	<b>Kit starter w/0 starter</b>	
	9096 4183 10	• 1	Transformer			9096 4183 03	• 1	Ac contactor	
	9096 4183 11	• 1	Transformer			9096 4183 04	• 1	Aux. Contactor	
	9096 4183 12	• 1	Transformer			9096 4183 56	• 2	Relay	
	9096 4183 13	• 2	Mcb-1p			9096 4183 56	• 2	Ac contactor-	
	9096 4183 15	• 3	Mcb-1p			9096 4183 07	• 2	Aux relay	
	9096 4183 16	• 3	Hrc fuse base			9096 4183 57	• 4	Addon block	
	9096 4183 17	• 3	Hrc fuse base			9096 4183 58	• 2	Timer pod	
	9096 4183 18	• 1	Emergency stop pb			9096 4183 03	• 2	Ac contactor	
	9096 4183 19	• 3	Nc element			9096 4183 07	• 2	Aux relay	
	9096 4183 20	• 1	Wago connector set			9096 4184 03	• 2	Biametal overload relay	
	9096 4183 21	• 1	Copper busbar with hardware			9096 4183 10	• 1	Transformer	

33



## Electrical kit starter

Ref.	Partnumber	Qty	Name	Remarks	Ref.	Partnumber	Qty	Name	Remarks
	9096418311	• 1	Transformer			9096418356	• 2	Ac contactor-	
	9096418312	• 1	Transformer			9096418307	• 2	Aux relay	
	9096418313	• 2	Mcb-1p			9096418357	• 4	Addon block	
	9096418315	• 3	Mcb-1p			9096418358	• 2	Timer pod	
	9096418316	• 3	Hrc fuse base			9096418303	• 2	Ac contactor	
	9096418317	• 3	Hrc fuse base			9096418307	• 2	Aux relay	
	9096418318	• 1	Emergency stop pb			9096418403	• 2	Biametal overload relay	
	9096418319	• 3	Nc element			9096418310	• 1	Transformer	
	9096418320	• 1	Wago connector set			9096418311	• 1	Transformer	
	9096418321	• 1	Copper busbar with hardware			9096418312	• 1	Transformer	
	9096418322	• 6	Epoxy busbar support			9096418313	• 2	Mcb-1p	
	9096418323	• 44	Terminal			9096418315	• 3	Mcb-1p	
	9096418349	• 3	Power terminal			9096418316	• 3	Hrc fuse base	
	9096418350	• 3	Power terminal			9096418317	• 3	Hrc fuse base	
	9096418351	• 2	Power terminal			9096418318	• 1	Emergency stop pb	
	9096418324	• 4	Earthing terminal			9096418319	• 3	Nc element	
	9096418325	• 3	End clamp			9096418320	• 1	Wago connector set	
	9096418326	• 11	End plate dd			9096418321	• 1	Copper busbar with hardware	
	9096418327	• 180	Control cable			9096418322	• 6	Epoxy busbar support	
	9096418328	• 14.5	Control cable			9096418323	• 44	Terminal	
	9096418329	• 6	Control cable			9096418349	• 3	Power terminal	
	9096418330	• 21	Control cable			9096418350	• 3	Power terminal	
	9096418331	• 3	Control cable			9096418351	• 2	Power terminal	
	9096418332	• 12.5	Power cable			9096418324	• 4	Earthing terminal	
	9096418333	• 11.5	Power cable			9096418325	• 3	End clamp	
	9096418334	• 9.5	Power cable			9096418326	• 11	End plate dd	
	9096418335	• 2	Power cable			9096418327	• 180	Control cable	
	9096418336	• 6	Earth cable			9096418328	• 14.5	Control cable	
	9096418337	• 1	Acrylic shourding set			9096418329	• 6	Control cable	
	9096515800	• 0	Base plate			9096418330	• 21	Control cable	
	9096418339	• 1	Consumable			9096418331	• 3	Control cable	
	9096418340	• 2	Earth bolt			9096418332	• 12.5	Power cable	
	9096418341	• 2	Din rail channel			9096418333	• 11.5	Power cable	
	9096418342	• 4	Pvc channel			9096418334	• 9.5	Power cable	
	9096418343	• 1	Packing box			9096418335	• 2	Power cable	
	9096418344	• 1	Label set			9096418336	• 6	Earth cable	
1010	9096425551	• 1	Service diagram			9096418337	• 1	Acrylic shourding set	
	9096418346	• 1	Fan for cubical			9096515800	• 0	Base plate	
	9096418347	• 1	Filter			9096418339	• 1	Consumable	
	9096418348	• 1	Din rail channel			9096418340	• 2	Earth bolt	
	9096418325	• 6	End clamp			9096418341	• 2	Din rail channel	
	9096418326	• 5	End plate dd			9096418342	• 4	Pvc channel	
	9096503900	• 1	Earthing cable			9096418343	• 1	Packing box	
	9096509500	• 1	Wire harness			9096418344	• 1	Label set	
	1621422613	• 2	Lable		1010	9096425551	• 1	Service diagram	
	9096442300	• 1	Temp.scanner			9096418346	• 1	Fan for cubical	
			ZT250 7.5 bar(e)			9096418347	• 1	Filter	
			250KW,3.3KV S			9096418348	• 1	Din rail channel	
			ZT250 7.5 bar(e)			9096418325	• 6	End clamp	
			250KW,6.6KV S			9096418326	• 5	End plate dd	
			ZT250 8.6 bar(e)			9096503900	• 1	Earthing cable	
			250KW,3.3KV S			9096509500	• 1	Wire harness	
			ZT250 8.6 bar(e)			1621422614	• 2	Lable	
			250KW,6.6KV S			9096442300	• 1	Temp.scanner	
			ZT250 10 bar(e)					ZT275 7.5 bar(e)	
			250KW,3.3KV S					275KW,3.3KV S	
			ZT250 10 bar(e)					ZT 275 7.5 bar(e)	
			250KW,6.6KV S					ZT275 8.6 bar(e)	
			<b>Zt250 modular pack</b>					275KW,3.3KV S	
			<b>complete</b>					ZT275 8.6 bar(e)	
	<b>9096 4962 00</b>	<b>1</b>	<b>Kit starter w/0 starter</b>					275KW,6.6KV S	
	9096418303	• 1	Ac contactor					ZT275 10 bar(e)	
	9096418304	• 1	Aux. Contactor					275KW,3.3KV S	
	9096418356	• 2	Relay						



## Electrical kit starter

33

Ref.	Partnumber	Qty	Name	Remarks	Ref.	Partnumber	Qty	Name	Remarks
			ZT275 10 bar(e) 275KW,6.6KV S			9096 4183 24	• 4	Earthing terminal	
			<b>Zt275 modular pack complete</b>			9096 4183 25	• 3	End clamp	
	<b>9096 4962 00</b>	<b>1</b>	<b>Kit starter w/0 starter</b>			9096 4183 26	• 11	End plate dd	
	9096 4183 03	• 1	Ac contactor			9096 4183 27	• 180	Control cable	
	9096 4183 04	• 1	Aux. Contactor			9096 4183 28	• 14.5	Control cable	
	9096 4183 56	• 2	Relay			9096 4183 29	• 6	Control cable	
	9096 4183 56	• 2	Ac contactor-			9096 4183 30	• 21	Control cable	
	9096 4183 07	• 2	Aux relay			9096 4183 31	• 3	Control cable	
	9096 4183 57	• 4	Addon block			9096 4183 32	• 12.5	Power cable	
	9096 4183 58	• 2	Timer pod			9096 4183 33	• 11.5	Power cable	
	9096 4183 03	• 2	Ac contactor			9096 4183 34	• 9.5	Power cable	
	9096 4183 07	• 2	Aux relay			9096 4183 35	• 2	Power cable	
	9096 4184 03	• 2	Biametal overload relay			9096 4183 36	• 6	Earth cable	
	9096 4183 10	• 1	Transformer			9096 4183 37	• 1	Acrylic shourding set	
	9096 4183 11	• 1	Transformer			9096 5158 00	• 0	Base plate	
	9096 4183 12	• 1	Transformer			9096 4183 39	• 1	Consumable	
	9096 4183 13	• 2	Mcb-1p			9096 4183 40	• 2	Earth bolt	
	9096 4183 15	• 3	Mcb-1p			9096 4183 41	• 2	Din rail channel	
	9096 4183 16	• 3	Hrc fuse base			9096 4183 42	• 4	Pvc channel	
	9096 4183 17	• 3	Hrc fuse base			9096 4183 43	• 1	Packing box	
	9096 4183 18	• 1	Emergency stop pb		1010	9096 4183 44	• 1	Label set	
	9096 4183 19	• 3	Nc element			9096 4255 51	• 1	Service diagram	
	9096 4183 20	• 1	Wago connector set			9096 4183 46	• 1	Fan for cubical	
	9096 4183 21	• 1	Copper busbar with hardware			9096 4183 47	• 1	Filter	
	9096 4183 22	• 6	Epoxy busbar support			9096 4183 48	• 1	Din rail channel	
	9096 4183 23	• 44	Terminal			9096 4183 25	• 6	End clamp	
	9096 4183 49	• 3	Power terminal			9096 4183 26	• 5	End plate dd	
	9096 4183 50	• 3	Power terminal			9096 5039 00	• 1	Earthing cable	
	9096 4183 51	• 2	Power terminal			9096 5095 00	• 1	Wire harness	
						1621 4226 15	2	Lable	
						9096 4423 00	1	Temp.scanner	

# 34

## Vci packing kit

Ref.	Partnumber	Qty	Name	Remarks	Ref.	Partnumber	Qty	Name	Remarks
			ZR160 7.5 bar(e) 190KW/ 3.3KVO					ZR250 7.5 bar(e) 320KW/ 6.6KVO	
			ZR160 7.5 bar(e) 190KW/ 6.6KVO					ZR250 8.6 bar(e) 280KW/ 3.3KVO	
			ZR160 7.5 bar(e) 200KW/ 3.3KVO					ZR250 8.6 bar(e) 280KW/ 6.6KVO	
			ZR160 7.5 bar(e) 200KW/ 6.6KVO					ZR250 8.6 bar(e) 300KW/ 3.3KVO	
			ZR160 8.6 bar(e) 175KW/ 3.3KVO					ZR250 8.6 bar(e) 300KW/ 6.6KVO	
			ZR160 8.6 bar(e) 175KW/ 6.6KVO					ZR250 10 bar(e) 255KW/ 3.3KVO	
			ZR160 8.6 bar(e) 190KW/ 3.3KVO					ZR250 10 bar(e) 255KW/ 6.6KVO	
			ZR160 8.6 bar(e) 190KW/ 6.6KVO					ZR250 10 bar(e) 280KW/ 3.3KVO	
			ZR160 10 bar(e) 165KW/ 3.3KVO					ZR250 10 bar(e) 280KW/ 6.6KVO	
			ZR160 10 bar(e) 165KW/ 6.6KVO					ZR275 7.5 bar(e) 320KW/ 3.3KVO	
			ZR160 10 bar(e) 175KW/ 3.3KVO					ZR275 7.5 bar(e) 320KW/ 6.6KVO	
			ZR200 7.5 bar(e) 240KW/ 3.3KVO					ZR275 7.5 bar(e) 345KW/ 3.3KVO	
			ZR200 7.5 bar(e) 240KW/ 6.6KVO					ZR275 7.5 bar(e) 345KW/ 6.6KVO	
			ZR200 7.5 bar(e) 255KW/ 3.3KVO		9096 5159 20	1		<b>Vci packing kit</b>	
			ZR200 7.5 bar(e) 255KW/ 6.6KVO		9096 9019 27	5		Partlist	
			ZR200 8.6 bar(e) 220KW/ 3.3KVO		9096 5300 00	1		Dhf 555	
			ZR200 8.6 bar(e) 220KW/ 6.6KVO		9096 5300 10	1		Kit a	
			ZR200 8.6 bar(e) 240KW/ 3.3KVO					Kit b	
			ZR200 8.6 bar(e) 240KW/ 6.6KVO					ZT160 7.5 bar(e) 160KW,3.3KVS	
			ZR200 8.6 bar(e) 240KW/ 3.3KVO					ZT160 7.5 bar(e) 160KW,6.6KVS	
			ZR200 8.6 bar(e) 240KW/ 6.6KVO					ZT160 8.6 bar(e) 160KW,3.3KVS	
			ZR200 8.6 bar(e) 240KW/ 6.6KVO					ZT160 8.6 bar(e) 160KW,6.6KVS	
			ZR200 10 bar(e) 200KW/ 3.3KVO					ZT160 10 bar(e) 160KW,3.3KVS	
			ZR200 10 bar(e) 200KW/ 6.6KVO					ZT160 10 bar(e) 160KW,6.6KVS	
			ZR200 10 bar(e) 220KW/ 3.3KVO					ZT200 7.5 bar(e) 200KW,3.3KVS	
			ZR200 10 bar(e) 220KW/ 6.6KVO					ZT200 7.5 bar(e) 200KW,6.6KVS	
			ZR250 7.5 bar(e) 300KW/ 3.3KVO					ZT200 8.6 bar(e) 200KW,3.3KVS	
			ZR250 7.5 bar(e) 300KW/ 6.6KVO					ZT200 8.6 bar(e) 200KW,6.6KVS	
			ZR250 7.5 bar(e) 320KW/ 3.3KVO					ZT 200 10 bar(e) 200KW,3.3KVS	

# 34

**Vci packing kit**

34

Ref.	Partnumber	Qty	Name	Remarks	Ref.	Partnumber	Qty	Name	Remarks
			ZT200 10 bar(e)					ZT 275 7.5 bar(e)	
			200KW,6.6KV S					275KW,6.6KV S	
			ZT250 7.5 bar(e)					ZT275 8.6 bar(e)	
			250KW,3.3KV S					275KW,3.3KV S	
			ZT250 7.5 bar(e)					ZT275 8.6 bar(e)	
			250KW,6.6KV S					275KW,6.6KV S	
			ZT250 8.6 bar(e)					ZT275 10 bar(e)	
			250KW,3.3KV S					275KW,3.3KV S	
			ZT250 8.6 bar(e)					ZT275 10 bar(e)	
			250KW,6.6KV S					275KW,6.6KV S	
			ZT250 10 bar(e)					<b>Vci packing kit</b>	
			250KW,3.3KV S		9096 5300 60	1		Kit a	
			ZT250 10 bar(e)		9096 5300 70	1		Kit b	
			250KW,6.6KV S		9096 9019 27	5		Dhf 555	
			ZT275 7.5 bar(e)		9096 5159 30	1		Partlist	
			275KW,3.3KV S		2908 8500 00	0.07		Roto	







**Atlas Copco** Stationary Air Compressors  
ZR/ZT 160-275 HV

Parts list

What sets Atlas Copco apart as a company is our conviction that we can only excel in what we do if we provide the best possible know-how and technology to really help our customers produce, grow and succeed.

There is a unique way of achieving that - we simply call it the Atlas Copco way. It builds on **interaction**, on long-term relationships and involvement in the customers' process, needs and objectives. It means having the flexibility to adapt to the diverse demands of the people we cater for.

It's the **commitment** to our customers' business that drives our effort towards increasing their productivity through better solutions. It starts with fully supporting existing products and continuously doing things better, but it goes much further, creating advances in technology through **innovation**. Not for the sake of technology, but for the sake of our customer's bottom line and peace-of-mind.

That is how Atlas Copco will strive to remain the first choice, to succeed in attracting new business and to maintain our position as the industry leader.



\* 9 0 9 5 0 5 0 3 5 5 \*